

Preface

Thank you for purchasing the FC155 series high performance vector control frequency inverter developed and manufactured by Janson Controls

FC155 series frequency inverter is a general used high performance current vector control inverter with advanced functions, such as high performance vector control of induction motor, user-programmable function and backstage monitoring software, communication bus and supporting multiple PG cards etc. It is applicable to textile, papermaking, wire drawing fans and pumps, machine tools, packaging, food and all kinds of automated production equipment.

This manual introduces functional characteristics and usage of FC155 series inverter, includes product model selection, parameter settings, running and debugging, maintenance, checking, and so on. Please be sure to read this manual carefully before operation. For equipment matching manufacturers, please send this manual to your end user together with your devices, in order to facilitate the usage.

PRECAUTIONS

- ◆ To describe the product details, the illustrations in the manual sometimes are under the state of removing the outer housing or security covering. While using the product, please be sure to mount the housing or covering as required, and operate in accordance with the contents of manual.
- ◆ The illustrations in this manual is only for explanation, may be different from the products your ordered.
- ◆ MBK is committed to constantly improve the products and features will continue to upgrade, the information provided is subject to change without notice.
- ◆ Please contact with the regional agent or client service center directly of MBK if there is any questions during usage.

Contents

Preface	1
Contents	2
Chapter 1 Safety Information and Precautions	4
1.1 Safety Information	4
1.2 General Precautions	6
Chapter 2 Product Information	9
2.1 Designation Rules	9
2.2 Nameplate	9
2.3 FC155 Series Frequency Inverter	9
2.4 Technical Specifications	11
2.5 Product appearance and installation dimension	14
2.6 Options	16
2.7 Daily maintenance of frequency inverters	17
2.8 Warranty Items	18
2.9 Selection Guide of braking component	18
Chapter 3 Installation of Frequency Inverter	21
3.1 Installation environment	21
3.2 Installation direction and space	21
3.3 Peripheral Devices Connection Diagram	22
3.4 Instructions of Main Circuit Peripheral Devices	23
3.5 Model Selection of Main Circuit Peripheral Devices	24
3.6 Removal and mounting of operating panel and cover	25
3.7 Sketch and Description of Main Circuit Terminals	26
3.8 Cautions for Main Circuit Wiring	28
3.9 Control Circuit and Main Circuit Terminals Description	30
Chapter 4 Operation and display	35
4.1 Instruction of operation and display	35
4.2 Viewing and modifying function codes	36
4.3 Monitoring Status Parameters	37
4.4 Password Setting	37

4.5 Motor Parameter Auto-tuning	37
Chapter 5 Function Code Table	39
Chapter 6 Description of Function Codes	78
6.1 Group F0: Basic Function Parameters	78
6.2 Group F1: Start/Stop Control Parameters	88
6.3 Group F2: Input Terminals	92
6.4 Group F3: Pulse/Analog input terminals	99
6.5 Group F4: Output Terminals	103
6.6 Group F5: Pulse/analog output terminals	110
6.7 Group F6: Auxiliary Functions	111
6.8 Group F7: Display Setting	114
6.9 Group F8: Fault and Protection	120
6.10 Group F9: Monitoring Parameters	129
6.11 Group FA: Communication parameters	130
6.12 Group Fb: Process Control PID Function	132
6.13 Group FC: Multi-reference and simple PLC	136
6.14 Group Fd: Swing Frequency, Fixed Length and Count	140
6.15 Group d0: Motor Parameters	142
6.16 Group d1: Motor Vector Control Parameters	145
6.17 Group d2: Torque Control Function	146
6.18 Group d3: V/F Control Parameters	148
6.19 Group d4: Control Optimization Parameters	151
Chapter 7 EMC (Electromagnetic compatibility)	154
7.1 Definition	154
7.2 EMC Standard Description	154
7.3 EMC Guide	154
Chapter 8 Fault Diagnosis and Solution	157
8.1 Fault Alarm and Countermeasures	157
8.2 Common Faults and Solutions	161
Appendix A Modbus communication protocol	164

Chapter 1 Safety Information and Precautions

In this manual, the notices are graded based on the degree of danger:

 **DANGER** indicates that failure to comply with the notice will result in serious injury or even death.

 **WARNING** indicates that failure to comply with the notice will result in moderate or minor injury and equipment damage.

Read this manual carefully so that you have a thorough understanding. Installation, commissioning or maintenance may be performed in conjunction with this chapter. MBK will assume no liability or responsibility for any injury or loss caused by improper operation.

1.1 Safety Information

1.1.1 Before installation

 **DANGER**

1. Do not use damaged or missing components frequency inverter. Failure to comply will result in personal injury.
2. Please use the electric motor with upper B insulation class. Failure to comply will result in personal injury.

1.1.2 During installation

 **DANGER**

1. Install the frequency inverter on incombustible objects such as metal, and keep it away from combustible materials. Failure to comply may result in a fire.

 **WARNING**

2. When two frequency inverters are laid in the same cabinet, arrange the installation positions properly to ensure the enough cooling effect.
3. Do not drop wire residue or screw into the frequency inverter. Failure to comply will result in damage to the frequency inverter.

1.1.3 Wiring

 **DANGER**

1. Wiring must be performed only by qualified personnel under instructions described in this manual. Failure to comply may result in unexpected accidents.
2. A circuit breaker must be used to isolate the power supply and the frequency inverter. Failure to comply may result in a fire.

3. Ensure that the power supply is cut off before wiring. Failure to comply may result in electric shock.
4. Connect the frequency inverter to ground properly by standard. Failure to comply may result in electric shock.

 **WARNING**

5. Never connect the power supply cables to the output terminals (U, V, W) of the Frequency inverter. Failure to comply will result in damage to the frequency inverter.
6. Make sure that all the connecting wires comply with the requirement of EMC and the safety standard in the region. Use wire sizes recommended in the manual. Failure to comply may result in accidents.
7. Never connect the braking resistor between the DC bus terminals (P+) and (P-). Failure to comply may result in a fire.

1.1.4 Before power-on

 **DANGER**

1. Check that the following requirements comply with:

The voltage class of the power supply is consistent with the rated voltage class of the frequency inverter.

The input terminals (R, S, T) and output terminals (U, V, W) are properly connected.

No short-circuit exists in the peripheral circuit.

The wiring is fastened.

Failure to comply will result in damage to frequency inverter.

2. Cover the frequency inverter properly before power-on to prevent electric shock.

 **WARNING**

3. Do not perform the voltage resistance test on any part of the frequency inverter because such test has been done in the factory. Failure to comply will result in accidents.

4. All peripheral devices must be connected properly under the instructions described in this manual. Failure to comply will result in accidents.

1.1.5 After power-on

 **DANGER**

1. Do not open the frequency inverter's cover after power-on to prevent from electric shock.
2. Do not touch the frequency inverter and its peripheral circuit to prevent from electric shock.
3. Do not touch the terminals of the frequency inverter (including the control terminals). Failure to comply may result in electric shock.
4. Do not touch the U, V, W terminal or motor connecting terminals when frequency inverter automatically does safety testing for the external high-voltage electrical circuit. Failure to comply may result in electric shock.

 **WARNING**

5. Note the danger during the rotary running of motor when check the parameters. Failure to comply will result in accidents.

6. Do not change the factory default settings of the frequency inverter. Failure to comply will result in damage to the frequency inverter.

1.1.6 During operation



1. Do not get close to the equipment when selected the restart function. Failure to comply may result in personal injury.
2. Do not touch the fan or the discharging resistor to check the temperature. Failure to comply will result in personal injury.
3. Signal detection must be performed only by qualified personal during operation



4. Avoid objects falling into the frequency inverter when it is running. Failure to comply will result in damage to frequency inverter.
5. Do not start/stop the frequency inverter by turning the contactor ON/OFF. Failure to comply will result in damage to the frequency inverter.

1.1.7 Maintenance



1. Do not repair or maintain the frequency inverter at power-on. Failure to comply will result in electric shock.
2. Repair or maintain the frequency inverter only after the charge light on frequency inverter is powered off. This allows for the residual voltage in the capacitor to discharge to a safe value. Failure to comply will result in personal injury.
3. Repair or maintenance of the frequency inverter may be performed only by qualified personnel. Failure to comply will result in personal injury or damage to the frequency inverter.

1.2 General Precautions

1.2.1 Motor insulation test

Perform the insulation test when the motor is used for the first time, or when it is reused after being stored for a long time, or in a regular check-up, in order to prevent the poor insulation of motor windings from damaging the frequency inverter. The motor must be disconnected from the frequency inverter during the insulation test. A 500-V mega-Ohm meter is recommended for the test. The insulation resistance must not be less than $5\text{ M}\Omega$.

1.2.2 Thermal protection of motor

If the rated capacity of the motor selected does not match that of the frequency inverter, especially when the frequency inverter's rated power is greater than the motor's, adjust the motor protection parameters on the operation panel of the frequency inverter or install a thermal relay in the motor circuit for protection.

1.2.3 Running at over 50 Hz

The frequency inverter provides frequency output of 0 to 3000 Hz (Up to 300 Hz is supported if the frequency inverter runs in CLVC and SFVC mode). If the frequency inverter is required to run at over 50 Hz, consider the bearable capacity of the machine.

1.2.4 Vibration of mechanical device

The frequency inverter may encounter the mechanical resonance point at some output frequencies, which can be avoided by setting the skip frequency.

1.2.5 Motor heat and noise

The output of the frequency inverter is pulse width modulation (PWM) wave with certain harmonic frequencies, and therefore, the motor temperature, noise, and vibration are slightly greater than those motor runs at grid power frequency (50 Hz).

1.2.6 Voltage-sensitive device or capacitor at output side of the Frequency inverter

Do not install the capacitor for improving power factor or lightning protection voltage-sensitive resistor at the output side of the frequency inverter because the output of the frequency inverter is PWM wave. Otherwise, the frequency inverter may suffer transient over current and even to be damaged.

1.2.7 Contactor at the Input/Output side of the frequency inverter

When a contactor is installed between the input side of the frequency inverter and the power supply, the frequency inverter must not be started or stopped by switching the contactor on or off. If the frequency inverter has to be operated by the contactor, ensure that the time interval between switching is at least one hour. Since frequently charge and discharge will shorten the service life of the capacitor inside of frequency inverter.

When a contactor is installed between the output side of the frequency inverter and the motor, do not turn off the contactor when the frequency inverter is active. Otherwise, IGBT modules inside of frequency inverter may be damaged.

1.2.8 When input voltage is over rated voltage range

The frequency inverter must not be used over the allowable voltage range specified in this manual. Otherwise, the frequency inverter's components may be damaged. If required, use a corresponding voltage transformer device.

1.2.9 Prohibition of three-phase input changed into two-phase input

Do not change the three-phase input of the frequency inverter to two-phase input. Otherwise, a fault will be result or the frequency inverter will be damaged.

1.2.10 Surge suppressor

The frequency inverter has a built-in voltage dependent resistor (VDR) for suppressing the surge voltage. For frequently surge place, please add extra surge voltage protection device at input side of frequency inverter.

Note: Do not connect the surge suppressor at the output side of the AC.

1.2.11 Altitude and de-rating

In places where the altitude is above 1000 m and the cooling effect reduces due to thin air, it is necessary to de-rate the frequency inverter. Please contact our company for technical support.

1.2.12 Some special usages

If wiring that is not described in this manual such as common DC bus is applied, please contact the agent or our company for technical support.

1.2.13 Disposal

The electrolytic capacitors on the main circuits and PCB may explode when they are burnt. Poisonous gas is generated when the plastic parts are burnt. Please treat them as industrial waste.


1.2.14 Adaptable Motor

- The standard adaptable motor is adaptable four-pole squirrel-cage asynchronous induction motor. For other types of motor, select a proper frequency inverter according to the rated motor current. If user uses inverter for permanent magnet synchronous motor, please contact my company for technical support.
- The cooling fan and rotor shaft of non-variable-frequency motor are coaxial, which results in reduced cooling effect when the rotational speed decreasing. If variable speed is required, add a more powerful fan or replace it with variable-frequency motor in applications where the motor overheats easily.
- The standard parameters of the adaptable motor have been configured inside the frequency inverter. It is still necessary to perform motor auto-tuning or modify the default values based on actual conditions. Otherwise, the running result and protection performance will be affected.
- The frequency inverter may alarm or even be damaged when short-circuit exists on cables or inside the motor. Therefore, perform insulation short-circuit test when the motor and cables are newly installed or during routine maintenance. During the test, make sure that the frequency inverter is disconnected from the tested parts.

Chapter 2 Product Information

2.1 Designation Rules

Figure 2-1 Designation rules



2.2 Nameplate

Figure 2-2 Nameplate

MODEL: FC155-3R7G/5R5PT4
 POWER: 3.7/5.5KW
 INPUT: 3PH AC380V~440V 50/60Hz
 OUTPUT: 3PH 0~440V 0~300Hz 9.0/13A
 S/N: Barcode
Janson Controls Technologies (Shenzhen) Co.,Limited

2.3 FC155 Series Frequency Inverter

Table 2-1 Models and technical data of FC155 series

Model	Power Capacity (KVA)	Input Current (A)	Output Current (A)	Adaptable Motor	
				KW	HP
Single-phase 220V, 50/60Hz					
FC155-0R4GS2	1	5.4	2.3	0.4	0.5
FC155-R75GS2	1.5	8.2	4	0.75	1
FC155-1R5GS2	3	14	7	1.5	2

Model	Power Capacity (KVA)	Input Current (A)	Output Current (A)	Adaptable Motor	
				KW	HP
FC155-2R2GS2	4	23	9.6	2.2	3
Three-phase 220V, 50/60Hz					
FC155-0R4GT2	1.5	3.4	2.1	0.4	0.5
FC155-R75GT2	3	5	3.8	0.75	1
FC155-1R5GT2	4	5.8	5.1	1.5	2
FC155-2R2GT2	5.9	10.5	9	2.2	3
FC155-3R7GT2	8.9	14.6	13	3.7	5
FC155-5R5GT2	17	26	25	5.5	7.5
FC155-7R5GT2	21	35	32	7.5	10
FC155-011GT2	30	46.5	45	11	15
FC155-015GT2	40	62	60	15	20
FC155-018GT2	57	76	75	18.5	25
FC155-022GT2	69	92	91	22	30
FC155-030GT2	85	113	112	30	40
FC155-037GT2	114	157	150	37	50
FC155-045GT2	134	180	176	45	60
FC155-055GT2	160	214	210	55	75
FC155-075GT2	231	307	304	75	100
Three-phase 380V, 50/60Hz					
FC155-R75GT4	-	1.5	3.4	2.1	0.75
FC155-1R5GT4	-	3	5	3.8	1.5
FC155-2R2GT4	-	4	5.8	5.1	2.2
FC155-3R7GT4	-	5.9	10.5	9	3.7
FC155-5R5GT4	FC155-5R5PT4	8.9	14.6	13	5.5
FC155-7R5GT4	FC155-7R5PT4	11	20.5	17	7.5
FC155-011GT4	FC155-011PT4	17	26	25	11
FC155-015GT4	FC155-015PT4	21	35	32	15
FC155-018GT4	FC155-018PT4	24	38.5	37	18.5
FC155-022GT4	FC155-022PT4	30	46.5	45	22
FC155-030GT4	FC155-030PT4	40	62	60	30
FC155-037GT4	FC155-037PT4	57	76	75	37
FC155-045GT4	FC155-045PT4	69	92	91	45
FC155-055GT4	FC155-055PT4	85	113	112	55
FC155-075GT4	FC155-075PT4	114	157	150	75
FC155-090GT4	FC155-090PT4	134	180	176	90
FC155-110GT4	FC155-110PT4	160	214	210	110
FC155-132GT4	FC155-132PT4	192	256	253	132
FC155-160GT4	FC155-160PT4	231	307	304	160
FC155-200GT4	FC155-200PT4	250	385	377	200
FC155-220GT4	FC155-220PT4	280	430	426	220

Model		Power Capacity (KVA)	Input Current (A)	Output Current (A)	Adaptable Motor	
					KW	HP
FC155-250GT4	FC155-250PT4	355	468	465	250	350
FC155-280GT4	FC155-280PT4	396	525	520	280	370
FC155-315GT4	FC155-315PT4	445	590	585	315	420
FC155-355GT4	FC155-355PT4	500	665	650	355	470
FC155-400GT4	FC155-400PT4	565	785	725	400	530
FC155-450GT4	FC155-450PT4	630	883	820	450	600

2.4 Technical Specifications

Table 2-2 Technical specifications of FC155

Item	Specifications		
Standard functions	Maximum frequency	0~3200.00Hz	
	Carrier frequency	0.5~16 kHz(The carrier frequency is automatically adjusted based on the load features.)	
	Input frequency resolution	Digital setting: 0.01 Hz Analog setting: maximum frequency x 0.025%	
	Control mode	Sensor-less flux vector control (SFVC) Closed-loop vector control (CLVC) (+PG Card) Voltage/Frequency (V/F) control	
	Startup torque	G type: 0.3Hz/150% (SFVC) ; 0 Hz/180% (CLVC) P type: 0.5Hz/100%	
	Speed range	1: 200 (SFVC)	1:1000 (CLVC)
	Speed stability accuracy	± 0.5% (SFVC)	± 0.02% (CLVC)
	Torque control accuracy	±5% (CLVC)	
	Overload capacity	G type: 60s for 150% of the rated current, 3s for 180% of the rated current P type: 60s for 120% of the rated current, 3s for 150% of the rated current	
	Torque boost	Auto boost; Manual boost: 0.1%~30.0%	
	V/F curve	Straight-line V/F curve Multi-point V/F curve N-powerV/F curve (1.2-power, 1.4-power, 1.6-power, 1.8-power, square)	
	V/F separation	Two types: complete separation; half separation	
	Acceleration/deceleration curve	Straight-line ramp S-curve ramp Four groups of acceleration/deceleration time with the range of 0.00s~65000s	
Standard functions	DC braking	DC braking frequency: 0.00 Hz ~ maximum frequency Braking time: 0.0~100.0s	

Item		Specifications
	JOG control	Braking trigger current value: 0.0%~100.0% JOG frequency range: 0.00Hz~50.00 Hz JOG acceleration/deceleration time: 0.00s~65000s
	Built-in PLC, multiple speeds	It realizes up to 16 speeds via the simple PLC function or combination of DI terminal states.
	Built-in PID	It realizes closed loop control system easily.
	Auto voltage regulation (AVR)	It can keep constant output voltage automatically when the mains voltage fluctuation.
	Overvoltage/Over current stall control	The current and voltage are limited automatically during the running process so as to avoid frequently tripping due to overvoltage/over current.
	Rapid current limit function	It can auto limit running current of frequency inverter to avoid frequently tripping.
	Torque limit and control	(Excavator characteristics) It can limit the torque automatically and prevent frequently over current tripping during the running process. Torque control can be implemented in the VC mode.
	High performance	Control of asynchronous motor is implemented through the high-performance current vector control technology.
Individualized functions	Instant power off not stop	The load feedback energy compensates the voltage reduction so that the frequency inverter can continue to run for a short time.
	Rapid current limit	To avoid frequently over current faults of the frequency inverter.
	Timing control	Time range: 0.0~6500.0 minutes
	Multiple communication protocols	Currently supports communication bus via Modbus-RTU and later will support PROFIBUS-DP, CANopen, etc.
	Motor overheat protection	The optional I/O extension card enables AI3 to receive the motor temperature sensor input (PT100, PT1000) so as to realize motor overheat protection.
	Multiple encoder types	It supports incremental encoder and encoders such as differential encoder, open-collector encoder, resolver, UVW encoder, and SIN/ COS encoder.
	Advanced background software	It supports the operation of frequency inverter parameters and virtual oscilloscope function, by which the state of frequency inverter can be monitored.
Run	Running command giving	key panel Control terminals Serial communication port You can switch between these giving in various ways.
	Frequency giving	There are 10 kinds frequency giving: digital setting, analog voltage setting, analog current setting, pulse setting, serial communication port setting, panel potentiometer, etc. You can switch between these giving in various ways.

Item	Specifications
Auxiliary frequency giving	There are 10 kinds auxiliary frequency giving. It can implement tiny tuning of auxiliary frequency and frequency synthesis.
Input terminal	<p>Standard:</p> <p>5 digital input (DI) terminals, one of which supports up to 100 kHz high-speed pulse input</p> <p>2 analog input (AI) terminals, support 0V~10 V voltage input or 0 mA~20 mA current input</p> <p>Expanding capacity:</p> <p>5 DI terminals</p> <p>1 AI terminal supports -10V~10 V voltage input.</p>
Output terminal	<p>Standard</p> <p>1 high-speed pulse output terminal (open-collector) that supports 0~100 kHz square wave signal output</p> <p>1 digital output (DO) terminal</p> <p>1 relay output terminal</p> <p>2 analog output (AO) terminals, support 0 mA~20 mA current output or 0 V~10 V voltage output.</p> <p>Expanding capacity:</p> <p>1 DO terminals</p> <p>1 relay output terminals</p>
Display and operation on the key panel	<p>LED display</p> <p>It displays the parameters.</p> <p>Parameters copy</p> <p>It can implement copy parameters function by PC software.</p> <p>Key locking and function selection</p> <p>It can lock the keys partially or completely and define the function range of some keys so as to prevent misoperation.</p> <p>Protection mode</p> <p>Motor short-circuit detection at power-on, input/output phase loss protection, overcurrent protection, overvoltage protection, under-voltage protection, overheat protection and overload protection, etc.</p>
Environment	<p>Installation location</p> <p>Indoor, no direct sunlight, dust, corrosive gas, combustible gas, oil smoke, vapor, drip or salt.</p> <p>Altitude</p> <p>Lower than 1000 m</p> <p>Ambient temperature</p> <p>-10°C~ +40°C (derated if the ambient temperature is between 40°C and 50°C)</p> <p>Humidity</p> <p>Less than 95%RH, without condensing</p> <p>Vibration</p> <p>Less than 5.9 m/s² (0.6 g)</p> <p>Storage temperature</p> <p>-20°C ~ +60°C</p>

2.5 Product appearance and installation dimension

2.5.1 Product appearance




Figure 2-3 FC155 series Product appearance (With potentiometer)




Figure 2-4 Appearance and installation dimension of FC155 series (Plastic housing structure)




Figure 2-5 Appearance and installation dimension of FC155 series (Metal housing structure)

The housing type of the FC155 models is listed in the following table.

Voltage & Power Class	Housing Type
Single-phase 220V	
0.4 - 2.2 Kw	Plastic housing
Three-phase 220 V	
0.4 - 7.5 Kw	Plastic housing
11 -75 Kw	Metal sheethousing
Three-phase 380 V	
0.75 - 18.5 Kw	Plastic housing
22 - 400 Kw	Metal sheet housing

2.5.2 Appearance and Mounting Hole Dimension (mm) of FC155 Frequency Inverter

Table 2-3 Appearance and mounting hole dimension (mm) of FC155 frequency inverter

Model	Appearance and installing dimension (mm)							Weight (kg)
	A	B	H	H1	W	D	Φd	
Three-phase 380V								
FC155-R75G/1R5PT4	113	172	186	-	125	164	ø5.0	2.0
FC155-1R5G/2R2PT4								
FC155-2R2G/3R7PT4	148	236	248	-	160	183	ø5.0	3.5
FC155-3R7G/5R5PT4								
FC155-5R5G/7R5PT4	190	305	322	-	208	192	ø6	6.2
FC155-7R5G/011PT4								
FC155-011G/015PT4	230	440	455	290	218	ø7	16.2	
FC155-015G/018PT4								
FC155-018G/022PT4	230	540	555	320	240	ø10	30	
FC155-022G/030PT4								
FC155-030G/037PT4	320	610	635	410	239	ø12	45	
FC155-037G/045PT4								
FC155-045G/055PT4	320	630	654	460	340	ø12	65	
FC155-055G/075PT4								
FC155-075G/090PT4	320	856	886	520	385	ø13	105	
FC155-090G/110PT4								
FC155-110G/132PT4	500	1313	1350	750	432	ø13	240	
FC155-132G/160PT4								
FC155-160G/200PT4	500	1410	1450	850	432	ø13	300	
FC155-200G/220PT4								
FC155-220G/250PT4	500	1410	1450	850	432	ø13	300	
FC155-250G/280PT4								
FC155-280G/315PT4	500	1410	1450	850	432	ø13	300	
FC155-315G/355PT4								
FC155-355G/400PT4	500	1410	1450	850	432	ø13	300	

Model	Appearance and installing dimension (mm)							Weight (kg)
	A	B	H	H1	W	D	Φd	
FC155-400G/450PT4								

2.5.3 Appearance and installation dimension of external keypad (keypad tray)




Figure 2-6 Appearance and installation dimension of external keypad (keypad tray)

2.6 Options

Please indicate if the following options are needed when placing order.

Table 2-4 Options of FC155 frequency inverter

Item	Model	Functions	Remarks
Internal braking unit	With "-B" after the product model	Single-phase: 0.4Kw~2.2Kw; Three-phase: 0.75Kw~18.5Kw, Standard built-in brake unit	The internal braking unit is optional for 22Kw~75Kw.
External braking unit		External braking unit for above 75Kw(including 75Kw)	

Item	Model	Functions	Remarks
Energy-regeneration unit		Energy saving product makes the electric energy offfrequency inverter feedback to the AC power grid.	
Rectifying unit		When manyfrequency inverters use the same DC bus, itcan save energy.	

2.7 Daily maintenance of frequency inverters

2.7.1 Daily maintenance

Due to the influence of temperature, humidity, dust and vibration, it will lead to poor heat dissipation and component aging of frequency inverter, and results in potential failure or reducing the service life of frequency inverter. Therefore, it is necessary to do daily and regular maintenance of the frequency inverter.

Daily check items:

- 1) Check if the sound is normal during the running of the motor;
- 2) Check if there is a vibration during the running of the motor;
- 3) check whether the installation environment of frequency inverter has changed;
- 4) Check if the cooling fan of frequency inverter is working correctly, the cooling air duct is clear;
- 5) Check if the frequency inverter is overheating;
- 6) Make sure that the frequency inverter should always be kept in a clean state;
- 7) Clear up effectively the dust on the surface of frequency inverter, prevent the dust from entering into the inside of frequency inverter, especially for the metal dust;
- 8) Clear up effectively the oil and dust on the cooling fan of frequency inverter.

2.7.2 Regular inspection

Please regularly check the frequency inverter, especially for the difficult checking place of running.

Regular inspection items:

- 1) Check the air duct and clear up regularly;
- 2) Check if there are any loose screws;
- 3) Check if the inverter has been corroded;
- 4) Check whether the wiring terminals show signs of arcing;
- 5) Main circuit insulation test.

Note: When using the megger(please use the DC 500V meg ohm meter) to measure the insulation resistance, you shall disconnect the main circuit with the frequency inverter. Do not use the insulation resistance meter to test the control circuit. It don't have to do the high voltage test (It has been done when the frequency inverter produced in factory.)

2.7.3 Wearing parts replacement

The wearing parts of frequency inverter include the cooling fan and filter electrolytic capacitor, its service life is closely related to the using environment and maintenance status. The general service life is shown as follows:

Part Name	Service Life
Fan	2 ~ 3 Years

Electrolytic capacitor	4 ~ 5 Years
------------------------	-------------

The user can confirm the replace time according to the running time.

- 1) Possible reasons for the damage of cooling fan: bearing wear and vane aging. Distinguish standard: Any cracks in the fan vanes, any abnormal vibration sound during the starting of frequency inverter.
- 2) Possible reasons for the damage of filter electrolytic capacitor: poor quality of the input power supply, the environment temperature is high, the load change frequently and the electrolyte aging. Distinguish standard: Any leakage of its liquid, if the safety valve is protruding, electrostatic capacitance and insulation resistance measurement.

2.7.4 Storage of the frequency inverter

After buying the frequency inverter, users shall pay attention to the temporary and long-term storage as following:

- 1) Store the frequency inverter in the original packaging;
- 2) Long-term storage can lead to the degradation of electrolytic capacitors, and must ensure to power on for once within half a year. And the power-on time is at least 5 hours. The input voltage must rise slowly to the rating by using the voltage regulator.

2.8 Warranty Items

- 1) Warranty only refers to frequency inverter.
- 2) Under normal use, if there is any failure or damage, our company is responsible for the warranty within 18 months. (Leave factory date is subjected to the S/N on the frequency inverter nameplate or according to the contract). When over 18 months, reasonable fee will be charged for maintenance;
- 3) During the period of 18 months, if the following situation happens, certain maintenance fee will be charged:
 - a. The users don't follow the rules in the manual lead to the frequency inverter damaged;
 - b. The damage caused by fire, flood and abnormal voltage;
 - c. The damage caused by using the frequency inverter for abnormal functions;
 - d. The relevant service fee is calculated according to the manufacturer's standard, if there is an contract, then it is subject to the contract items.

2.9 Selection Guide of braking component

Table 2-5 is the recommended value of braking resistor, users can select the different resistance value and power according to the actual situation, (but the resistance value should not be less than the recommended value in the table and the power can be larger.) The selection of braking resistance need to be confirmed according to the power that the motor generated in the practical application systems, and is relevant to the system inertia, deceleration time, the energy of the potential energy load, needs customers to choose according to actual situation. The greater the inertia the shorter deceleration time is needed and more frequently braking, so that to choose braking resistor with bigger power but smaller resistance value.

2.9.1 Selection of braking resistance value

When braking, almost all the renewable energy of motor is consumed on the braking resistor.

According to the formula: $U * U/R = Pb$

In the formula:

U --- The braking voltage when the system brakes stably (different system is different, for the 380VAC system generally take 700V)

R - Braking resistor

Pb – Braking Power

2.9.2 Selection power of braking resistor

In theory the power of braking resistor is consistent with the braking power, but it need to be taken into consideration that the braking resistor power will derate to 70%.

According to the formula: $0.7 \cdot P_r = P_b \cdot D$

In this formula:

P_r----Resistor power

D---- Braking proportion (the proportion that the regeneration process accounts for the whole process)

Elevator---- 20%~30%

Uncoiling and coiling machine---- 20%~30%

Centrifugal machine---- 50%~60%

Occasionally braking load---- 5%

Other machine generally----10%

Table 2-5 FC155 Inverter braking components selection table


Model	Recommend power of braking resistor	Recommend resistance value of braking resistor	Braking unit	Remarks
Single-phase 220V				
FC155-0R4GS2	80W	$\geq 200\Omega$	Built-in as standard	No special instructions
FC155-R75GS2	80W	$\geq 150\Omega$		
FC155-1R5GS2	100W	$\geq 100\Omega$		
FC155-2R2GS2	100W	$\geq 70\Omega$		
Three-phase 220V				
FC155-0R4GT2	150W	$\geq 150\Omega$	Built-in as standard	No special instructions
FC155-R75GT2	150W	$\geq 110\Omega$		
FC155-1R5GT2	250W	$\geq 100\Omega$		
FC155-2R2GT2	300W	$\geq 65\Omega$		
FC155-3R7GT2	400W	$\geq 45\Omega$		
FC155-5R5GT2	800W	$\geq 22\Omega$		
FC155-7R5GT2	1000W	$\geq 16\Omega$		
FC155-011GT2	1500W	$\geq 11\Omega$	Built-in as option	Add "-B" to the model
FC155-015GT2	2500W	$\geq 8\Omega$		
FC155-018GT2	3.7 kW	$\geq 8.0\Omega$		
FC155-022GT2	4.5 kW	$\geq 8\Omega$		
FC155-030GT2	5.5 kW	$\geq 4\Omega$		
FC155-037GT2	7.5 kW	$\geq 4\Omega$		
FC155-045GT2	4.5 kW×2	$\geq 4\Omega \times 2$	External	—
FC155-055GT2	5.5 kW×2	$\geq 4\Omega \times 2$	External	—

Model	Recommend power of braking resistor	Recommend resistance value of braking resistor	Braking unit	Remarks
FC155-075GT2	16k W	$\geq 1.2\Omega$	External	—
Three-phase 380V				
FC155-R75G/1R5PT4	150W	$\geq 300\Omega$	Built-in as standard	No special instructions
FC155-1R5G/2R2PT4	150W	$\geq 220\Omega$		
FC155-2R2G/3R7PT4	250W	$\geq 200\Omega$		
FC155-3R7G/5R5PT4	300W	$\geq 130\Omega$		
FC155-5R5G/7R5PT4	400W	$\geq 90\Omega$		
FC155-7R5G/011PT4	500W	$\geq 65\Omega$		
FC155-011G/015PT4	800W	$\geq 43\Omega$		
FC155-015G/018PT4	1000W	$\geq 32\Omega$		
FC155-018G/022PT4	1300W	$\geq 25\Omega$		
FC155-022G/030PT4	1500W	$\geq 22\Omega$		
FC155-030G/037PT4	2500W	$\geq 16\Omega$	Built-in as option	Add "-B" to the model
FC155-037G/045PT4	3.7 kW	$\geq 16\Omega$		
FC155-045G/055PT4	4.5 kW	$\geq 16\Omega$		
FC155-055G/075PT4	5.5 kW	$\geq 8\Omega$	Built-in as option	Add "-B" to the model
FC155-075G/090PT4	7.5 kW	$\geq 8\Omega$		
FC155-090G/110PT4	4.5 kW×2	$\geq 8\Omega \times 2$	External	
FC155-110G/132PT4	5.5 kW×2	$\geq 8\Omega \times 2$		
FC155-132G/160PT4	6.5 kW×2	$\geq 8\Omega \times 2$		
FC155-160G/200PT4	16kW	$\geq 2.5\Omega$	External	
FC155-200G/220PT4	20 kW	$\geq 2.5\Omega$		
FC155-220G/250PT4	22 kW	$\geq 2.5\Omega$	External	
FC155-250G/280PT4	12.5 kW×2	$\geq 2.5\Omega \times 2$		
FC155-280G/315PT4	14 kW×2	$\geq 2.5\Omega \times 2$	External	
FC155-315G/355PT4	16 kW×2	$\geq 2.5\Omega \times 2$		
FC155-355G/400PT4	17 kW×2	$\geq 2.5\Omega \times 2$		
FC155-400G/450PT4	14 kW×3	$\geq 2.5\Omega \times 3$		

2.9.3 Braking resistor connection description

The braking resistor connection of FC155 series frequency inverter is showed as below:

Figure 2-7 Braking resistor connection scheme



Chapter 3 Installation of Frequency Inverter


3.1 Installation environment

1. The place with indoor vents or ventilation devices.
2. The environment temperature shall be -10°C~40°C. If the temperature is over 40°C but less than 50°C, better to take down the cover of frequency inverter or open the front door of cabinet to facilitate heat dissipation.
3. Try to avoid high temperature and wet place; the humidity shall be less than 90% without frost deposit.
4. Avoid direct sunlight.
5. Keep away from flammable, explosive and corrosive gas and liquid.
6. No dust, floating fiber and metal particles.
7. Install on the place without strongly vibration. And the vibration should be not over 0.6G, especially pay attention to far away from the punching machine, etc.
8. Keep away from electromagnetic interference source.

3.2 Installation direction and space

In order not to affect the service life of frequency inverter and reduce its performance, note for its installation direction and space and correctly fasten it.

Figure 3-1 Ventilating duct installation dimension diagram of frequency inverter



Power class	Installation dimension	
	A	B
≤7.5kW	≥ 20mm	≥ 100mm
11kW~ 30kW	≥ 50mm	≥ 200mm
≥ 37kW	≥ 50mm	≥ 300mm

Please install the frequency inverter vertically, to send out the heat upward, and pay attention to the direction of frequency inverter to avoid inversion.

If there are several units of frequency inverters to install in one cabinet, please install them side by side,

do not to install up and down.

3.3 Peripheral Devices Connection Diagram

Figure 3-2 Peripheral Devices Connection

Please use the inverter within the allowed range of power supply

Notice that the selection of circuit breaker as there is a great impulse current flowing into the inverter when it powered on

Please avoid to frequently start/stop the inverter with the contactor to ensure safety and avoid shortening the service life of inverter.

To suppress high harmonics and improve the power factor

To prevent electric shock, motor and inverter must well grounded

Grounding

Output AC noise filter

AC motor

Three-phase AC Power

R S T




No-fuse circuit breaker (MCCB) or Leakage circuit breaker




Electromagnetic
Electromagnetic Contactor



Input AC reactor



Input AC noise filter



Braking resistor / energy
feedback unit (option)




Braking resistor (option)



Output AC noise filter



DC reactor



Grounding

3.4 Instructions of Main Circuit Peripheral Devices

Table 3-1 Main circuit peripheral devices use instructions

Parts Name	Installation Location	Function Description
MCCB	Front of input circuit	The capacity of the circuit breaker shall be 1.5 to 2 times of the rated current of the inverter. The protect time of the circuit breaker shall fully consider the time features of the inverter overload protection.
Residual-current circuit breaker(RCCB)	Front of input circuit	As the inverter output is the high-frequency pulse voltage, so that it will arise a high-frequency leakage current. Special leakage circuit breaker shall be used when installing leakage circuit breaker at the input side of the inverter. B type leakage circuit breaker is recommended, and the leakage current value shall be set as 300mA.
Contactor	Between MCCB and input side of frequency inverter	Frequently open and close of contactor will cause inverter failure, so that the highest frequency for opening and closing of contactor shall be not exceeded than 10 times/min when braking resistor is used, to avoid the over-hot damage of braking resistor, please install thermal protection relay to do over-hot detection of braking resistor, to control the disconnection of the input contactor via touch points of the thermal protection relay.
Input AC reactor or DC reactor	Input side of frequency inverter , near the inverter	1. The inverter power supply capacity is more than 600kVA or 10 times of the power supply capacity. 2. If there is switch type reactive-load compensation capacitor or load with silicon control at the same power node, there will be high peak current flowing into input power circuit, causing the damage of the rectifier components. 3. When the voltage unbalance degree of the three-phase power supply of the inverter exceeds 3%, the rectifier components will be damaged. 4. It is required that the input power factor of inverter shall be higher than 90%. When the above situations occurred, install the AC reactor at the input side of inverter or DC reactor to the DC reactor terminal.
Input noise filter	Input side of frequency inverter	To reduce the noise input from the power to the inverter or output from the inverter to the power.
Thermal protection relay	Output side of frequency inverter	Although the inverter has motor overload protection function, when one inverter drives two or more motors or multi-pole motors, to prevent the motor over-temperature failure, thermal protection relay shall be installed between the inverter and each motor.
Output filter	Output side of frequency inverter	When the output side of the inverter is connected with output filter, the conduction and radiation interference can be reduced.
Output AC reactor	Between the output side of frequency inverter and motor, near the frequency inverter	When the cable connecting the inverter and the motor is longer than 100 meters, it is suggested to install AC output reactor to suppress the high-frequency oscillation to avoid the damage to motor insulation, large leakage current and frequent inverter protective action.

3.5 Model Selection of Main Circuit Peripheral Devices

Table 3-2 Model Selection Diagram of Main Circuit Peripheral Devices (Recommended)

Model	MCCB (A)	Contactor (A)	Cable of Input Side Main Circuit (mm ²)	Cable of Output Side Main Circuit (mm ²)	Cable of Control Circuit (mm ²)
Single-phase 220V					
FC155-0R4GS2	16	10	2.5	2.5	1.0
FC155-R75GS2	16	10	2.5	2.5	1.0
FC155-1R5GS2	20	16	4.0	2.5	1.0
FC155-2R2GS2	32	20	6.0	4.0	1.0
Three-phase 220V					
FC155-0R4GT2	10	10	2.5	2.5	1.0
FC155-R75GT2	16	10	2.5	2.5	1.0
FC155-1R5GT2	16	10	2.5	2.5	1.0
FC155-2R2GT2	25	16	4.0	4.0	1.0
FC155-3R7GT2	32	25	4.0	4.0	1.0
FC155-5R5GT2	63	40	4.0	4.0	1.0
FC155-7R5GT2	63	40	6.0	6.0	1.0
FC155-011GT2	100	63	10	10	1.0
FC155-015GT2	125	100	16	10	1.0
FC155-018GT2	160	100	16	16	1.0
FC155-022GT2	200	125	25	25	1.0
FC155-030GT2	200	125	35	25	1.0
FC155-037GT2	250	160	50	35	1.0
FC155-045GT2	250	160	70	35	1.0
FC155-055GT2	350	350	120	120	1.0
FC155-075GT2	500	400	185	185	1.0
Three-phase 380V					
FC155-R75G/1R5PT4	10	10	2.5	2.5	1.0
FC155-1R5G/2R2PT4	16	10	2.5	2.5	1.0
FC155-2R2G/3R7PT4	16	10	2.5	2.5	1.0
FC155-3R7G/5R5PT4	25	16	4.0	4.0	1.0
FC155-5R5G/7R5PT4	32	25	4.0	4.0	1.0
FC155-7R5G/011PT4	40	32	4.0	4.0	1.0
FC155-011G/015PT4	63	40	4.0	4.0	1.0
FC155-015G/018PT4	63	40	6.0	6.0	1.0
FC155-018G/022PT4	100	63	6	6	1.0
FC155-022G/030PT4	100	63	10	10	1.0
FC155-030G/037PT4	125	100	16	10	1.0
FC155-037G/045PT4	160	100	16	16	1.0
FC155-045G/055PT4	200	125	25	25	1.0
FC155-055G/075PT4	250	125	35	25	1.0
FC155-075G/090PT4	250	160	50	35	1.0
FC155-090G/110PT4	350	160	70	35	1.0
FC155-110G/132PT4	350	350	120	120	1.0
FC155-132G/160PT4	400	400	150	150	1.0

Model	MCCB (A)	Contactor (A)	Cable of Input Side Main Circuit (mm ²)	Cable of Output Side Main Circuit (mm ²)	Cable of Control Circuit (mm ²)
FC155-160G/200PT4	500	400	185	185	1.0
FC155-200G/220PT4	630	600	150*2	150*2	1.0
FC155-220G/250PT4	630	600	150*2	150*2	1.0
FC155-250G/280PT4	800	600	185*2	185*2	1.0
FC155-280G/315PT4	800	800	185*2	185*2	1.0
FC155-315G/355PT4	1000	800	150*3	150*3	1.0
FC155-355G/400PT4	1000	800	150*4	150*4	1.0
FC155-400G/450PT4	1200	1000	150*4	150*4	1.0

3.6 Removal and mounting of operating panel and cover


3.6.1 Removal and mounting of operating panel (keypad)

The operating panel of FC155 series Frequency inverter is a plug type, If you need to take it off when use or maintenance, please make sure the gentle actions, or it is easy to damage the plug type connection terminals on operating panel.

3.6.2 Removal and Mounting of Frequency Inverter Cover


The FC155 series frequency inverter above 18.5kw (380V) uses plastic case. The removal and mounting of upper cover refers Figure 3-3. Please use tool to push the hooks on both side of upper cover.

Figure 3-3 the cover removal of plastic case



The FC155 series frequency inverter above 22kw (380V) uses metal case. The removal of lower cover refers figure 3-4. Or follow the operation, firstly use hands to remove the two screws from the bottom of upper cover, then press and raise the bottom of upper cover.

Figure 3-4 Removal of metal case upper cover



3.7 Sketch and Description of Main Circuit Terminals

3.7.1 Function and description of Main Circuit Terminals

3.7.1.1 Main Circuit Terminals Sketch of Single-phase 220V Models

Including model:

Single-phase 220V: FC155-0R4GS2~FC155-2R2GS2



Terminal symbol	Terminal name and function description
P+、PB	Connecting terminals of braking resistor
P+、P-	Input terminals of DC power
⊕/ E	Grounding terminal
L1、L2	Single-phase AC powerinput terminals
U/T1、V/T2、W/T3	Three-phase AC power outputterminals

3.7.1.2 Main Circuit Terminals Sketch of Three-phase 220V/380V Small Rated Power Standard Models

Including model:

Three-phase 220V: FC155-0R4GT2~FC155-7R5GT2

Three-phase 380V: FC155-R75G/1R5PT4~FC155-015G/018PT4




Terminal symbol	Terminal name and function description
+, PB	Connecting terminals of braking resistor
+, -	Input terminals of DC power
⊕/ E	Grounding terminal

R、S、T	Three-phase AC powerinput terminals
U、V、W	Three-phase AC power outputterminals

3.7.1.3 Main Circuit Terminals Sketch of Three-phase 220V/380V Middle and Big Power Standard Models

Including model:

Three-phase 380V: FC155-011G/015PT4~FC155-018G/022PT4



Terminal symbol	Terminal name and function description
R、S、T	Three-phase AC power input terminals
+, PB	Connecting terminals of braking resistor
+, -	DC power input terminals;
U、V、W	Three-phase AC power output terminals
⏚/E	Grounding terminal

Three-phase 380V: FC155-022G/030PT4~FC155-110G/132PT4



Terminal symbol	Terminal name and function description
R/L1、S/L2、T/L3	Three-phase AC power input terminals
P、P+	Connecting terminals of external DC reactor, Normally short circuited with copper bar.
P+、P-	DC power input terminals; DC output terminals of external braking unit
U/T1、V/T2、W/T3	Three-phase AC power output terminals
⏚/E	Grounding terminal

Three-phase 380V: FC155-132G/160PT4



Terminal symbol	Terminal name and function description
R/、S/L2、T/L3	Three-phase AC power input terminals
P+ 、P-	DC power input terminals
U/T1、V/T2、W/T3	Three-phase AC power output terminals
E	Grounding terminal

Note: Product with standard built-in unit can realize DC bus and braking function at the same time, if external DC reactor and braking function is needed, please contact the manufacturer.

3.8 Cautions for Main Circuit Wiring

3.8.1 Power Supply Wiring

- ◆ It is forbidden to connect the power cable to the inverter output terminal, otherwise, the internal components of the inverter will be damaged.
- ◆ To facilitate the input side over current protection and maintenance after power off, the inverter shall connect to the power supply through the circuit breaker or leakage circuit breaker and contactor.
- ◆ Please confirm that the power supply phases, rated voltage are consistent with that of the nameplate, otherwise, the inverter may be damaged.

3.8.2 Motor Wiring

- ◆ It is forbidden to short circuit or ground the inverter output terminal, otherwise the internal components of the inverter will be damaged.
- ◆ Avoid short circuit the output cables or with the inverter enclosure, otherwise there exists the danger of electric shock.
- ◆ It is forbidden to connect the output terminal of the inverter to the capacitor or LC/RC noise filter with phase lead, otherwise, the internal components of the inverter may be damaged.
- ◆ When contactor is installed between the inverter and the motor, it is forbidden to switch on/off the contactor during the running of the inverter, otherwise, there will be large current flowing into the inverter, triggering the inverter protection action.
- ◆ Length of cable between the inverter and motor
If the cable between the inverter and the motor is too long, the higher harmonic leakage current of the output end will produce by adverse impact on the inverter and the peripheral devices. It is suggested that when the motor cable is longer than 100m, output AC reactor be installed. Refer to the following table for the carrier frequency setting.

Table 3-3 Comparison table between the cable length and carrier frequency

Length of cable between the inverter and motor	Less than 50m	Less than 100 m	More than 100m
Carrier frequency (d4-00)	Less than 15kHz	Less than 10kHz	Less than 5kHz

3.8.3 Grounding Wiring

- ◆ The inverter will produce leakage current. The higher the carrier frequency is, the larger the leakage current will be. The leakage current of the inverter system is more than 3.5mA, and the specific value of the leakage current is determined by the use conditions. To ensure the safety, the inverter and the

motor must be grounded.


- ◆ The grounding resistance shall be less than 10ohm. For the grounding wire diameter requirement, refer to 2.6 electrolyte of main circuit peripheral devices.
- ◆ Do not share grounding wire with the welding machine and other power equipment.
- ◆ In the applications with more than 2 inverters, keep the grounding wire from forming a loop.

Figure 3-5 Grounding Wire Connection Sketch Map



3.8.4 Countermeasures for Conduction and Radiation Interference


Figure 3-6 Connection of conduction and radiation interference solutions



- ◆ When the noise filter is installed, the wire connecting the filter to the inverter input power end shall be as short as possible.
- ◆ The filter enclosure and mounting cabinet shall be reliably grounded in large area to reduce the back flow impedance of the noise current I_g .
- ◆ The wire connecting the inverter and the motor shall be as short as possible. The motor cable adopts 4-core cable, with the grounding end grounded at the inverter side, the other end connected to the motor enclosure. The motor cable shall be sleeved into the metal tube.
- ◆ The input power wire and output motor wire shall be kept away from each other as far as possible.
- ◆ The equipment and signal cables vulnerable to influence shall be kept far away from the inverter.
- ◆ Key signal cables shall adopt shielding cable. It is suggested that the shielding layer shall be grounded with 360-degree grounding method and sleeved into the metal tube. The signal cable shall be kept far away from the inverter input wire and output motor wire. If the signal cable must cross the input wire and output motor wire, they shall be kept orthogonal.
- ◆ When analog voltage and current signals are adopted for remote frequency setting, twinning shielding cable shall be used. The shielding layer shall be connected to the grounding terminal PE of the inverter, and the signal cable shall be no longer than 50m.
- ◆ The wires of the control circuit terminals RA/RB/RC and other control circuit terminals shall be separately routed.
- ◆ It is forbidden to short circuit the shielding layer and other signal cables and the equipment.
- ◆ When the inverter is connected to the inductive load equipment (e.g. electromagnetic contactor, relay and solenoid valve), surge suppressor must be installed on the load equipment coil, as showed in

Figure 3-7


Figure 3-7 Application example of inductive load surge suppressor



3.9 Control Circuit and Main Circuit Terminals Description


3.9.1 Control Circuit and Main Circuit Wiring

Figure 3-8 Control Circuit and Main Circuit Wiring



3.9.2 Control Circuit Terminal Layout

Figure 3-9 FC155 series control circuit terminal sketch map



3.9.3 Description of control circuit terminals

Table 3-4 Description of control circuit terminals



Type	Terminal Symbol	Terminal Name	Terminal function description
Power Supply	+10V-GND	External +10V power supply	Provide +10V power supply to external unit. Maximum output current:10mA Generally, it provides power supply to external potentiometer with resistance range of 1 kΩ~5kΩ
	+24V-COM	External +24V power supply	Provide +24 V power supply to external unit. Generally, it provides power supply to DI/DO terminals and external sensors. Maximum output current: 200 mA
	PLC-+24V	External power supply	The factory default setting is connected PLC with +24V terminal. When using the external signal to drive DI1~DI5, it will disconnect the connector slip of PLC with the +24V.
Analog input	AI1-GND	Analog input terminal 1	1. Input range: DC 0V~10V/ 0mA~20mA, decided by jumper J12 on the control board 2. Impedance: 22 kΩ (voltage input), 500 Ω (current input)
	AI2-GND	Analog input terminal 2	1. Input range: DC 0V~10V/ 0mA~20mA, decided by jumper J5 on the control board 2. Impedance: 22 kΩ (voltage input), 500 Ω (current input)
Digital input	DI1	Digital input 1	1. Optical coupling isolation, compatible with dual polarity input
	DI2	Digital input 2	2. Input Impedance: 2.4 kΩ
	DI3	Digital input 3	3. Voltage range for level input: 9V~30 V
	DI4	Digital input 4	Besides features of DI1~DI4 and it can be used for high-speed pulse input. Maximum input frequency: 100 kHz
	DI5/HDI	High Speed Pulse Input Terminal	
Analog output	AO1-GND	Analog output terminal 1	Voltage or current output is decided by jumper J4. Output voltage range: 0V~10 V Output current range: 0mA~20 mA
	AO2-GND	Analog output terminal 2	Voltage or current output is decided by jumper J5. Output voltage range: 0V~10 V Output current range: 0mA~20 mA

Type	Terminal Symbol	Terminal Name	Terminal function description
Digital output	DO1-CME	Digital output 1	Optical coupling isolation, dual-polarity open collector output Output voltage range: 0V~24 V Output current range: 0mA~50 mA Note that CME and COM are internally insulated, but they are shorted by jumper externally by factory default. In this case DO1 is driven by +24 V, If you want to drive DO1 by external power supply, please remove jumper between CME and COM.
	FM- COM	High Speed Pulse Output Terminal	It is set by b4-00 (FM terminal output modeselection) As high-speed pulse output, the maximum frequency achieves to 100 kHz. As open-collector output, its function is the same as that of DO1.
Relay output	TA-TB	NC terminal	Contact driving capacity: 250 VAC, 3 A, COSØ = 0.4
	TA-TC	NO terminal	DC 30 V, 1 A

3.9.4 Wiring of Analog Input Terminals

When the voltage signal is used as analog input, it is susceptible from outside interference. Please use shielding cable, and ensure that the shielding cable inerrably connects to the grounding. The cable should be as short as possible, and keep away from power lines. In serious interference occasions, adding a filter capacitor or ferrite core in signal cable can be considered.


Figure 3-10 wiring of analog input terminals




9.5 Wiring of Multi-functional Input Terminals

Figure 3-11 wiring of digital input terminals in four different modes


DI wiring mode 1(factory default wiring mode): the external power supply is not used when DI is set as NPN mode




DI wiring mode 2: the external power supply is used when DI is set as NPN mode




DI wiring mode 3: the external power supply is not used when DI is set as PNP mode




DI wiring mode 4: the external power supply is used when DI is set as PNP mode



3.9.6 Wiring of digital output terminals when using internal and external power supply



Internal power supply wiring



External power supply wiring

Note: When external power supply is adopted, please connect negative end of external power supply with terminal COM. The maximum current of open-collector output is 50mA. If the external load is a relay, please install a fly-wheel diode to the two sides of relay. Please correctly install the polarity of fly-wheel diode, otherwise control card and DSP can be damaged.

3.9.7 Description of Control Circuit Jumper


Jumper Name	Function Description	Default Setting
J2	Mode selection of AI1 voltage or current input	V
J3	Mode selection of AI2 voltage or current input	I
J4	Mode selection of AO1 voltage or current input	V
J5	Mode selection of AO2 voltage or current input	I
J6	Local keyboard OFF or external drive ON	Model selection
J7	Communicate one unit OFF, multiple units in parallel ON	OFF
J9	Selection of control card grounding	OFF

Chapter 4 Operation and display

4.1 Instruction of operation and display

By using the operation panel, it is available to realize the functions such as parameter modification, inverter working state monitoring and STAT/STOP of inverter running control, etc. Its appearance and functions are showed as following pictures:

Figure 4-1 Operating panel



1) Description of indicator

- RUN:

OFF indicates that the frequency inverter is in the stop state and ON indicates that the frequency inverter is in the running state.

- LOCAL:

It is an indicator of the operation controlled by keypad, terminals or remote (communication). OFF indicates keypad operation control state; ON indicates terminals operation control state; Blinking indicates remote operation control state.

- FWD/REV: It is Forward/Reverse indicator, OFF indicates forward running, ON indicates reverse running.

- TUNE: Tuning/ Torque Control/Fault indicator

When the indicator is ON, it indicates torque control mode. When the indicator is blinking slowly, it indicates the auto-tuning state. When the indicator is blinking quickly, it indicates the fault state.

2) Unit indicator

Hz: frequency unit;

A: Current unit;

V: Voltage unit

3) Digital display area

The 5-digit LED display is able to display the set frequency, output frequency, monitoring data and fault codes.

4) Description of keys on the operation panel (keypad)

Table 4-1 Keypad function table


Key	Name	Function
PRG	Programming	Enter or exit menu level I.
ENT	Confirmation	Enter the menu interfaces level by level, and confirm the parameter setting.
△	Increment	Increase data or function code.
▽	Decrement	Decrease data or function code.
▷	Shift	Select the displayed parameters in turn in the stop or running state, and select the digit to be modified when modifying parameters.
RUN	RUN	Start the frequency inverter in the operation panel control mode.
STOP	Stop/Reset	Stop the operation when it is in the running state and perform the reset operation when it is in the fault state. The functions of this key are restricted by F7-18.
MF.K	Multi-function	Perform function switchover according to the setting of F7-31.
Potentiometer	Operation panel	Regulate the speed directly by panel potentiometer when F0-10 is set to 10.

4.2 Viewing and modifying function codes

The operation panel of the FC155 adopts easy two-level menu for the operation such as parameter setting, etc.

The two-level menu consists of function code group, function code (Level I menu), and function code setting value (level II menu), as shown in the following figure.

Figure 4-3 Operation procedure on the operation panel



Instruction: When using two-level mane, you can return to level I menu by pressing key PRG or ENTER.

The difference between them is:

After you press ENTER, the system saves the parameter setting first, and then goes back to Level I menu and shifts to the next function code.

After you press PRG, the system does not save the parameter setting, but directly returns to Level I menu and remains at the present function code.

Under the Level II state, if there is no blinking digit of this parameter, then it indicates that the parameter can not to be modified. The possible reasons are:

- 1) This function code is a non-modifiable parameter, such as the actual testing parameters, operation

records, etc.

2) This function code cannot be modified under the running state, but can modify after stopping.

4.3 Monitoring Status Parameters

In the stop or running state, you can press key “▷” on the operation panel to display status parameters. Whether the parameters are displayed, it is determined by the bits of values converted from the values of parameters F7-00~F7-09 in the hexadecimal format.

In stop state, there are 14 status parameters you can select to displayed or not, they are: setting frequency, bus voltage, DI input status, DO output status, analog input AI1 voltage, analog input AI2 voltage, analog input AI3 voltage, count value, length value, PLC running step, load speed, PID setting, PULSE input frequency, heatsink temperature and one reserved parameters.

In running state, there are 32 running state parameters: including setting frequency, running frequency, bus voltage, output voltage and output current. This five parameters are default displaying. The other display parameter includes output power, output torque, DI input status, DO output status, analog input AI1 voltage, analog input AI2 voltage, analog input AI3 voltage, count value, length value, load speed, PID setting, PID feedback, PLC stage, pulse input frequency, running frequency 2, remaining running time, AI1 voltage before correction, AI2 voltage before correction, AI3 voltage before correction, linear speed, current power-on time, heatsink temperature, communication setting value, encoder feedback speed, main frequency X display and the auxiliary frequency Y, you can set whether these parameters are displayed by F7-00 and F7-06.

When the frequency inverter is repowered on again after power failure, the parameters are recorded as before power failure and displaying.

4.4 Password Setting

The frequency inverter provides the user password protection function. When F2-29 is set to a non-zero value, the value is the user password. The password takes effect after you exit the function code editing state. When you press PRG key, “-----” will be displayed, and you must enter the correct user password to enter the menu, or you cannot enter to the menu. To cancel the password protection function, enter with password and set F7-29 to 0.

Otherwise, the inverter provides READ ONLY protection of function codes to avoid wrong modification. When F7-30 is 0, then all the parameters can be modified; when F7-30 is set to a non-zero value, then all the codes can ready only and cannot be modified. To cancel this protection, set the F7-30 to 0.

4.5 Motor Parameter Auto-tuning

Select vector control running mode, before frequency inverter start to operate, you must accurately write in the nameplate parameter of motor by keypad. FC155 frequency inverter will match standard motor parameter according to the nameplate; the vector control mode strongly depended on motor's parameters, if you want to get good control performance, then you must let inverter to obtain the exact

parameters of controlled motor.

The process of motor auto-tuning is as follows:

Firstly, select command source (F0-01) as keypad command channel. Then write in the actual motor parameters as the following parameters (according to the nameplate of present motor):

Motor	Parameter
auto-tuning	d0-00: Motor Rated Power d0-01: Motor Rated Voltage d0-02: Motor Rated Current d0-03: Motor Rated Frequency d0-04: Motor Rated Speed

AC asynchronous motor tuning

If the motor can be completely separated from the load, then please set d0-05 to 2(asynchronous motor complete auto-tuning), then press the RUN key on the keypad. The frequency inverter will automatically calculate the following parameters of motor:

Motor	Parameter
auto-tuning	d0-06: Stator resistance (asynchronous motor) d0-07: Rotor resistance (asynchronous motor) d0-08: Leakage inductive reactance(asynchronous motor) d0-09: Mutual inductive reactance(asynchronous motor) d0-10: No-load current(asynchronous motor)

Finish motor parameter auto-tuning.

If the motor cannot be completely separated with the load, then please select d0-05 as 1: asynchronous static auto-tuning, and press the RUN key in the keypad panel.

And the frequency inverter will automatically calculate the following parameters of motor:

Motor	Parameter
auto-tuning	d0-06: Stator resistance (asynchronous motor) d0-07: Rotor resistance (asynchronous motor) d0-08: Leakage inductive reactance(asynchronous motor)

If the motor cannot separate from the load, but we still needs accurate motor parameters (such as lifting applications). Set d0-05 to 3: static complete auto-tuning, after confirmation then press RUN key. Then the frequency inverter performs static complete auto-tuning and obtained parameters are same as complete auto-tuning.

Chapter 5 Function Code Table

If F7-29 is set to a non-zero number, parameter protection is enabled. You must enter correct user password to enter the menu.

To cancel the password protection function, enter with password and set F7-29 to 0.

The symbols in the function code table are described as follows:

" \star ": The parameter can be modified when the frequency inverter is in stop or running state.

" $\star\star$ ": The parameter cannot be modified when the frequency inverter is in running state.

" \bullet ": The parameter is the actually measured value and cannot be modified.

" $\ast\ast$ ": The parameter is factory parameter and can be modified only by the manufacturer.

Standard Function Parameters

Function Code	Parameter Name	Setting Range	Default	Property
Group F0: Basic Function Parameters				
F0-00	Motor control mode	0: Sensor-less flux vector control (SFVC) 1: Closed-loop vector control (CLVC) 2: Voltage/Frequency (V/F) control	2	\star
F0-01	Command source selection	0: Operation panel control (LED off) 1: Terminal control (LED on) 2: Communication control (LED blinking)	0	\star
F0-02	Frequency reference resolution	1: 0.1 Hz 2: 0.01 Hz	2	\star
F0-03	Maximum frequency	50.00Hz~320.00Hz, Unit:0.01Hz 50.00~3200.00 Hz(Unit:0.1Hz)	50.00 Hz	\star
F0-04	Source of frequency upper limit	0: Set by F0-05 1: AI1 2: AI2 3: AI3 4: Pulse setting (HDI) 5: Communication setting	0	\star
F0-05	Frequency upper limit	Frequency lower limit ~ maximum frequency	50.00 Hz	\star
F0-06	Frequency upper limit offset	0.00 Hz ~ maximum frequency (F0-03)	0.00 Hz	\star
F0-07	Frequency lower limit	0.00 Hz ~ frequency upper limit (F0-05)	0.00 Hz	\star

Function Code	Parameter Name	Setting Range	Default	Property
F0-08	Preset frequency	0.00Hz ~ maximum frequency	50.00 Hz	☆
F0-09	Base frequency for UP/DOWN modification during running	0: Running frequency 1: Setting frequency	0	★
F0-10	Main frequency source X selection	0: Digital setting (Preset frequency F0-08, UP/DOWN modifiable, non-record at power failure) 1: Digital setting (Preset frequency F0-08, UP/DOWN modifiable, record at power failure) 2: AI1 3: AI2 4: AI3 5: Pulse setting (HDI) 6: Multi-step speed 7: Simple PLC 8: PID 9: Communication setting 10: AI-KB(Only valid for keypad with potentiometer)	10	★
F0-11	Auxiliary frequency source Y selection	0: Digital setting (Preset frequency F0-08, UP/DOWN modifiable, not record at power failure) 1: Digital setting (Preset frequency F0-08, UP/DOWN modifiable, record at power failure) 2: AI1 3: AI2 4: AI3 5: Pulse setting (HDI) 6: Multi-step speed 7: Simple PLC 8: PID 9: Communication setting 10: AI-KB (Only valid for keypad with potentiometer)	1	★
F0-12	Selection of auxiliary frequency Y range	0: Relative to maximum frequency 1: Relative to main frequency X	0	☆
F0-13	Range of auxiliary frequency Y	0%~150%	100%	☆
F0-14	Frequency source selection	Unit's digit (Frequency source selection)	00	☆

Function Code	Parameter Name	Setting Range	Default	Property
		0: Main frequency source X 1: X and Y operation (operation relationship determined by ten's digit) 2: Switchover between X and Y 3: Switchover between X Ten's digit (X and Y operation relationship) 0: X+Y 1: X-Y 2: Maximum(X, Y) 3: Minimum(X, Y)		
F0-15	Frequency offset of auxiliary frequency source for X and Y operation	0.00 Hz ~ maximum frequency (F0-03)	0.00 Hz	☆
F0-16	Binding command source to frequency source	Unit's digit (Binding operation panel command to frequency) 0: No binding 1: Frequency source by digital setting 2: AI1 3: AI2 4: AI3 5: Pulse setting (HDI) 6: Multi-step speed 7: Simple PLC 8: PID 9: Communication setting Ten's digit (Binding terminal command to frequency source) 0~9, same as unit's digit Hundred's digit (Binding communication command to frequency source) 0~9, same as unit's digit Thousand's digit (Binding automatic running command to frequency source) 0~9, same as unit's digit	0000	☆
F0-17	Record of digital setting frequency of power failure	0: Not record 1: Record	1	☆

Function Code	Parameter Name	Setting Range	Default	Property
F0-18	Acceleration/ Deceleration mode	0: Linear acceleration/deceleration 1: S-curve acceleration/deceleration A 2: S-curve acceleration/deceleration B	0	☆
F0-19	Acceleration/Deceleration time unit	0:1s 1: 0.1s 2: 0.01s	1	☆
F0-20	Acceleration time 1	0.01s~65000s	Model dependent	☆
F0-21	Deceleration time 1	0.01s~65000s	Model dependent	☆
F0-22	Acceleration time 2	0.01s~65000s	Model dependent	☆
F0-23	Deceleration time 2	0.01s~65000s	Model dependent	☆
F0-24	Acceleration time 3	0.01s~65000s	Model dependent	☆
F0-25	Deceleration time 3	0.01s~65000s	Model dependent	☆
F0-26	Acceleration time 4	0.01s~65000s	Model dependent	☆
F0-27	Deceleration time 4	0.01s~65000s	Model dependent	☆
F0-28	Time proportion of S-curve start segment	0.0% ~50%	30.0%	☆
F0-29	Time proportion of S-curve end segment	0.0% ~50%	30.0%	☆
F0-30	Frequency switchover point between acceleration time 1 and acceleration time 2	0.00Hz ~ maximum frequency	0.00 Hz	☆
F0-31	Frequency switchover point between deceleration time 1 and deceleration time 2	0.00Hz ~ maximum frequency	0.00 Hz	☆
F0-32	Acceleration/Deceleration time base frequency	0: Maximum frequency (F0-03) 1: Set frequency 2: 100 Hz	0	☆
Group F1: Start/Stop Control Parameters				

Function Code	Parameter Name	Setting Range	Default	Property
F1-00	Start mode	0: Direct start 1: Rotational speed tracking restart 2: Pre-excited start (asynchronous motor)	0	★
F1-01	Rotational speed tracking mode	0: From frequency at stop 1: From zero speed 2: From maximum frequency	0	★
F1-02	Rotational speed tracking speed	1~100	20	★
F1-03	Startup frequency	0.00~10.00 Hz	0.00 Hz	★
F1-04	Startup frequency holding time	0.0s~100.0s	0.0s	★
F1-05	Startup DC braking current/Pre-excited current	0%~100%	0%	★
F1-06	Startup DC braking time/Pre-excited time	0.0s~100.0s	0.0s	★
F1-07	Stop mode	0: Decelerate to stop 1: Free stop	0	★
F1-08	Initial frequency of stop DC braking	0.00 Hz ~ maximum frequency	0.00 Hz	☆
F1-09	Waiting time of stop DC braking	0.0s~100.0s	0.0s	★
F1-10	Stop DC braking current	0%~100%	0%	★
F1-11	Stop DC braking time	0.0s~100.0s	0.0s	★
F1-12	Reverse running	0: Enabled 1: Disabled	0	☆
F1-13	Forward/Reverse rotation dead-zone time	0.0s~3000.0s	0.0s	☆
F1-14	Rotation direction	0: Same direction 1: Reverse direction	0	☆
F1-15	Running mode when set frequency lower than frequency lower limit	0: Run at frequency lower limit 1: Stop 2: Run at zero speed	0	☆
F1-16	Terminal JOG priority	0: Disabled 1: Enabled	0	☆
Group F2: Input Terminals				

Function Code	Parameter Name	Setting Range	Default	Property
F2-00	DI1 function selection	0: No function 1: Forward RUN (FWD) or running command 2: Reverse RUN (REV) or the direction of FED/REV 3: Three-line control 4: Forward JOG (FJOG) 5: Reverse JOG (RJOG) 6: Multi-function terminal 1 7: Multi-function terminal 2 8: Multi-function terminal 3 9: Multi-function terminal 4 10: Terminal UP 11: Terminal DOWN 12: UP and DOWN setting clear (terminal, operation panel) 13: Terminal 1 for acceleration/deceleration time selection 14: Terminal 2 for acceleration/deceleration time selection 15: Frequency source switchover 16: Switchover between main frequency source X and preset frequency 17: Switchover between auxiliary frequency source Y and preset frequency 18: Terminal 1 for running command source switchover 19: Terminal 2 for control command source switchover 20: Speed control/torque control switchover 21: Torque control prohibited 22: PID pause 23: PID integral pause 24: Reverse PID action direction 25: PID parameter switchover 26: PLC status reset 27: Swing pause 28: Counter input 29: Counter reset 30: Length count input	1	★
F2-01	DI2 function selection		2	★
F2-02	DI3 function selection		6	★
F2-03	DI4 function selection		7	★
F2-04	HDI(DI5) function selection		32	★
F2-05	DI6function selection (Extended)		00	★
F2-06	DI7 function selection (Extended)		00	★

Function Code	Parameter Name	Setting Range	Default	Property
F2-07	DI8 function selection (Extended)	31: Length reset 32: Pulse input (enabled only for HDI) 33: Frequency modification enabled 34: Acceleration/deceleration prohibited 35: Reserved 36: Reserved 37: Fault reset (RESET) 38: Normally open (NO) input of external fault 39: Normally closed (NC) input of external fault 40: User-defined fault 1 41: User-defined fault 2 42: RUN pause 43: Free stop 44: Emergency stop 45: External STOP terminal 1 46: External STOP terminal 2 47: Immediate DC braking 48: Deceleration DC braking 49: Clear the current running	00	★
F2-08	DI9 function selection (Extended)		00	★
F2-09	DI10 function selection (Extended)		00	★
F2-10	DI filter time	0.000s~1.000s	0.010s	☆
F2-11	Terminal command mode	0: Two-line mode 1 1: Two-line mode 2 2: Three-line mode 1 3: Three-line mode 2	0	★
F2-12	Terminal UP/DOWN ratio	0.001Hz/s~65.535 Hz/s	1.000Hz/s	☆
F2-13	DI1 ON delay time	0.0s~3000.0s	0.0s	☆
F2-14	DI1 OFF delay time	0.0s~3000.0s	0.0s	☆
F2-15	DI2 ON delay time	0.0s~3000.0s	0.0s	☆
F2-16	DI2 OFF delay time	0.0s~3000.0s	0.0s	☆
F2-17	DI3 ON delay time	0.0s~3000.0s	0.0s	☆
F2-18	DI3 OFF delay time	0.0s~3000.0s	0.0s	☆
F2-19	DI valid selection 1	Unit's digit (DI1 valid mode)	00000	★
		0: Low level valid 1: High level valid		
		Ten's digit (DI2 valid mode)		
		0, 1 (same as DI1)		

Function Code	Parameter Name	Setting Range	Default	Property
F2-20	DI valid selection 2	Hundred's digit (DI3 valid mode)	00000	★
		0, 1 (same as DI1)		
		Thousand's digit (DI4 valid mode)		
		0, 1 (same as DI1)		
		Ten thousand's digit (HDI valid mode)		
		0, 1 (same as DI1)		
		Unit's digit (DI6 valid mode)		
		0, 1 (same as DI1)		
		Ten's digit (DI7 valid mode)		
		0, 1 (same as DI1)		
Group F3: Pulse/Analog input terminals				
F3-00	AI curve 1 minimum input	0.00 V~F3-02	0.01 V	★
F3-01	Corresponding setting of AI curve 1 minimum input	-100.0%~100.0%	0.0%	★
F3-02	AI curve 1 maximum input	F3-00~10.00V	10.00V	★
F3-03	Corresponding setting of AI curve 1 maximum input	-100.0%~100.0%	100.0%	★
F3-04	AI curve 2 minimum input	0.00 V~F3-06	0.01 V	★
F3-05	Corresponding setting of AI curve 2 minimum input	-100.0%~100.0%	0.0%	★
F3-06	AI curve 2 maximum input	F3-04~10.00V	10.00V	★

Function Code	Parameter Name	Setting Range	Default	Property
F3-07	Corresponding setting of AI curve 2 maximum input	-100.0%~100.0%	100.0%	☆
F3-08	AI curve 3 minimum input	0.00 V~F3-10	0.01 V	☆
F3-09	Corresponding setting of AI curve 3 minimum input	-100.0%~100.0%	0.0%	☆
F3-10	AI curve 3 maximum input	F3-08~10.00V	10.00V	☆
F3-11	Corresponding setting of AI curve 3 maximum input	-100.0%~100.0%	100.0%	☆
F3-12	AI curve 4 minimum input	0.00 V~F3-14	0.01 V	☆
F3-13	Corresponding setting of AI curve 4 minimum input	-100.0%~100.0%	0.0%	☆
F3-14	AI curve 4 first point input	F3-12~F3-16	3.33V	☆
F3-15	Corresponding setting of AI4first point input	-100.0%~100.0%	33.3%	☆
F3-16	AI curve 4 second point input	F3-14~F3-18	6.67V	☆
F3-17	Corresponding setting of AI4second point input	-100.0%~100.0%	6.67%	☆
F3-18	AI4 maximum input	F3-16~10.00V	10.00V	☆
F3-19	Corresponding setting of AI4 maximum input	-100.0%~100.0%	100.0%	☆
F3-20	AI curve 5 minimum input	0.00 V~F3-22	0.01 V	☆
F3-21	Corresponding setting of AI curve 5 minimum input	-100.0%~100.0%	0.0%	☆
F3-22	AI curve 5first point input	F3-20~F3-24	3.33V	☆
F3-23	Corresponding setting of AI5first point input	-100.0%~100.0%	33.3%	☆
F3-24	AI curve 5second point input	F3-22~F3-26	6.67V	☆
F3-25	Corresponding setting of AI5second point input	-100.0%~100.0%	6.67%	☆
F3-26	AI5 maximum input	F3-24~10.00V	10.00V	☆

Function Code	Parameter Name	Setting Range	Default	Property
F3-27	Corresponding setting of AI5 maximum input	-100.0%~100.0%	100.0%	☆
F3-28	Pulse minimum input	0.00 kHz~F3-30	0.00 kHz	☆
F3-29	Corresponding setting of pulse minimum input	-100.00%~100.0%	0.0%	☆
F3-30	Pulse maximum input	F3-28~100.00 kHz	50.00kHz	☆
F3-31	Corresponding setting of pulse maximum input	-100.00%~100.0%	100.0%	☆
F3-32	AI curve setting	Unit's digit (AI curve 1 selection)	321	☆
		1: curve 1; 2: curve 2; 3: curve 3; 4: curve 4; 5: curve 5		
		Ten's digit(AI curve 2 selection)		
		1-5(same as AI curve 1)		
		Hundred's digit(AI curve 3 selection)		
		1-5(same as AI curve 1)		
		Unit's digit(AI curve 1 lower limit selection)		
F3-33	AI curve lower than minimum input	0: minimum input; 1: 0.0%	000	☆
		Ten's digit(AI curve 2 lower limit selection)		
		0, 1(same as AI1)		
		Hundred's digit(AI curve 3 lower limit selection)		
		0, 1(same as AI1)		
		Unit's digit(AI curve 1 lower limit selection)		
F3-34	AI1 filter time	0.00s ~ 10.00s	0.10s	☆
F3-35	AI2 filter time	0.00s ~ 10.00s	0.10s	☆
F3-36	AI3 filter time	0.00s ~ 10.00s	0.10s	☆
F3-37	Pulse filter time	0.00s ~ 10.00s	0.10s	☆
F3-38	AI1 input voltage lower limit	0.00 V ~ F3-39	0.00 V	☆
F3-39	AI1 input voltage upper limit	F3-38 ~ 10.00 V	10.00 V	☆
F3-40	Jump point of AI1 input corresponding setting	-100.0%~100.0%	0.0%	☆

Function Code	Parameter Name	Setting Range	Default	Property
F3-41	Jump amplitude of AI1 input corresponding setting	0.0%~100.0%	0.0%	☆
F3-42	Jump point of AI2 input corresponding setting	-100.0%~100.0%	0.0%	☆
F3-43	Jump amplitude of AI2 input corresponding setting	0.0%~100.0%	0.0%	☆
F3-44	Jump point of AI3 input corresponding setting	-100.0%~100.0%	0.0%	☆
F3-45	Jump amplitude of AI3 input corresponding setting	0.0%~100.0%	0.0%	☆
F3-46	Minimum input value of AI-KB	0.0V ~ 10.0V	0.50V	☆
F3-47	Maximum input value of AI-KB	0.50V ~10.0V	9.5V	☆
F3-48	AI-KB filter time	0.00s~10.00s	1.00s	☆

Group F4: Output Terminals

F4-00	FM terminal output mode	0: Pulse signal output (FMP) 1: Switch signal output (FMR)	1	☆
F4-01	FMR functionselection (open-collector output terminal)	0: No output 1: Ready for RUN 2: Frequency inverter running 3: Fault output (stop) 4: Fault output(free stop fault, no output at under-voltage) 5: Frequency limited 6: Torque limited 7: Frequency upper limit reached 8: Frequency lower limit reached 1(no output at stop) 9: Frequency lower limit reached 2(having output at stop)	0	☆
F4-02	Relay 1 functionselection (TA-TB-TC)	10: Reverse running 11: Zero-speed running (no	3	☆

Function Code	Parameter Name	Setting Range	Default	Property
F4-03	Relay 2 functionselection (Extension card)	output at stop) 12: Zero-speed running 2 (having output at stop) 13: Set count value reached 14: Designated count value reached 15: Length reached 16: PLC cycle complete 17: Frequency level detection FDT1 output 18: Frequency level detection FDT2 output 19: Frequency reached 20: Frequency 1 reached 21: Frequency 2 reached 22: Current 1 reached 23: Current 2 reached 24: Module temperature reached 25: Timing reached 26: Zero current state 27: Output current limit exceeded	0	☆
F4-04	DO1 function selection (open-collector output terminal)	28: Lower voltage state output 29: Frequency inverter overload pre-warning 30: Motor overheat warning 31: Motor overload pre-warning 32: Off load 33: AI1 larger than AI2 34: AI1 input limit exceeded 35: Alarm output 36: This time running time reached 37: Accumulative power-on time reached 38: Accumulative running time reached	1	☆
F4-05	DO2 function(Extension card)		0	☆
F4-06	FMR ON delay time	0.0s~3000.0s	0.0s	☆
F4-07	FMR OFF delay time	0.0s~3000.0s	0.0s	☆
F4-08	Relay 1 ON delay time	0.0s~3000.0s	0.0s	☆
F4-09	Relay 1 OFF delay time	0.0s~3000.0s	0.0s	☆
F4-10	Relay 2 ON delay time	0.0s~3000.0s	0.0s	☆
F4-11	Relay 2 OFF delay time	0.0s~3000.0s	0.0s	☆

Function Code	Parameter Name	Setting Range	Default	Property
F4-12	DO1 ON delay time	0.0s~3000.0s	0.0s	☆
F4-13	DO1 OFF delay time	0.0s~3000.0s	0.0s	☆
F4-14	DO2 ON delay time	0.0s~3000.0s	0.0s	☆
F4-15	DO2 OFF delay time	0.0s~3000.0s	0.0s	☆
F4-16	DO valid mode selection	Unit's digit (FMR valid mode)	00000	☆
		0: Positive logic 1: Negative logic		
		Ten's digit (Relay 1 valid mode)		
		0, 1 (same as FMR)		
		Hundred's digit (Relay 2 valid mode)		
		0, 1 (same as FMR)		
		Thousand's digit (DO1 valid mode)		
		0, 1 (same as FMR)		
		Ten thousand's digit (DO2 valid mode)		
		0, 1 (same as FMR)		
F4-17	Frequency detection value 1(FDT1 level)	0.00 Hz ~ maximum frequency	50.00 Hz	☆
F4-18	Frequency detection hysteresis(FDT 1)	0.0%~100.0% (FDT1 level)	5.0%	☆
F4-19	Frequency detection value 2 (FDT2 level)	0.00 ~ maximum frequency	50.00 Hz	☆
F4-20	Frequency detection hysteresis 2 (FDT 2)	0.0%~100.0% (FDT2 level)	5.0%	☆
F4-21	Detection range of frequency reached	0.00~100% (maximum frequency)	3.0%	☆
F4-22	Any frequency reaching detection value 1	0.00 Hz ~ maximum frequency	50.00 Hz	☆
F4-23	Any frequency reaching detection amplitude 1	0.0%~100.0% (maximum frequency)	3.0%	☆
F4-24	Any frequency reaching detection value 2	0.00 Hz ~ maximum frequency	50.00 Hz	☆
F4-25	Any frequency reaching detection amplitude 2	0.0%~100.0% (maximum frequency)	3.0%	☆
F4-26	Zero current detection level	0.0%~100.0% (ratedmotor current)	5.0%	☆
F4-27	Zero current detection delay time	0.00s~600.00s	0.10s	☆

Function Code	Parameter Name	Setting Range	Default	Property
F4-28	Output over currentthreshold	0.0% (no detection) 0.1%~300.0% (rated motor current)	200.0%	☆
F4-29	Overcurrent detection delay time	0.00s~600.00s	0.10s	☆
F4-30	Any current reaching 1	0.0%~100.0% (rated motor current)	100.0%	☆
F4-31	Amplitude of any current reaching 1	0.0%~100.0% (rated motor current)	3.0%	☆
F4-32	Any current reaching 2	0.0%~100.0% (rated motor current)	100.0%	☆
F4-33	Amplitude of any current reaching 2	0.0%~100.0% (rated motor current)	3.0%	☆
F4-34	IGBT Module temperature threshold	25°C ~100°C	75°C	☆
Group F5: Pulse/analog output terminals				
F5-00	FMP function selection(Pulse output terminal)	0: Running frequency corresponding to 0~Max. frequency 1: Set frequency corresponding to 0~Max. frequency 2: Output current corresponding to 0~Doubled motor rated current 3: Output torque (absolute value) corresponding to 0~double rated torque 4: Output power corresponding to 0~Doubled motor rated power 5: Output voltage corresponding to 0~1.2 times DC bus voltage 6: Motor rotational speed corresponding to 0~Max. frequency 7: Output current corresponding to 0~1000A 8: Output voltage corresponding to 0~1000V 9: Output torque corresponding to (-200%~200%) motor rated torque 10: Pulse input corresponding to 0Hz~100kHz	0	☆
F5-01	AO1 function selection	0	☆	

Function Code	Parameter Name	Setting Range	Default	Property
F5-02	AO2 function selection	11: AI1 corresponding to 0~10V 12: AI2 corresponding to 0~10V 13: AI3 corresponding to 0~10V 14: Length corresponding to 0~Length setting value 15: Count value corresponding to 0~Count setting value 16: Communication setting corresponding to 0~32767	1	☆
F5-03	Maximum FMP output frequency	0.01 kHz ~100.00 kHz	50.00 kHz	☆
F5-04	AO1 zero offset coefficient	-100.0%~100.0%	0.0%	☆
F5-05	AO1 gain	-10.00~10.00	1.00	☆
F5-06	AO2 zero offset coefficient	-100.0%~100.0%	0.0%	☆
F5-07	AO2 gain	-10.00~10.00	1.00	☆
Group F6: Auxiliary Functions				
F6-00	JOG running frequency	0.00 Hz ~ maximum frequency	6.00 Hz	☆
F6-01	JOG acceleration time	0.01s~6500.0s	10.0s	☆
F6-02	JOG deceleration time	0.01s~6500.0s	10.0s	☆
F6-03	Accumulative power-on time reach threshold	0h~65000 h	0 h	☆
F6-04	Accumulative running time reach threshold	0h~65000 h	0 h	☆
F6-05	Action after running time reached	0: Continue to run 1: Stop	0	☆
F6-06	Dormant frequency	0.00Hz~Wakeup frequency (F6-08)	0.00 Hz	★
F6-07	Dormant delay time	0.0s~6000.0s	0.0s	☆
F6-08	Wakeup frequency	Dormant frequency (F6-06) ~ Maximum frequency(F0-03)	0.00 Hz	★
F6-09	Wakeup delay time	0.0s~6000.0s	0.0s	☆
F6-10	Timing function	0: Disabled 1: Enabled	0	☆

Function Code	Parameter Name	Setting Range	Default	Property
F6-11	Timing duration source	0: F6-12 1: AI1 2: AI2 3: AI3 (100% of analog input corresponds to the value of F6-12)	0	☆
F6-12	Timing duration	0.0min~6500.0 min	0.0min	☆
F6-13	This-time running time reachthreshold	0.0min~6500.0 min	0.0 min	☆
F6-14	Cooling fan control	0: Fan working during running 1: Fan working during power on	0	☆
F6-15	Startup protection	0: No 1: Yes	0	☆
F6-16	Jump frequency 1	0.00 Hz ~ maximum frequency	0.00 Hz	☆
F6-17	Jump frequency 2	0.00 Hz ~ maximum frequency	0.00 Hz	☆
F6-18	Frequency jump amplitude	0.00 Hz ~ maximum frequency	0.00 Hz	☆
F6-19	Jump frequency during acceleration /deceleration	0: Disabled 1: Enabled	0	☆
F6-20	Droop control	0.01~10.00 Hz	0.00 Hz	☆
Group F7: Display Setting				
F7-00	LED display running parameters 1	Unit's digit (set frequency, unit: Hz)	11101	☆
		0: Display 1: No display		
		Ten's digit (running frequency, unit :Hz)		
		0, 1 (same as unit's digit)		
		Hundred's digit (bus voltage, unit: V)		
		0, 1 (same as unit's digit)		
		Thousand's digit (output voltage, unit: V)		
		0, 1 (same as unit's digit)		
		Ten thousand's digit (output current, unit A)		
		0, 1 (same as unit's digit)		
F7-01	LED display running parameters 2	Unit's digit (output power, unit: kW)	00000	☆

Function Code	Parameter Name	Setting Range	Default	Property
		0: Display 1: No display Ten's digit (output torque, unit :%) 0, 1 (same as unit's digit) Hundred's digit (DI input status) 0, 1 (same as unit's digit) Thousand's digit (DO output status) 0, 1 (same as unit's digit) Ten thousand's digit (AI1 voltage, unit V) 0, 1 (same as unit's digit)		
F7-02	LED display running parameters 3	Unit's digit (AI2, unit: V) 0: Display 1: No display Ten's digit (AI3, unit :V) 0, 1 (same as unit's digit) Hundred's digit (count value) 0, 1 (same as unit's digit) Thousand's digit (length value) 0, 1 (same as unit's digit) Ten thousand's digit (load speed display) 0, 1 (same as unit's digit)	00000	☆
F7-03	LED display running parameters 4	Unit's digit (PID setting) 0: Display 1: No display Ten's digit (PID feedback) 0, 1 (same as unit's digit) Hundred's digit (PLC stage) 0, 1 (same as unit's digit) Thousand's digit (pulse setting frequency, unit: kHz) 0, 1 (same as unit's digit)	00000	☆

Function Code	Parameter Name	Setting Range	Default	Property
		Ten thousand's digit (running frequency 2, unit: Hz) 0, 1 (same as unit's digit)		
F7-04	LED display running parameters 5	Unit's digit (remaining running time) 0: Display 1: No display	00000	☆
		Ten's digit (AI1 voltage before correction) 0, 1 (same as unit's digit)		
		Hundred's digit (AI2 voltage before correction) 0, 1 (same as unit's digit)		
		Thousand's digit (AI3 voltage before correction) 0, 1 (same as unit's digit)		
		Ten thousand's digit (Linear speed) 0, 1 (same as unit's digit)		
		Unit's digit (Current power-on time, unit: Hour) 0: Display 1: No display		
		Ten's digit (Current running time, unit: Minute) 0, 1 (same as unit's digit)		
		Hundred's digit (Heatsink temperature display, unit: °C) 0, 1 (same as unit's digit)		
		Thousand's digit (Communication setting value) 0, 1 (same as unit's digit)		
		Ten thousand's digit (Encoder feedback speed, unit: Hz) 0, 1 (same as unit's digit)		
F7-06	LED display running parameters 7	Unit's digit (Main frequency X display, unit: Hz)	00	☆

Function Code	Parameter Name	Setting Range	Default	Property
		0: Display 1: No display		
F7-07	LED display stop parameters 1	Ten's digit (Auxiliary frequency Y display, unit: Hz)	00011	☆
		0, 1 (same as unit's digit)		
		Hundred's digit, reserved		
		Thousand's digit, reserved		
		Ten thousand's digit, reserved		
		Unit's digit (set frequency, unit: Hz)		
		0: Display 1: No display		
		Ten's digit (bus voltage, unit :V)		
		0, 1 (same as unit's digit)		
		Hundred's digit (DI input status)		
F7-08	LED display stop parameters 2	0, 1 (same as unit's digit)	00000	☆
		Thousand's digit (DO output status)		
		0, 1 (same as unit's digit)		
		Ten thousand's digit (AI1 voltage, unit V)		
		0, 1 (same as unit's digit)		
		Unit's digit (AI2 voltage, unit V)		
		0: Display 1: No display		
		Ten's digit (AI3 voltage, unit V)		
		0, 1 (same as unit's digit)		
		Hundred's digit (count value)		

Function Code	Parameter Name	Setting Range	Default	Property
		0, 1 (same as unit's digit)		
F7-09	LED display stop parameters 3	Unit's digit (load speed)	00000	☆
		0: Display 1: No display		
		Ten's digit (PID setting)		
		0, 1 (same as unit's digit)		
		Hundred's digit (pulse setting frequency, unit: kHz)		
		0, 1 (same as unit's digit)		
		Thousand's digit (heatsink temperature display, unit: °C)		
		0, 1 (same as unit's digit)		
		Ten thousand's digit, reserved		
F7-10	Load speed display coefficient	0.0001~6.5000	1.0000	☆
F7-11	Number of decimal places for load speed display	0: 0 decimal place 1: 1 decimal place 2: 2 decimal places 3: 3 decimal places	1	☆
F7-14	Heatsink temperature	0.0°C ~100.0°C	--	●
F7-15	Accumulative power-on time	0 h ~65535 h	--	●
F7-16	Accumulative running time	0~65535 h	--	●
F7-17	Accumulative power consumption	0 kWh~65535 kWh	--	●
F7-18	STOP/RESET key function	0: STOP/RESET key enabled only in operation panel control 1: STOP/RESET key enabled in any operation mode	0	☆
F7-19	Restore parameter default settings	0: No operation 1: Restore default settings except motor parameters and accumulation record. 2: Restore default settings for all parameters 3: Reserved 4: Clear records	0	☆
F7-22	Parameter group display selection 1	Unit's digit (Group F1)	11111	☆
		0: Display 1: No display		

Function Code	Parameter Name	Setting Range	Default	Property
		Ten's digit (Group F2) 0, 1 (same as unit's digit) Hundred's digit (Group F3) 0, 1 (same as unit's digit) Thousand's digit (Group F4) 0, 1 (same as unit's digit) Ten thousand's digit (Group F5) 0, 1 (same as unit's digit)		
		Unit's digit (Group F6) 0: Display 1: No display Ten's digit (Group F8) 0, 1 (same as unit's digit) Hundred's digit (Group F9) 0, 1 (same as unit's digit) Thousand's digit (Group FA) 0, 1 (same as unit's digit) Ten thousand's digit (Group Fb) 0, 1 (same as unit's digit)		
F7-23	Parameter group display selection2	Unit's digit (Group FC) 0: Display 1: No display Ten's digit (Group Fd) 0, 1 (same as unit's digit) Hundred's digit (Group d0) 0, 1 (same as unit's digit) Thousand's digit (Group d1) 0, 1 (same as unit's digit) Ten thousand's digit (Group d2) 0, 1 (same as unit's digit)	11111	☆
F7-24	Parameter group display selection3	Unit's digit (Group d3)	11111	☆
F7-25	Parameter group display	Unit's digit (Group d3)	11	☆

Function Code	Parameter Name	Setting Range	Default	Property
	selection4	0: Display 1: No display Ten's digit (Group d4) 0, 1 (same as unit's digit) Hundred's digit, reserved Thousand's digit, reserved Ten thousand's digit, reserved		
F7-29	User password	0~65535	00000	☆
F7-30	Parameter modification property	0: Modifiable 1~65535: Not modifiable	00000	☆
F7-31	MF.K Key function selection	0: MF.K key disabled 1: Switchover between operation panel control and remote command control (terminal or communication) 2: Switchover between forward rotation and reverse rotation 3: Forward JOG 4: Reverse JOG	3	★
F7-33	Product number	-	Factory default	•
F7-34	Function software version	-	Factory default	•
F7-35	Performance software version	-	Factory default	•
F7-36	Temporary function software version	-	Factory default	•
F7-37	Temporary performance software version	-	Factory default	•
Group F8: Fault and Protection				
F8-00	G/P type display	0: P type(variable torque load e.g. fan and pump) 1: G type(constant torque load)	1	☆
F8-01	Motor overload protection selection	0: Disabled 1: Enabled	0	☆
F8-02	Motor overload protection gain	0.20~10.00	1.00	☆
F8-03	Motor overload warning coefficient	50%~100%	80%	☆

Function Code	Parameter Name	Setting Range	Default	Property
F8-04	Overvoltage stall gain	0% (no stall overvoltage)~100%	0	☆
F8-05	Overvoltage stall protective voltage	120%~150%	130%	☆
F8-06	Over current stall gain	0~100	20	☆
F8-07	Over current stall protective current	100%~200%	150%	☆
F8-08	Overvoltage threshold	200.0V~2500.0 V	810.0V	☆
F8-09	Undervoltage threshold	50.0%~150.0%	100.0%	☆
F8-10	Braking use ratio	0%~100%	100%	☆
F8-11	Short-circuit to ground after power- on	0: Disabled 1: Enabled	1	☆
F8-12	Input phase loss protection selection	0: Disabled 1: Enabled	1	☆
F8-13	Output phase loss protection selection	0: Disabled 1: Enabled	0	☆
F8-14	Off load protection	0: Disabled 1: Enabled	0	☆
F8-15	Off load detection level	0.0%~100.0% (ratedmotor current)	1.0%	☆
F8-16	Off load detection time	0.0s~60.0s	1.0s	☆
F8-17	Rapid current limit	0: Disabled 1: Enabled	1	☆
F8-18	Over-speed detection value	0.0%~50.0% (maximum frequency)	20.0%	☆
F8-19	Over-speed detection time	0.0s~60.0s	1.0s	☆
F8-20	Detection value of too large speed deviation	0.0%~50.0% (maximum frequency)	20.0%	☆
F8-21	Detection time of too large speed deviation	0.0s~60.0s	5.0s	☆
F8-22	Action selection at instantaneous power failure	0: Invalid 1: Decelerate 2: Decelerate to stop	0	☆
F8-23	Voltage rally judging time at instantaneous power failure	0.00s~100.00s	0.00s	☆
F8-24	Judging voltage of instantaneous power failure	60.0%~100.0% (standard bus voltage)	80.0%	☆
F8-25	Judging voltage of instantaneous power failure restoring	60.0%~100.0% (standard bus voltage)	90.0%	☆

Function Code	Parameter Name	Setting Range	Default	Property
F8-26	Fault auto reset times	0~99	00	☆
F8-27	Relay action selection during fault auto reset	0: Not act 1: Act	0	☆
F8-28	Interval time of fault auto reset	0.1s~100.0s	1.0s	☆
F8-29	Type of motor temperature sensor	0: No temperature sensor 1: PT100 2: PT1000	0	☆
F8-30	Motor overheat protection threshold	0°C~200°C	120°C	☆
F8-31	Motor overheat warning threshold	0°C~200°C	100°C	☆
F8-32	Fault protection action selection 1	Unit's digit (Motor overload, Err11)	00000	☆
		0: Free stop 1: Stop according to the stop mode 2: Continue to run		
		Ten's digit (Power input phase loss, Err12)		
		Same as unit's digit		
		Hundred's digit (Power output phase loss, Err13)		
		Same as unit's digit		
		Thousand's digit (External equipment fault, Err15)		
		Same as unit's digit		
		Ten thousand's digit (Communication fault, Err16)		
		Same as unit's digit		
F8-33	Fault protection action selection 2	Unit's digit (Encoder /PG card fault, Err20)	00000	☆
		0: Free stop 1: Switch to V/F mode, stop according to stopping mode 2: Switch to V/F control, continue to run		
		Ten's digit (EEPROM read-write fault, Err21)		
		0: Free stop 1: Stop according to the stop mode		
		Hundred's digit: reserved		

Function Code	Parameter Name	Setting Range	Default	Property
		Thousand's digit (Motor overheat, Err25) Same as unit's digit in F8-32 Ten thousand's digit (Accumulative running time reached) Same as unit's digit in F8-32		
F8-34	Fault protection action selection 3	Unit's digit (User-defined fault 1, Err27) Same as unit's digit in F8-32 Ten's digit (User-defined fault 2, Err28) Same as unit's digit in F8-32 Hundred's digit (Accumulative power-on time reached, Err29) Same as unit's digit in F8-32 Thousand's digit (Off load, Err30) 0: Free stop 1: Stop according to the stop mode 2: Continue to run at 7% of rated motor frequency and restore to the set frequency if the load recovers Ten thousand's digit (PID feedback lost during running, Err31) Same as unit's digit in F8-32	00000	☆
F8-35	Fault protection action selection 4	Unit's digit (Too large speed deviation, Err42) Same as unit's digit in F8-32 Ten's digit (Motor over-speed, Err43) Same as unit's digit in F8-32 Hundred's digit (Initial position fault, Err51) Same as unit's digit in F8-32 Ten thousand's digit, reserved	00	☆

Function Code	Parameter Name	Setting Range	Default	Property
F8-36	Frequency selection for continuing to run of fault	0: At present running frequency 1: At setting frequency 2: Frequency upper limit 3: Frequency lower limit 4: Backup frequency of abnormality(F8-37)	0	☆
F8-37	Backup frequency of abnormality	0.0%~100.0% (maximum frequency)	1.0%	☆
F8-38	1st fault type	—	—	●
F8-39	2nd fault type	—	—	●
F8-40	3rd (latest) fault type	—	—	●
F8-41	Frequency of latest fault	—	—	●
F8-42	Current of latest fault	—	—	●
F8-43	DC Bus voltage of latest fault	—	—	●
F8-44	DI terminals status of latest fault	—	—	●
F8-45	DO terminals status of latest fault	—	—	●
F8-46	Frequency inverter status of latest fault	—	—	●
F8-47	Power-on time of latest fault	—	—	●
F8-48	Running time of latest fault	—	—	●
F8-49	Frequency of 2nd fault	—	—	●
F8-50	Current of 2nd fault	—	—	●
F8-51	DC Bus voltage of 2nd fault	—	—	●
F8-52	DI terminals status of 2nd fault	—	—	●
F8-53	DO terminals status of 2nd fault	—	—	●
F8-54	Frequency inverter status of 2nd fault	—	—	●
F8-55	Power-on time of 2nd fault	—	—	●
F8-56	Running time of 2nd fault	—	—	●

Function Code	Parameter Name	Setting Range	Default	Property
F8-57	Frequency of 1st fault	—	—	•
F8-58	Current of 1st fault	—	—	•
F8-59	DC Bus voltage of 1st fault	—	—	•
F8-60	DI terminals status of 1st fault	—	—	•
F8-61	DO terminals status of 1st fault	—	—	•
F8-62	Frequency inverter status of 1st fault	—	—	•
F8-63	Power-on time of 1st fault	—	—	•
F8-64	Running time of 1st fault	—	—	•
Group F9: Monitoring Parameters				
F9-00	Running frequency	—	—	•
F9-01	Set frequency	—	—	•
F9-02	DC Bus voltage	—	—	•
F9-03	Output voltage	—	—	•
F9-04	Output current	—	—	•
F9-05	Output power	—	—	•
F9-06	Output torque	—	—	•
F9-07	Fault information	—	—	•
F9-08	Present setting frequency (%)	—	—	•
F9-09	Present running frequency (%)	—	—	•
F9-10	Frequency inverter running state	—	—	•
F9-11	AI1 voltage	—	—	•
F9-12	AI2 voltage	—	—	•
F9-13	AI3 voltage	—	—	•
F9-14	AI1 voltage before correction	—	—	•
F9-15	AI2 voltage before correction	—	—	•

Function Code	Parameter Name	Setting Range	Default	Property
F9-16	AI3 voltage before correction	—	—	•
F9-17	Counter value	—	—	•
F9-18	Length value	—	—	•
F9-19	Load speed	—	—	•
F9-20	PID setting	—	—	•
F9-21	PID feedback	—	—	•
F9-22	PLC stage	—	—	•
F9-23	Current remaining time of PLC	—	—	•
F9-24	Input pulse frequency	—	—	•
F9-25	feedback speed	—	—	•
F9-26	Remaining running time	—	—	•
F9-27	Linear speed	—	—	•
F9-28	Present power-on time	—	—	•
F9-29	Present running time	—	—	•
F9-30	Communication setting value	—	—	•
F9-31	Actual feedback speed	—	—	•
F9-32	Main frequency X	—	—	•
F9-33	Auxiliary frequency Y	—	—	•
F9-34	Motor temperature	—	—	•
F9-35	Target torque	—	—	•
F9-36	Resolver position	—	—	•
F9-37	Heatsink temperature	—	—	•
F9-38	ABZ position	—	—	•
F9-39	Target voltage of V/F separation	—	—	•
F9-40	Output voltage of V/F separation	—	—	•

Function Code	Parameter Name	Setting Range	Default	Property
F9-41	DI state	—	—	●
F9-42	DO state	—	—	●
Group FA: Communication parameters				
FA-00	Communication type selection	0: Modbus protocol	0	☆
FA-01	Baud ratio	0:300BPS 1:600BPS 2:1200BPS 3:2400BPS 4:4800BPS 5:9600BPS 6:19200BPS 7:38400BPS	5	☆
FA-02	Modbus data format	0: No check, data format <8,N,2> 1: Even parity check, dataformat<8,E,1> 2: Odd Parity check, data format<8,O,1> 3: No check, data format<8,N,1> Valid for Modbus	0	☆
FA-03	Broadcast address	0~249, 0 is broadcast address	1	☆
FA-04	Modbus response delay	0ms~20ms(only valid for Modbus)	2ms	☆
FA-05	Communication interface timeout	0.0s(inactive), 0.1s~60.0s	0.0s	☆
FA-06	Communication protocol selection	0: Non-standard Modbus protocol 1: Standard Modbus protocol	1	☆
FA-07	Communication reading current resolution	0: 0.01A 1: 0.1A	0	☆
Group Fb: Process Control PID Function				
Fb-00	PID setting source	0: Fb-01 1: AI1 2: AI2 3: AI3 4: Pulse setting (HDI) 5: Communication setting 6: Multi-function	0	☆
Fb-01	PID digital setting	0.0%~100.0%	0.0%	☆

Function Code	Parameter Name	Setting Range	Default	Property
Fb-02	PID setting change time	0.00s~650.00s	1.00s	☆
Fb-03	PID feedback source	0: AI1 1: AI2 2: AI3 3: Pulse setting (HDI) 4: AI1 – AI2 5: AI1 + AI2 6: MAX (AI1 , AI2) 7: MIN (AI1 , AI2) 8: Communication setting	0	☆
Fb-04	PID action direction	0: Forward action 1: Reverse action	0	☆
Fb-05	PID setting feedback range	0~65535	1000	☆
Fb-06	Proportional gain Kp1	0.00~10.00	2.00	☆
Fb-07	Integral time Ti1	0.01s~10.00s	0.50s	☆
Fb-08	Differential time Td1	0.000s~10.000s	0.000s	☆
Fb-09	Proportional gain Kp2	0.01~10.00	2.00	☆
Fb-10	Integral time Ti2	0.01s~10.00s	0.50s	☆
Fb-11	Differential time Td2	0.00~10.00s	0.00s	☆
Fb-12	PID parameter switchover condition	0: No switchover 1: Switchover via DI	0	☆
Fb-13	PID parameter switchover deviation 1	0.0% ~Fb-14	20.0%	☆
Fb-14	PID parameter switchover deviation 2	Fb-13 ~ 100.0%	80.0%	☆
Fb-15	PID integral property	Unit's digit (Integral separation) 0: Invalid 1: Valid Ten's digit (Whether to stop integral operation when the output reaches the limit) 0: Continue integral operation 1: Stop integral operation	00	☆
Fb-16	PID initial value	0.0%~100.0%	0.0%	☆
Fb-17	PID initial value holding time	0.00s~650.00s	0.00s	☆

Function Code	Parameter Name	Setting Range	Default	Property
Fb-18	Frequency upper limit of PID reverse rotation	0.00Hz ~ maximum frequency	0.00 Hz	☆
Fb-19	PID deviation limit	0.0%~100.0%	0.0%	☆
Fb-20	PID differential amplitude limit	0.00%~100.00%	0.10%	☆
Fb-21	Maximum positive deviation between two PID outputs	0.00%~100.00%	1.00%	☆
Fb-22	Maximum negative deviation between two PID outputs	0.00%~100.00%	1.00%	☆
Fb-23	PID feedback filter time	0.00s~60.00s	0.00s	☆
Fb-24	PID output filter time	0.00s~60.00s	0.00s	☆
Fb-25	Detection value of PID feedback loss	0.0%: Not judging feedback loss 0.1%~100.0%	0.0%	☆
Fb-26	Detection time of PID feedback loss	0.0s~20.0s	0.0s	☆
Fb-27	PID operation at stop	0: No PID operation at stop 1: PID operation at stop	1	☆

Group FC: Multi-reference and simple PLC

FC-00	Reference 0	-100.0% ~ 100.0%	0.0%	☆
FC-01	Reference 1	-100.0% ~ 100.0%	0.0%	☆
FC-02	Reference 2	-100.0% ~ 100.0%	0.0%	☆
FC-03	Reference 3	-100.0% ~ 100.0%	0.0%	☆
FC-04	Reference 4	-100.0% ~ 100.0%	0.0%	☆
FC-05	Reference 5	-100.0% ~ 100.0%	0.0%	☆
FC-06	Reference 6	-100.0% ~ 100.0%	0.0%	☆
FC-07	Reference 7	-100.0% ~ 100.0%	0.0%	☆
FC-08	Reference 8	-100.0% ~ 100.0%	0.0%	☆
FC-09	Reference 9	-100.0% ~ 100.0%	0.0%	☆
FC-10	Reference 10	-100.0% ~ 100.0%	0.0%	☆
FC-11	Reference 11	-100.0% ~ 100.0%	0.0%	☆

Function Code	Parameter Name	Setting Range	Default	Property
FC -12	Reference 12	-100.0% ~ 100.0%	0.0%	☆
FC -13	Reference 13	-100.0% ~ 100.0%	0.0%	☆
FC -14	Reference 14	-100.0% ~ 100.0%	0.0%	☆
FC -15	Reference 15	-100.0% ~ 100.0%	0.0%	☆
FC-16	Multi-reference 0 source	0: Set by FC-00 1: AI1 2: AI2 3: AI3 4: Pulse setting(HDI) 5: PID 6: Set by preset frequency (F0-08), modified via terminal UP/DOWN	0	☆
FC-17	Simple PLC running mode	0: Stop after the frequency inverter runs one cycle 1: Keep final values after the frequency inverter runs one cycle 2: Repeat after the frequency inverter runs one cycle	0	☆
FC-18	Simple PLC retentive selection	Unit's digit (Retentive upon power failure)	00	☆
		0: No 1: Yes		
		Ten's digit (Retentive upon stop)		
		0: No 1: Yes		
FC-19	Running time of simple PLC segment 0	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-20	Running time of simple PLC segment 1	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-21	Running time of simple PLC segment 2	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-22	Running time of simple PLC segment 3	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-23	Running time of simple PLC segment 4	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-24	Running time of simple PLC segment 5	0.0s(h)~6553.5s(h)	0.0s (h)	☆

Function Code	Parameter Name	Setting Range	Default	Property
FC-25	Running time of simple PLC segment 6	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-26	Running time of simple PLC segment 7	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-27	Running time of simple PLC segment 8	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-28	Running time of simple PLC segment 9	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-29	Running time of simple PLC segment 10	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-30	Running time of simple PLC segment 11	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-31	Running time of simple PLC segment 12	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-32	Running time of simple PLC segment 13	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-33	Running time of simple PLC segment 14	0.0s(h)~6553.5s(h)	0.0s (h)	☆
FC-34	Running time of simple PLC segment 15	0.0s(h)~6553.5s(h)	0.0s (h)	
FC-35	Time unit of simple PLC running	0: s (second) 1: h (hour)	0	☆
FC-36	Acceleration time of simple PLC segment 0	0.01s~65000s	Model dependent	☆
FC-37	Deceleration time of simple PLC segment 0	0.01s~65000s	Model dependent	☆
FC-38	Acceleration time of simple PLC segment 1	0.01s~65000s	Model dependent	☆
FC-39	Deceleration time of simple PLC segment 1	0.01s~65000s	Model dependent	☆
FC-40	Acceleration time of simple PLC segment 2	0.01s~65000s	Model dependent	☆
FC-41	Deceleration time of simple PLC segment 2	0.01s~65000s	Model dependent	☆
FC-42	Acceleration time of simple PLC segment 3	0.01s~65000s	Model dependent	☆
FC-43	Deceleration time of simple PLC segment 3	0.01s~65000s	Model dependent	☆
FC-44	Acceleration time of simple PLC segment 4	0.01s~65000s	Model dependent	☆
FC-45	Deceleration time of simple PLC segment 4	0.01s~65000s	Model dependent	☆
FC-46	Acceleration time of simple PLC segment 5	0.01s~65000s	Model dependent	☆
FC-47	Deceleration time of simple PLC segment 5	0.01s~65000s	Model dependent	☆

Function Code	Parameter Name	Setting Range	Default	Property
FC-48	Accelerationtime of simple PLC segment 6	0.01s~65000s	Model dependent	☆
FC-49	Deceleration time of simple PLCsegment 6	0.01s~65000s	Model dependent	☆
FC-50	Accelerationtime of simple PLC segment 7	0.01s~65000s	Model dependent	☆
FC-51	Deceleration time of simple PLCsegment 7	0.01s~65000s	Model dependent	☆
FC-52	Accelerationtime of simple PLC segment 8	0.01s~65000s	Model dependent	☆
FC-53	Deceleration time of simple PLCsegment 8	0.01s~65000s	Model dependent	☆
FC-54	Accelerationtime of simple PLC segment 9	0.01s~65000s	Model dependent	☆
FC-55	Deceleration time of simple PLCsegment 9	0.01s~65000s	Model dependent	
FC-56	Accelerationtime of simple PLC segment 10	0.01s~65000s	Model dependent	☆
FC-57	Deceleration time of simple PLCsegment 10	0.01s~65000s	Model dependent	☆
FC-58	Accelerationtime of simple PLC segment 11	0.01s~65000s	Model dependent	☆
FC-59	Deceleration time of simple PLCsegment 11	0.01s~65000s	Model dependent	☆
FC-60	Accelerationtime of simple PLC segment 12	0.01s~65000s	Model dependent	☆
FC-61	Deceleration time of simple PLCsegment 12	0.01s~65000s	Model dependent	☆
FC-62	Accelerationtime of simple PLC segment 13	0.01s~65000s	Model dependent	☆
FC-63	Deceleration time of simple PLCsegment 13	0.01s~65000s	Model dependent	☆
FC-64	Accelerationtime of simple PLC segment 14	0.01s~65000s	Model dependent	☆
FC-65	Deceleration time of simple PLCsegment 14	0.01s~65000s	Model dependent	☆
FC-66	Accelerationtime of simple PLC segment 15	0.01s~65000s	Model dependent	☆
FC-67	Deceleration time of simple PLCsegment 15	0.01s~65000s	Model dependent	☆
Group Fd: Swing Frequency, Fixed Length and Count				
Fd-00	Swing frequency setting mode	0: Relative to the central frequency 1: Relative to the maximum frequency	0	☆

Function Code	Parameter Name	Setting Range	Default	Property
Fd-01	Swing frequency amplitude	0.0%~100.0%	0.0%	☆
Fd-02	jump frequency amplitude of Swing running	0.0%~50.0%	0.0%	☆
Fd-03	Swing frequency cycle	0.1s~3000.0s	10.0s	☆
Fd-04	Triangular wave rising time coefficient	0.1%~100.0%	50.0%	☆
Fd-05	Set length	0m~65535 m	1000 m	☆
Fd-06	Actual length	0m~65535 m	0 m	☆
Fd-07	Number of pulses per meter	0.1~6553.5	100.0	☆
Fd-08	Set count value	1~65535	1000	☆
Fd-09	Designated count value	1~65535	1000	☆

Group d0: Motor Parameters

d0-00	Rated motor power	0.1kw~1000.0 kW	Model dependent	★
d0-01	Rated motor voltage	1V~2000 V	Model dependent	★
d0-02	Rated motor current	0.01A~655.35 A (Frequency inverter power ≤ 55 kW) 0.1A~6553.5 A (Frequency inverter power ≥75 kW)	Model dependent	★
d0-03	Rated motor frequency	0.01 Hz~maximum frequency	Model dependent	★
d0-04	Rated motor rotational speed	1rpm~65535rpm	Model dependent	★
d0-05	Motor auto-tuning selection	0: No auto-tuning 1: Asynchronous motor static auto-tuning 2: Asynchronous motor complete auto-tuning 3: Asynchronous motor static complete auto-tuning	0	★
d0-06	Stator resistance (asynchronous motor)	0.001Ω~65.535 Ω (Frequency inverter power ≤ 55 kW) 0.0001Ω~6.5535 Ω (Frequency inverter power ≥75 kW)	Tuning parameter	★

Function Code	Parameter Name	Setting Range	Default	Property
d0-07	Rotor resistance (asynchronous motor)	0.001Ω~65.535 Ω (Frequency inverter power ≤ 55 kW) 0.0001Ω~6.5535 Ω (Frequency inverter power ≥75 kW)	Tuning parameter	★
d0-08	Leakage inductive reactance(asynchronous motor)	0.01mH~655.35 mH (Frequency inverter power ≤ 55 kW) 0.001mH~65.535 mH (Frequency inverter power ≥75 kW)	Tuning parameter	★
d0-09	Mutual inductive reactance(asynchronous motor)	0.1mH~6553.5 mH (Frequency inverter power ≤ 55 kW) 0.01—655.35 mH (Frequency inverter power ≥75 kW)	Tuning parameter	★
d0-10	No-load current (asynchronous motor)	0.01A to d0-02 (Frequency inverter power ≤ 55 kW) 0.1A to d0-02 (Frequency inverter power ≥75 kW)	Tuning parameter	★
d0-11	Encoder pulses per revolution	1~32767	1024	★
d0-12	Encoder type	0: ABZ incremental encoder 1: Resolver	0	★
d0-13	A/B phase sequence of ABZ incremental encoder	0: Forward 1: Reserve	0	★
d0-14	Number of pole pairs of resolver	1~99	1	★
d0-15	Encoder wire-break fault detection time	0: No action 0.1s~10.0s	0.0s	★

Group d1: Motor Vector Control Parameters

d1-00	Speed loop proportional gain 1(Kp1)	0.01~10.00	0.30	★
d1-01	Speed loop integral time 1(Ti1)	0.01s~10.00s	0.50s	☆
d1-02	Switchover frequency 1	0.00 to d1-05	5.00 Hz	☆
d1-03	Speed loop proportional gain 2(Kp2)	0.01~10.00	0.20	☆
d1-04	Speed loop integral time 2(Ti2)	0.01s~10.00s	1.00s	☆
d1-05	Switchover frequency 2	d1-02 to maximum output frequency	10.00 Hz	☆

Function Code	Parameter Name	Setting Range	Default	Property
d1-06	Speed loop integral property	0: Integral separation disable 1: Integral separation enable	0	☆
d1-07	ASR input filtering time	0.000s~0.100s	0	☆
d1-09	Excitation adjustment proportional gain	0~30000	1300	☆
d1-10	Excitation adjustment integral gain	0~30000	1300	☆
d1-11	Torque adjustment proportional gain	0~30000	1300	☆
d1-12	Torque adjustment integral gain	0~30000	1300	☆
d1-13	torque upper limit source in speed control mode	0: d1-14 1: AI1 2: AI2 3: AI3 4: Pulse setting (HDI) 5: Communication setting	0	☆
d1-14	Digital setting of torque limit	0.0%~200.0%	150.0%	☆
d1-15	Motor running slip gain	50%~200%	100%	☆
Group d2: Torque Control Function				
d2-00	Speed/Torque control selection	0: Speed control 1: Torque control	0	★
d2-01	Torque setting source in torque control	0: Digital setting (d2-02) 1: AI1 2: AI2 3: AI3 4: Pulse setting (HDI) 5: Communication setting 6: MIN (AI1, AI2) 7: MAX (AI1, AI2)	0	☆
d2-02	Torque digital setting in torque control	-200.0% ~ 200.0%	100.0%	☆
d2-05	Forward maximum frequency in torque control	0.00 Hz ~ maximum frequency (F0-03)	50.00 Hz	☆
d2-06	Reverse maximum frequency in torque	0.00 Hz ~ maximum frequency (F0-03)	50.00 Hz	☆
d2-07	Acceleration time in torque control	0.00s~120.00s	0.10s	☆
d2-08	Deceleration time in torque control	0.00s~120.00s	0.10s	☆

Function Code	Parameter Name	Setting Range	Default	Property
Group d3: V/F Control Parameters				
d3-00	V/F curve setting	0: Linear V/F 1: Multi-point V/F 2: Square V/F 3: 1.2-power V/F 4: 1.4-power V/F 6: 1.6-power V/F 8: 1.8-power V/F 10: V/F complete separation 11: V/F half separation	0	★
d3-01	Torque boost	0.0% (fixed torque boost) 0.1%~30.0%	Model dependent	☆
d3-02	Cut-off frequency of torque boost	0.0%~80.0% Actual cut-off frequency=Motor rated frequency×d3-02	50.0%	★
d3-03	Multi-point V/F frequency 1 (F1)	0.00 Hz ~ d3-05	0.00 Hz	☆
d3-04	Multi-point V/F voltage 1 (V1)	0.0%~100.0%	0.0%	☆
d3-05	Multi-point V/F frequency 2 (F2)	d3-03 to d3-07	0.00 Hz	☆
d3-06	Multi-point V/F voltage 2 (V2)	0.0%~100.0%	0.0%	☆
d3-07	Multi-point V/F frequency 3 (F3)	d3-05 ~ maximum frequency (F0-03)	0.00 Hz	☆
d3-08	Multi-point V/F voltage 3 (V3)	0.0%~100.0%	0.0%	☆
d3-09	V/F slip compensation gain	0.0%~200.0%	0.0%	☆
d3-10	Oscillation suppression gain	0~100	0	☆
d3-11	Voltage source for V/F separation	0: Digital setting(d3-12) 1: AI1 2: AI2 3: AI3 4: Pulse setting(HDI) 5: Multi-function 6: Simple PLC 7: PID 8: Communication setting Note:100.0% corresponds to the rated motor voltage	0	☆
d3-12	Voltage digital setting for V/F separation	0 V ~ rated motor voltage	0 V	☆

Function Code	Parameter Name	Setting Range	Default	Property
d3-13	Voltage rise time of V/F separation	0.0s~1000.0s	0.0s	☆
Group d4: Control Optimization Parameters				
d4-00	Carrier frequency	0.5kHz~16.0 kHz	Model dependent	☆
d4-01	DPWM switchover frequency upper limit	0.00Hz~15.00 Hz	12.00 Hz	☆
d4-02	PWM modulation mode	0: Asynchronous modulation 1: Synchronous modulation	0	☆
d4-03	Carrier frequency adjustment with temperature	0: No 1: Yes	0	☆
d4-04	Random PWM depth	0: Random PWM invalid 1~10: Random PWM carrier frequency depth	0	☆
d4-05	Dead zone compensation mode selection	0: No compensation 1: Compensation mode 1 2: Compensation mode 2	1	☆
d4-06	SFVC mode selection	0: SFVC mode 1 1: SFVC mode 2	2	★

Chapter 6 Description of Function Codes

6.1 Group F0: Basic Function Parameters

Function Code	Parameter Name	Setting Range	Default
F0-00	Motor control mode	0: Sensorless flux vector control (SFVC) 1: Closed-loop vector control (CLVC) 2: Voltage/Frequency (V/F) control	2

- 0: Sensor-less flux vector control (SFVC)

It indicates open-loop vector control, and is applicable to high-performance control applications such as machine tool, centrifuge, wire drawing machine and injection molding machine. One frequency inverter can operate only one motor.

- 1: Closed-loop vector control (CLVC)

It indicates closed-loop vector control. An encoder must be installed at the motor side, and a PG card matching the encoder must be installed at the frequency inverter side. It is applicable to high-accuracy speed control or torque control applications such as high-speed paper making machine, crane and elevator. One frequency inverter can drive only one motor.

- 2: Voltage/Frequency (V/F) control

It is applicable to applications with low load requirements or applications where one frequency inverter operates multiple motors, such as fan and pump.

Note:

- If vector control is used, motor auto-tuning must be performed because the advantages of vector control can only be utilized after correct motor parameters are obtained. Better performance can be achieved by adjusting speed regulator parameters in group "d1".

Function Code	Parameter Name	Setting Range	Default
F0-01	Command source selection	0: Operation panel control (LED off) 1: Terminal control (LED on) 2: Communication control (LED blinking)	0

It is used to determine the input channel of the frequency inverter control commands, such as run, stop, forward rotation, reverse rotation and jog operation. You can input the commands in the following three channels:

- 0: Operation panel control ("LOCAL/REMOT" indicator off)

Commands are given by pressing keys "RUN" and "STOP/RESET" on the operation panel.

- 1: Terminal control ("LOCAL/REMOT" indicator on)

Commands are given by means of multifunctional input terminals with functions such as FWD, REV, JOGF, and JOGR.

- 2: Communication control ("LOCAL/REMOT" indicator blinking)

Commands are given from host computer. For more details please refer to the appendix of communication protocol.

Function Code	Parameter Name	Setting Range	Default
F0-02	Frequency reference resolution	1: 0.1 Hz 2: 0.01 Hz	2

It is used to set the resolution of all frequency-related parameters.

If the resolution is 0.1Hz, the max. output frequency of FC155 can be up to 3200.0Hz. If the resolution is 0.01 Hz, the FC155 can output up to 320.00 Hz.

Note:

- Modifying this parameter will make the decimal places of all frequency-related parameters change and corresponding frequency values change display.

Function Code	Parameter Name	Setting Range	Default
F0-03	Maximum frequency	50.00~3200.00 Hz	50.00 Hz

When the frequency source is AI, pulse setting (HDI), or Multi-segment speed, the 100% of input corresponds to the value of this parameter F0-03.

The output frequency of the FC155 can reach up to 3200 Hz. To take both frequency reference resolution and frequency input range into consideration, you can set the number of decimal places for frequency reference in F0-02.

- If F0-02 is set to 1, the frequency reference resolution is 0.1 Hz. In this case, the setting range of F0-03 is 50.0 to 3200.0 Hz.
- If F0-02 is set to 2, the frequency reference resolution is 0.01 Hz. In this case, the setting range of F0-03 is 50.00 to 320.00 Hz.

Note:

After the value of F0-02 is modified, the frequency resolution of all frequency related function codes change accordingly.

Function Code	Parameter Name	Setting Range	Default
F0-04	Source of frequency upper limit	0: Set by F0-05 1: AI1 2: AI2 3: AI3 4: Pulse setting (HDI) 5: Communication setting	0

It is used to set the source of the frequency upper limit, including digital setting (F0-05), AI, pulse setting or communication setting. If the frequency upper limit is set by means of AI1, AI2, AI3, PULSE (HDI) or communication, the setting is similar to that of the main frequency source X. For details, see the description of F0-10.

For example, to avoid runaway in torque control mode in winding machine application, you can set the frequency upper limit by means of analog input. When the frequency inverter reaches the upper limit, it will run at this limited speed.

Function Code	Parameter Name	Setting Range	Default
F0-05	Frequency upper limit	Frequency lower limit ~ maximum frequency	50.00 Hz

This parameter is used to set the frequency upper limit. The setting range is from frequency lower limit(F0-07)~maximum frequency(F0-03)

Function Code	Parameter Name	Setting Range	Default
F0-06	Frequency upper limit offset	0.00 Hz ~ maximum frequency (F0-03)	0.00 Hz

If the source of the frequency upper limit is analog input or pulse setting, the final frequency upper limit is obtained by adding the offset in this parameter to the frequency upper limit set in F0-04.

Function Code	Parameter Name	Setting Range	Default
F0-07	Frequency lower limit	0.00 Hz ~ frequency upper limit (F0-05)	0.00 Hz

If the frequency command is lower than the value of this parameter, the frequency inverter can stop, or run at the frequency lower limit, or run at zero speed. The result can be determined by F1-15(setting frequency lower than frequency lower limit running mode).

Function Code	Parameter Name	Setting Range	Default
F0-08	Preset frequency	0.00 ~ maximum frequency (valid when frequency source is digital setting)	50.00 Hz

If the frequency source is digital setting or terminal UP/DOWN, the value of this parameter is the initial frequency of the frequency inverter (digital setting).

Function Code	Parameter Name	Setting Range	Default
F0-09	Base frequency for UP/DOWN modification during running	0: Running frequency 1: Setting frequency	0

This parameter is valid only when the frequency source is digital setting.

When using the keys Δ and ∇ the terminal UP/DOWN function, using which method to modify setting frequency, that is aim frequency is increased on the base of running frequency or changed on the basis of setting frequency.

It is used to set the base frequency to be modified by using keys Δ and ∇ the terminal UP/DOWN function. If the running frequency and setting frequency are different, there will be a large difference between the frequency inverter's performances during the acceleration/ deceleration process.

Function Code	Parameter Name	Setting Range	Default
F0-10	Main frequency source X selection	0: Digital setting (Preset frequency F0-08, UP/DOWN modifiable, non-record at power failure) 1: Digital setting (Preset frequency F0-08, UP/DOWN modifiable, record at power failure) 2: AI1 3: AI2 4: AI3 5: Pulse setting (HDI) 6: Multi-segment speed 7: Simple PLC 8: PID 9: Communication setting 10: AI-KB(Only valid for keypad with potentiometer)	10

It is used to select the setting channel of the main frequency. You can set the main frequency in the following 10 channels:

- **0: Digital setting** (Preset frequency F0-08, UP/DOWN modifiable, not record at power failure)

The initial value of set frequency is the value of F0-08(Preset frequency). You can change the set frequency by pressing “ Δ ” and “ ∇ ” on the operation panel (or using the UP/DOWN function of input terminals).

When the Frequency inverter is powered on again after power failure, the set frequency reverts to the value of F0-08.

- **1: Digital setting** (Preset frequency F0-08, UP/DOWN modifiable, record at power failure)

The initial value of the set frequency is the value of F0-08 (Preset frequency). You can change the set frequency by pressing keys Δ and ∇ on the operation panel (or using the UP/DOWN functions of input terminals).

When the frequency inverter is powered on again after power failure, the setting frequency is the value memorized at the moment of the last power failure and the modification value of keys Δ and ∇ (Or the terminal UP/DOWN).

Note that F0-17 (record selection of digital setting frequency upon stopping) determines whether the set frequency is memorized or cleared when the frequency inverter stops. It is related to stopping rather

than power failure.

- **2: AI1**
- **3: AI2**
- **4: AI3**

The frequency is set by analog input. The FC155 control board provides two analog input (AI) terminals (AI1, AI2). Another AI terminal (AI3) is provided by the I/O extension card.

Including:

AI1: 0V~10 V voltage input or 0mA~20mA current input, determined by jumper J2 on control card;

AI2: 0V~10V voltage input or 0mA~20 mA current input, determined by jumper J3 on control card;

AI3: -10V~10 V voltage input

The corresponding relationship curve between the input voltage of AI1, AI2 and AI3 and the target frequency can be user-defined.

When AI is used as the frequency setting source, the corresponding value 100% of the voltage/current input corresponds to the value of F0-03 (Maximum frequency).

- **5: Pulse setting (HDI)**

The frequency is set by the terminal HDI (high-speed pulse). The signal specification of pulse setting is 9V~30V (voltage range) and 0 kHz~100 kHz (frequency range). Pulse can be only input by the terminal HDI.

The relation between HDI terminal input pulse frequency and corresponding setting is set by F3-28~F3-31. The corresponding relation is the linear relation of these two points. The corresponding value 100% of pulse setting corresponds to the value of F0-03 (Maximum frequency).

- **6: Multi-segment speed**

In Multi-segment speed mode, combinations of different DI terminal states correspond to different set frequencies. The FC155 supports a maximum of 16 speeds implemented by 16 state combinations of four DI terminals in Group FC. The multiple segments speed indicates percentages of the value of F0-03 (Maximum frequency).

If a DI terminal is used for the multi-segment speed terminal, you need to perform related setting in group F2. For details, refer to the descriptions of Group F2.

- **7: Simple PLC (built-in)**

When the simple programmable logic controller (PLC) mode is used as the frequency source, the running frequency of the frequency inverter can be switched over among the 16 frequency references. You can set the holding time and acceleration/deceleration time of the 16 frequency references. For details, refer to the descriptions of Group FC.

- **8: PID**

The output of PID control is used as the running frequency. PID control is generally used in on-site closed-loop control, such as constant pressure closed-loop control and constant tension closed-loop control.

When applying PID as the frequency source, it is necessary to set the relevant parameters of PID function in group Fb.

- **9: Communication setting**

The frequency is set by means of communication.

- **10: AI-KB**

The frequency command is given by potentiometer in the keypad. It is only valid for the keypad with potentiometer.

Function Code	Parameter Name	Setting Range	Default
F0-11	Auxiliary frequency source Y selection	0: Digital setting (Preset frequency F0-08, UP/DOWN modifiable, not record at power failure) 1: Digital setting (Preset frequency F0-08, UP/DOWN modifiable, record at power failure) 2: AI1 3: AI2 4: AI3 5: Pulse setting (HDI) 6: Multi-segment speed 7: Simple PLC 8: PID 9: Communication setting 10: AI-KB (Only valid for keypad with potentiometer)	1

When used as an independent frequency input channel (frequency source switched over from X to Y), the auxiliary frequency source Y is used in the same way as the main frequency source X (refer to F0-10).

When the auxiliary frequency source is used for operation (frequency source is "X and Y operation"), pay attention to the following aspects:

- 1) If the auxiliary frequency source Y is digital setting, the preset frequency (F0-08) does not take effect. You can directly adjust the set main frequency by pressing keys ~~and~~ on the ~~operation~~ panel (or using the UP/DOWN function of input terminals).
- 2) If the auxiliary frequency source is analog input (AI1, AI2 and AI3) or pulse setting, 100% of the input corresponds to the range of the auxiliary frequency Y (set in F0-12 and F0-13).
- 3) If the auxiliary frequency source is pulse setting, it is similar to analog input.

Note: The main frequency source X and auxiliary frequency source Y must not use the same channel. That is, F0-10 and F0-11 cannot be set to the same value in case of confusion.

Function Code	Parameter Name	Setting Range	Default
F0-12	Selection of auxiliary frequency Y range	0: Relative to maximum frequency 1: Relative to main frequency X	0
F0-13	Range of auxiliary frequency Y	0%~150%	100%


If X and Y operation is used, F0-12 and F0-13 are used to set the adjustment range of the auxiliary frequency source.

You can set the auxiliary frequency to be relative to either maximum frequency or main frequency X. If relative to main frequency X, the setting range of the auxiliary frequency Y varies according to the main frequency X.

Function Code	Parameter Name	Setting Range	Default
F0-14	Frequency source selection	Unit's digit (Frequency source selection) 0: Main frequency source X 1: X and Y operation (operation relationship determined by ten's digit) 2: Switchover between X and Y 3: Switchover between X and "X and Y operation" 4: Switchover between Y and "X and Y operation" Ten's digit (X and Y operation relationship) 0: X+Y 1: X-Y 2: Maximum(X, Y) 3: Minimum(X, Y)	00

It is used to select the frequency setting channel. Frequency setting can be realized by the main frequency source X and auxiliary frequency source Y operation.

Figure 6-1 Target frequency setting



If the frequency source involves X and Y operation, you can set the frequency offset in F0-15 for superposition to the X and Y operation result, flexibly satisfying various requirements.

Function Code	Parameter Name	Setting Range	Default
F0-15	Frequency offset of auxiliary frequency source for X and Y	0.00 Hz ~ maximum frequency (F0-03)	0.00 Hz

This parameter is valid only when the frequency source is set to "X and Y operation". The final frequency is obtained by adding the frequency offset set in this parameter to the X and Y operation result.

Function Code	Parameter Name	Setting Range	Default
F0-16	Binding command source to frequency source	Unit's digit (Binding operation panel command to frequency source) 0: No binding 1: Frequency source by digital setting 2: AI1 3: AI2 4: AI3 5: Pulse setting (HDI) 6: Multi-reference 7: Simple PLC 8: PID 9: Communication setting Ten's digit (Binding terminal command to frequency source) 0~9, same as unit's digit Hundred's digit (Binding communication command to frequency source) 0~9, same as unit's digit Thousand's digit (Binding automatic running command to frequency source) 0~9, same as unit's digit	0000

It is used to bind three running command sources with ten frequency sources, facilitating to implement synchronous switchover.

For details on the frequency sources, see the description of F0-10(Main frequency source X selection). Different running command sources can be bound to the same frequency source.

If a command source has bound to a frequency source, this frequency source set in F0-10~ F0-14 no longer takes effect when this command source is effective.

Function Code	Parameter Name	Setting Range	Default
F0-17	Record of digital setting frequency of power failure	0: Notrecord 1: Record	1

This parameter is valid only when the frequency source is digital setting.

If this parameter is set to 0, the digital setting frequency value restore to the value of F0-08 (Preset frequency) after the frequency inverter stops. The modification by using keys \triangle and ∇ or the terminal UP/DOWN function is cleared to zero.

If this parameter is set to 1, the digital setting frequency value is the set frequency at the moment when the frequency inverter stops. The modification by using keys \triangle and ∇ or the terminal UP/ DOWN function remains is record and valid.

Function Code	Parameter Name	Setting Range	Default
F0-18	Acceleration/Deceleration mode	0: Linear acceleration/deceleration 1: S-curve acceleration/deceleration A 2: S-curve acceleration/deceleration B	0

It is used to set the frequency changing mode during the frequency inverter start and stop process.

- **0: Linear acceleration/deceleration**

The output frequency increases or decreases in linear mode. FC155 provides four groups of acceleration / deceleration time, which can be selected by using multi-functional DI terminals (F2-00 to F2-09).

- **1: S-curve acceleration/deceleration A**

The b0-23 (F0-28) and b0-24(F0-29) respectively define the time proportions of the start segment and the end segment in S-curve acceleration/deceleration A. This two parameters need to meet the requirement: F0-28+F0-29 ≤ 100.0%.

In Figure 6-2, t1 is the time defined in F0-28, during the period, the curve slope of the output frequency change increases gradually. t2 is the time defined in F0-29, during this period, the slope of the output frequency change gradually decreases to 0. Within the time between t1 and t2, the slope of the output frequency change remains unchanged, that is, it is linear acceleration/ deceleration.

- **2: S-curve acceleration/deceleration B**


In this curve, the rated motor frequency f_b is always the inflection point of S curve. This mode is usually used in applications where quick acceleration/deceleration is required at the speed higher than the rated frequency.

When the setting frequency is higher than rated frequency, the acceleration/deceleration time is:


$$t = \left(\frac{4}{9} \times \left(\frac{f}{f_b} \right)^2 + \frac{5}{9} \right) \times T$$

In this formula, f is setting frequency, f_b is motor rated frequency, T is the acceleration time from 0 Hz to rated frequency f_b .

Figure 6-2S-curve acceleration/deceleration A diagram



S-curve acceleration/deceleration B diagram



Function Code	Parameter Name	Setting Range	Default
F0-19	Acceleration/Deceleration time unit	0:1s 1: 0.1s 2: 0.01s	1

To satisfy the requirements of different applications, FC155 series provides three acceleration/deceleration time units, 1s, 0.1s and 0.01s.

Note:


- Modifying this parameter will make the decimal places of four groups acceleration/deceleration time change and corresponding acceleration/deceleration time will change. Pay attention for it in on-site application.

Function Code	Parameter Name	Setting Range	Default
F0-20	Acceleration time 1	0.00s~650.00s (F0-19 = 2) 0.0s~6500.0s (F0-19 = 1) 0s~65000s (F0-19 = 0)	Model dependent
F0-21	Deceleration time 1	0.00s~650.00s (F0-19 = 2) 0.0s~6500.0s (F0-19 = 1) 0s~65000s (F0-19 = 0)	Model dependent
F0-22	Acceleration time 2	0.00s~650.00s (F0-19 = 2) 0.0s~6500.0s (F0-19 = 1) 0s~65000s (F0-19 = 0)	Model dependent
F0-23	Deceleration time 2	0.00s~650.00s (F0-19 = 2) 0.0s~6500.0s (F0-19 = 1) 0s~65000s (F0-19 = 0)	Model dependent
F0-24	Acceleration time 3	0.00s~650.00s (F0-19 = 2) 0.0s~6500.0s (F0-19 = 1) 0s~65000s (F0-19 = 0)	Model dependent
F0-25	Deceleration time 3	0.00s~650.00s (F0-19 = 2) 0.0s~6500.0s (F0-19 = 1) 0s~65000s (F0-19 = 0)	Model dependent
F0-26	Acceleration time 4	0.00s~650.00s (F0-19 = 2) 0.0s~6500.0s (F0-19 = 1) 0s~65000s (F0-19 = 0)	Model dependent
F0-27	Deceleration time 4	0.00s~650.00s (F0-19 = 2) 0.0s~6500.0s (F0-19 = 1) 0s~65000s (F0-19 = 0)	Model dependent

Acceleration time indicates the time required by the frequency inverter to accelerate from 0 Hz to "Acceleration / Deceleration base frequency" (F0-32), that is, t1 in Figure 6-3.

Deceleration time indicates the time required by the frequency inverter to decelerate from "Acceleration / Deceleration base frequency" (F0-32) to 0 Hz, that is, t2 in Figure 6-3.

Figure 6-3 Acceleration/Deceleration time



The FC155 provides totally four groups of acceleration/deceleration time for selection. You can perform switchover by using a DI terminal. And you can set the four groups of acceleration/deceleration time through the following function codes:


- Group 1: F0-20, F0-21;
- Group 2: F0-22, F0-23;
- Group 3: F0-24, F0-25;
- Group 4: F0-26, F0-27;

Function Code	Parameter Name	Setting Range	Default
F0-28	Time proportion of S-curve start segment	0.0% ~50%	30.0%
F0-29	Time proportion of S-curve end segment	0.0% ~ 50%	30.0%

Function Code	Parameter Name	Setting Range	Default
F0-30	Frequency switchover point between acceleration time 1 and acceleration time 2	0.00Hz ~ maximum frequency	0.00 Hz
F0-31	Frequency switchover point between deceleration time 1 and deceleration time 2	0.00Hz ~ maximum frequency	0.00 Hz

This function is valid when acceleration/deceleration time switchover is not performed by means of DI terminal. It is used to select different groups of acceleration/ deceleration time based on the running frequency range rather than DI terminal during the running process of the frequency inverter.

Figure 6-4 Acceleration/deceleration time switchover



During acceleration, if the running frequency is smaller than the value of F0-30, acceleration time 2 is selected. If the running frequency is larger than the value of F0-30, acceleration time 1 is selected.

During deceleration, if the running frequency is larger than the value of F0-31, deceleration time 1 is selected. If the running frequency is smaller than the value of F0-31, deceleration time 2 is selected.

Function Code	Parameter Name	Setting Range	Default
F0-32	Acceleration/Deceleration time base frequency	0: Maximum frequency (F0-03) 1: Set frequency 2: 100 Hz	0

The acceleration/deceleration time indicates the time for the frequency inverter to increase from 0 Hz to the frequency set in F0-32, figure 6-3 is the acceleration/deceleration time diagram. If this parameter is set to 1, the acceleration/deceleration time is related to the set frequency. If the set frequency changes frequently, the motor's acceleration/deceleration also changes. Please note it in the application.

6.2 Group F1: Start/Stop Control Parameters

Function Code	Parameter Name	Setting Range	Default
F1-00	Start mode	0: Direct start 1: Rotational speed tracking restart 2: Pre-excited start (asynchronous motor)	0

- 0: Direct start**
- If the DC braking time is set to 0, the frequency inverter starts to run from the startup frequency.
- If the DC braking time is not 0, the frequency inverter performs DC braking first and then starts to run from the startup frequency. It is applicable to small-inertia load application and where the motor is likely to rotate at startup.
- 1: Rotational speed tracking restart**

The frequency inverter judges the rotational speed and direction of the motor firstly, and then starts at the tracked frequency. Then the inverter smoothly starts the rotating motor without any impact. It is applicable to the restart of instantaneous power failure of large-inertia loads. To ensure the perfect performance of rotational speed tracking restart, please set the motor parameters correctly.

- 2: Pre-excited start (asynchronous motor)**

It is valid only for asynchronous motor and used for building the magnetic field before the motor runs.

For pre-excited current and pre-excited time, see parameters of F1-05 and F1-06.

- If the pre-excited time is 0, the frequency inverter cancels pre-excitation and starts to run from startup frequency.

- If the pre-excited time is not 0, the frequency inverter pre-excites firstly before startup, improving the dynamic response of the motor.

Function Code	Parameter Name	Setting Range	Default
F1-01	Rotational speed tracking mode	0: From frequency at stop 1: From zero speed 2: From maximum frequency	0

To complete the rotational speed tracking process within the shortest time, select the proper mode in which the frequency inverter tracks the motor rotational speed.

- **0: From frequency at stop**

It is the commonly selected mode.

- **1: From zero frequency**

It is applicable to restart after a long time of power failure.

- **2: From the maximum frequency**

It is applicable to the power-generating load.

Function Code	Parameter Name	Setting Range	Default
F1-02	Rotational speed tracking speed	1~100	20

In the rotational speed tracking restart mode, select the rotational speed tracking speed. The larger the value is, the faster the tracking is. However, too large value may cause unreliable tracking.

Function Code	Parameter Name	Setting Range	Default
F1-03	Startup frequency	0.00~10.00 Hz	0.00 Hz
F1-04	Startup frequency holding time	0.0s~100.0s	0.0s

To ensure the motor torque at frequency inverter startup, set a proper startup frequency. In addition, to build excitation when the motor starts up, the startup frequency must be held for a certain period.

The startup frequency (F1-03) is not restricted by the frequency lower limit. If the setting target frequency is lower than the startup frequency, the frequency inverter will not start and stays in the holding state.

During switchover between forward rotation and reverse rotation, the startup frequency holding time is disabled. The holding time is not included in the acceleration time but in the running time of simple PLC.

Example 1:

F0-10 = 0	The frequency source is digital setting.
F0-08 = 3.00 Hz	The digital setting frequency is 3.00 Hz.
F1-03 = 5.00 Hz	The startup frequency is 5.00 Hz.
F1-04 = 2.0s	The startup frequency holding time is

In this example, the frequency inverter stays in the holding state and the output frequency is 0.00 Hz.

Example 2:

F0-10 = 0	The frequency source is digital setting.
F0-08 = 10.0	The digital setting frequency is 10.00 Hz.
F1-03 = 5.00 Hz	The startup frequency is 5.00 Hz.
F1-04 = 2.0s	The startup frequency holding time is

In this example, the frequency inverter accelerates to 5.00 Hz at 2s, and then accelerates to the set frequency 10.00 Hz.

Function Code	Parameter Name	Setting Range	Default
F1-05	Startup DC braking current/Pre-excited current	0%~100%	0%
F1-06	Startup DC braking time/Pre-excited time	0.0s~100.0s	0.0s

Startup DC braking is generally used during restart of the frequency inverter after the rotating motor stops. Pre-excitation is used to make the frequency inverter build magnetic field for the asynchronous motor before startup to improve the responsiveness.

Startup DC braking is valid only for direct start (F1-00 = 0). In this case, the frequency inverter performs DC braking at the setting startup DC braking current. After the startup DC braking time, the frequency inverter starts to run. If the startup DC braking time is 0, the frequency inverter starts directly without DC braking. The larger the startup DC braking current is, the larger the braking force is.

If the startup mode is pre-excited start (F1-00 = 3), the frequency inverter firstly builds magnetic field based on the set pre-excited current. After the pre-excited time, the frequency inverter starts to run. If the pre-excited time is 0, the frequency inverter starts directly without pre-excitation.

The startup DC braking current or pre-excited current is a percentage of motor rated current.

Function Code	Parameter Name	Setting Range	Default
F1-07	Stop mode	0: Decelerate to stop 1: Free stop	0

- 0: Decelerate to stop

After the stop command is enabled, the frequency inverter decreases the output frequency according to the deceleration time and stops when the frequency decreases to zero.

- 1: Free stop

After the stop command is enabled, the frequency inverter immediately stops the output. The motor will free stop based on the mechanical inertia.

Function Code	Parameter Name	Setting Range	Default
F1-08	Initial frequency of stop DC braking	0.00 Hz ~ maximum frequency	0.00 Hz
F1-09	Waiting time of stop DC braking	0.0s~100.0s	0.0s
F1-10	Stop DC braking current	0%~100%	0%
F1-11	Stop DC braking time	0.0s~100.0s	0.0s

- F1-08 (Initial frequency of stop DC braking)

During the process of decelerating to stop, the frequency inverter starts DC braking when the running frequency is lower than the value set in b1-08.

- F1-09 (Waiting time of stop DC braking)

When the running frequency decreases to the initial frequency of stop DC braking, the frequency inverter stops output for a certain period and then starts DC braking. This prevents faults such as over current caused due to DC braking at high speed.


- F1-10 (Stop DC braking current)

This parameter specifies the output current at DC braking and is a percentage relative to the motor rated current. The larger the value is, the stronger the DC braking effects, but the more heat the motor and frequency inverter emit.

- F1-11 (Stop DC braking time)

This parameter specifies the holding time of DC braking. If it is set to 0, DC braking is cancelled. The stop DC braking process is shown in the following figure.

Figure 6-5 Stop DC braking process




Function Code	Parameter Name	Setting Range	Default
F1-12	Reverse running	0: Enabled 1: Disabled	0

It is used to set whether the frequency inverter allows reverse rotation. In the applications where reverse rotation is prohibited, set F1-12 to 1.

Function Code	Parameter Name	Setting Range	Default
F1-13	Forward/Reverse rotation dead-zone time	0.0s~3000.0s	0.0s

It is used to set the time when the output is 0 Hz at transition of the frequency inverter forward rotation and reverse rotation, as shown in the following figure.

Figure 6-6 Forward/Reverse rotation dead-zone time



Function Code	Parameter Name	Setting Range	Default
F1-14	Rotation direction	0: Same direction 1: Reverse direction	0

You can change the rotation direction of the motor just by modifying this parameter without changing the motor wiring. Modifying this parameter is equivalent to exchanging any two phase of the motor's U, V, W wires.

Note:

The motor will restore original running direction after parameter initialization (A0-09). Do not use this function in applications where changing the rotating direction of the motor is prohibited after system commissioning is complete.

Function Code	Parameter Name	Setting Range	Default
F1-15	Running mode when set frequency lower than frequency lower limit	0: Run at frequency lower limit 1: Stop 2: Run at zero speed	0

It is used to set the frequency inverter running mode when the set frequency is lower than the frequency lower limit. FC155 provides three running modes to satisfy requirements of various applications.

Function Code	Parameter Name	Setting Range	Default
F1-16	Terminal JOG priority	0: Disabled 1: Enabled	0

It is used to set whether terminal JOG is priority.

If terminal JOG is priority, the frequency inverter switches to terminal JOG running state when there is a terminal JOG command during the running process of the frequency inverter.

6.3 Group F2: Input Terminals

FC155 provides 5 standards multi-functional digital input (DI) terminals (HDI can be used for high-speed pulse input terminal) and two analog input (AI) terminals. The optional extension card provides another 5 DI terminals (DI6 to DI10) and one AI terminal (AI3).

Function Code	Parameter Name	Default	Remark
F2-00	DI1 function selection	1: Forward RUN (FWD)	Standard
F2-01	DI2 function selection	2: Reverse RUN (REV)	Standard
F2-02	DI3 function selection	6: Multi-function terminal 1	Standard
F2-03	DI4 function selection	7: Multi-function terminal 2	Standard
F2-04	HDI(DI5) function selection	32: Pulse input	Standard
F2-05	DI6 function selection	0	Extended
F2-06	DI7 function selection	0	Extended
F2-07	DI8 function selection	0	Extended
F2-08	DI9 function selection	0	Extended
F2-09	DI10 function selection	0	Extended

The following table lists the functions available for the DI terminals.

Table 6-1 Functions of DI terminals

Value	Function	Description
0	No function	Set the reserved terminals to no function to avoid misoperation.
1	Forward RUN (FWD) or running command	The terminal is used to control forward or reverse running of the frequency inverter.

Value	Function	Description
2	Reverse RUN (REV) or the direction of FED/REV	
3	Three-line control	The terminal determines three-line control of the frequency inverter. For details, see the description of F2-11.
4	Forward JOG (FJOG)	FJOG indicates forward JOG running, while RJOG indicates reverse JOG running. The JOG frequency, acceleration time and deceleration time are described respectively in F6-00, F6-01 and F6-02.
5	Reverse JOG (RJOG)	
6	Multi-function terminal 1	The setting of 16 speeds or 16 other references can be implemented through combinations of 16 states of these four terminals. More details please refer the description of attached diagram 1.
7	Multi-function terminal 2	
8	Multi-function terminal 3	
9	Multi-function terminal 4	
10	Terminal UP	If the frequency is determined by external terminals, the terminals with the two functions are used as increment and decrement commands for frequency modification.
11	Terminal DOWN	When the frequency source is digital setting, they are used to adjust the frequency.
12	UP and DOWN setting clear (terminal, operation panel)	If the frequency source is digital setting, the terminal is used to clear the frequency modification by using the UP/DOWN function or the increment/decrement key on the operation panel, returning the set frequency to the value of F0-08.
13	Terminal 1 for acceleration/ deceleration time selection	Totally four groups of acceleration/deceleration time can be selected through combinations of two states of these two terminals. More details please refer the description of attached diagram 2.
14	Terminal 2 for acceleration/ deceleration time selection	
15	Frequency source switchover	The terminal is used to perform switchover between two frequency sources according to the setting in F0-14.
16	Switchover between main frequency source X and preset frequency	After this terminal becomes ON, the frequency source X is replaced by the preset frequency (F0-08).
17	Switchover between auxiliary frequency source Y and preset frequency	After this terminal is enabled, the frequency source Y is replaced by the preset frequency (F0-08).
18	Terminal 1 for running command source switchover	If the command source is set to terminal control (F0-01=1), this terminal is used to perform switchover between terminal control and operation panel control. If the command source is set to communication control (F0-01= 2), this terminal is used to perform switchover between communication control and operation panel control.
19	Terminal 2 for control command source switchover	It is used to perform switchover between terminal control and communication control. If the command source is terminal control, the system will switch over to communication control after this terminal becomes ON.

Value	Function	Description
20	Speed control/Torque control switchover	This terminal enables the frequency inverter to switch over between speed control and torque control. When this terminal becomes OFF, the frequency inverter runs in the mode set in d2-00. When this terminal becomes ON, the frequency inverter switches over to the other control mode.
21	Torque control prohibited	The inverter is prohibited from torque control and enters the speed control mode.
22	PID pause	PID is invalid temporarily. The frequency inverter maintains the present frequency output without supporting PID adjustment of frequency source.
23	PID integral pause	After this terminal becomes ON, the integral adjustment function pauses. However, the proportional and differentiation adjustment functions are still valid.
24	Reverse PID action direction	After this terminal becomes ON, the PID action direction is reversed to the direction set in Fb-04.
25	PID parameter switchover	If the PID parameters switchover performed by means of DI terminal (Fb-12 = 1). When the terminal becomes OFF, the PID parameters are Fb-06 ~Fb-08; when this terminal becomes ON, the PID parameters switch to Fb-09 ~Fb-11.
26	PLC status reset	The terminal is used to restore the original status of PLC control for the frequency inverter when PLC control is started again after a pause.
27	Swing pause	The frequency inverter outputs the central frequency, and the swing frequency function pauses.
28	Counter input	This terminal is used to count pulses.
29	Counter reset	This terminal is used to clear the counter status.
30	Length count input	This terminal is used to count the length.
31	Length reset	This terminal is used to clear the length.
32	Pulse input (enabled only for HDI)	HDI(DI5) is used for pulse input.
33	Frequency modification enabled	After this terminal becomes ON, the frequency inverter does not respond to any frequency modification until this terminal is valid.
34	Acceleration/Deceleration prohibited	It enables the frequency inverter to maintain the present frequency output without being affected by external signals (except the STOP command).
35	Reserved	Reserved
36	Reserved	Reserved.
37	Fault reset (RESET)	The terminal is used for fault reset function, the same as the function of RESET key on the operation panel. Remote fault reset is implemented by this function.
38	Normally open (NO) input of external fault	If this terminal becomes ON, the frequency inverter reports Err15 and performs the fault protection action. For more details, see the description of F8-32.
39	Normally closed (NC) input of external fault	After this terminal becomes ON, the frequency inverter reports Err15 and performs the fault protection action. For more details, see the description of F8-32.

Value	Function	Description
40	User-defined fault 1	If these two terminals become ON, the frequency inverter reports Err27 and Err28 respectively, and performs fault protection actions based on the setting in F8-33.
41	User-defined fault 2	
42	RUN pause	The frequency inverter decelerates to stop, but the running parameters are all memorized, such as PLC, swing frequency and PID parameters. After this function is disabled, the frequency inverter restore to its status before stop.
43	Free stop	The frequency inverter blocks its output, the motor free stop and is not controlled by the frequency inverter. It is the same as free stop described in F1-07.
44	Emergency stop	When this terminal becomes ON, the frequency inverter stops within the shortest time. During the stop process, the current remains at the set current upper limit. This function is used to satisfy the requirement of stopping the frequency inverter in emergency state.
45	External STOP terminal 1	In operation keypad mode, this terminal can be used to stop the frequency inverter, equivalent to the function of the STOP key on the operation keypad.
46	External STOP terminal 2	In any control mode (operation panel, terminal or communication), it can be used to make the frequency inverter decelerate to stop. In this case, the deceleration time is fixed to deceleration time 4.
47	Immediate DC braking	After this terminal becomes ON, the frequency inverter directly switches over to the DC braking state.
48	Deceleration DC braking	When this terminal becomes ON, the frequency inverter decelerates to the initial frequency of DC braking and then switches over to DC braking state.
49	Clear the current running time	When this terminal becomes ON, the frequency inverter's current running time is cleared. This function must be supported by Fb-10 and Fb-13.

The four multi-function terminals have 16 state combinations, corresponding to 16 reference values, as listed in the following table.

K4	K3	K2	K1	Reference Setting	Corresponding Parameter
OFF	OFF	OFF	OFF	Reference 0	FC-00
OFF	OFF	OFF	ON	Reference 1	FC-01
OFF	OFF	ON	OFF	Reference 2	FC-02
OFF	OFF	ON	ON	Reference 3	FC-03
OFF	ON	OFF	OFF	Reference 4	FC-04
OFF	ON	OFF	ON	Reference 5	FC-05
OFF	ON	ON	OFF	Reference 6	FC-06
OFF	ON	ON	ON	Reference 7	FC-07
ON	OFF	OFF	OFF	Reference 8	FC-08
ON	OFF	OFF	ON	Reference 9	FC-09
ON	OFF	ON	OFF	Reference 10	FC-10
ON	OFF	ON	ON	Reference 11	FC-11
ON	ON	OFF	OFF	Reference 12	FC-12
ON	ON	OFF	ON	Reference 13	FC-13

ON	ON	ON	OFF	Reference 14	FC-14
ON	ON	ON	ON	Reference 15	FC-15

If the frequency source is multi-function, the value 100% of FC-00~ FC-15 corresponds to the value of F0-03 (Maximum frequency).

Besides as the multi-speed function, the multi-function can be also used as the PID setting source or the voltage source for V/F separation, satisfying the requirement on switchover of different setting values.

Table 6-2 Function description of Acceleration/Deceleration time selection terminals

Terminal 2	Terminal 1	Acceleration/Deceleration Time	Corresponding
OFF	OFF	Acceleration/Deceleration time 1	F0-20, F0-21
OFF	ON	Acceleration/Deceleration time 2	F0-22, F0-23
ON	OFF	Acceleration/Deceleration time 3	F0-24, F0-25
ON	ON	Acceleration/Deceleration time 4	F0-26, F0-27

Function Code	Parameter Name	Setting Range	Default
F2-10	DI filter time	0.000s~1.000s	0.010s

It is used to set the software filter time of DI terminal status. If DI terminals are liable to interference then may cause malfunction, increase the value of this parameter to enhance the anti-interference capability. However, increase of DI filter time will slow down the response of DI terminals.

Function Code	Parameter Name	Setting Range	Default
F2-11	Terminal command mode	0: Two-line mode 1 1: Two-line mode 2 2: Three-line mode 1 3: Three-line mode 2	0

This parameter is used to select different four modes to control the inverter by external terminals. For the convenience of description, the following sample is adopted by the DI1, DI2 and DI3 among DI1 to DI10, these three terminals are used as external terminals, that is, the functions of DI1, DI2 and DI3 is set by the value of F2-00 to F2-02.


- 0: Two-line mode 1

It is the most commonly used two-line mode, the forward/reverse rotation of the motor is determined by DI1 and DI2. The parameters are set as below:

Function Code	Parameter Name	Value	Function Description
F2-11	Terminal command mode	0	Two-line 1
F2-00	DI1 function selection	1	Forward RUN (FWD)
F2-01	DI2 function selection	2	Reverse RUN (REV)

Figure 6-7 setting of two-line mode 1

K1	K2	Running direction
1	0	Forward RUN
0	1	Reverse RUN
0	0	Stop
1	1	Stop



Refer above figure, when only K1 is ON, the frequency inverter instructs forward rotation. When only K2 is ON, the frequency inverter instructs reverse rotation. When K1 and K2 are ON or OFF simultaneously,

the frequency inverter stops.


- 1: Two-line mode 2

In this mode, DI1 is RUN enabled terminal, and DI2 determines the running direction. The parameters are set as below:

Function Code	Parameter Name	Value	Function Description
F2-11	Terminal command mode	1	Two-line 2
F2-00	DI1 function selection	1	RUN enabled
F2-01	DI2 function selection	2	Forward or reverse

Figure 6-8 Setting of two-line mode 2

K1	K2	Running direction
1	0	Forward RUN
1	1	Reverse RUN
0	0	Stop
0	1	Stop




As shown in the preceding figure, if K1 is ON, the frequency inverter instructs forward rotation when K2 is OFF, and instructs reverse rotation when K2 is ON. If K1 is OFF, K2 is ON or both K1 and K2 are OFF, the Frequency inverter stops.

- 2: Three-line mode 1

In this mode, DI3 is RUN enabled terminal, and the direction is decided by DI1 and DI2. The parameters are set as below:

Function Code	Parameter Name	Value	Function Description
F2-11	Terminal command mode	2	Three-line 1
F2-00	DI1 function selection	1	Forward RUN (FWD)
F2-01	DI2 function selection	2	Reverse RUN (REV)
F3-02	DI3 function selection	3	Three-line control

Figure 6-9 Setting of three-line mode 1



As shown in the preceding figure, if SB1 is ON, the frequency inverter instructs forward rotation when SB2 is pressed to be ON, and instructs reverse rotation when SB3 is pressed to be ON. The frequency inverter stops immediately after SB1 becomes OFF. During normal startup and running, SB1 must remain ON. The frequency inverter's running state is determined by the final actions on SB1, SB2 and


SB3.

- 3: Three-line mode 2

In this mode, DI3 is RUN enabled terminal. The RUN command is given by DI1 and the direction is decided by DI2. The parameters are set as below:

Function Code	Parameter Name	Value	Function Description
F2-11	Terminal command mode	3	Three-line 2
F2-00	DI1 function selection	1	RUN enabled
F2-01	DI2 function selection	2	Forward or reverse direction
F2-02	DI3 function selection	3	Three-line control

Figure 6-10 Setting of three-line mode 2



As shown in the preceding figure, if SB1 is ON, the frequency inverter starts running when SB2 is pressed to be ON; the frequency inverter instructs forward rotation when K is OFF and instructs reverse rotation when K is ON. The Frequency inverter stops immediately after SB1 becomes OFF. During normal startup and running, SB1 must remain ON, SB2 is effective immediately after ON action.

Function Code	Parameter Name	Setting Range	Default
F2-12	Terminal UP/DOWN ratio	0.001Hz/s~65.535 Hz/s	1.000Hz/s

It is used to adjust the ratio of changing of frequency for per second when the frequency is adjusted by means of terminal UP/DOWN.

- If b0-11 (Frequency reference resolution) is 2, the setting range is 0.001Hz/s~65.535 Hz/s.
- If b0-11 (Frequency reference resolution) is 1, the setting range is 0.01Hz/s~655.35 Hz/s.

Function Code	Parameter Name	Setting Range	Default
F2-13	DI1 ON delay time	0.0s~3000.0s	0.0s
F2-14	DI1 OFF delay time	0.0s~3000.0s	0.0s
F2-15	DI2 ON delay time	0.0s~3000.0s	0.0s
F2-16	DI2 OFF delay time	0.0s~3000.0s	0.0s
F2-17	DI3 ON delay time	0.0s~3000.0s	0.0s
F2-18	DI3 OFF delay time	0.0s~3000.0s	0.0s

These parameters are used to set the delay time of the frequency inverter when the status of DI terminals changes.

The DI1 to DI3 support the delay time function.

Function Code	Parameter Name	Setting Range	Default
F2-19	DI valid selection 1	Unit's digit (DI1 valid mode)	00000
		0: Low level valid	
		1: High level valid	
		Ten's digit (DI2 valid mode)	
		0, 1 (same as DI1)	
		Hundred's digit (DI3 valid mode)	
		0, 1 (same as DI1)	
		Thousand's digit (DI4 valid mode)	
		0, 1 (same as DI1)	
		Ten thousand's digit (HDI valid mode)	
F2-20	DI valid selection 2	0, 1 (same as DI1)	00000
		Unit's digit (DI6 valid mode)	
		0, 1 (same as DI1)	
		Ten's digit (DI7 valid mode)	
		0, 1 (same as DI1)	
		Hundred's digit (DI8 state)	
		0, 1 (same as DI1)	
		Thousand's digit (DI9 valid mode)	
		0, 1 (same as DI1)	
		Ten thousand's digit (DI10 valid mode)	

These parameters are used to set the valid mode of DI terminals.

- 0: Low level valid

The DI terminal is valid when being connected with COM, and invalid when being disconnected from COM.

- 1: High level valid

The DI terminal is invalid when being connected with COM, and valid when being disconnected from COM.

6.4 Group F3: Pulse/Analog input terminals

Function Code	Parameter Name	Setting Range	Default
F3-00	AI curve 1 minimum input	0.00 V~F3-02	0.01 V
F3-01	Corresponding setting of AI curve 1 minimum input	-100.0%~100.0%	0.0%
F3-02	AI curve 1 maximum input	F3-00~10.00V	10.00V
F3-03	Corresponding setting of AI curve 1 maximum input	-100.0%~100.0%	100.0%

These parameters are used to define the relationship between the analog input voltage and the corresponding setting value.

When the analog input voltage is larger than the setting value of maximum input F3-02, the analog voltage is according to maximum input to calculate; In the same way, when the analog input voltage is less than the setting value of minimum input F3-00, then the analog voltage is calculated according to minimum input setting by F3-01 or 0.0%.

When the analog input is current input, 1 mA current corresponds to 0.5 Volts.


AI1 filter time is used to set the software filter time of AI1. If the analog input is liable to interference, increase the value of this parameter to stabilize the detected analog input. However, increase of the AI

filter time will slow down the response of analog detection. Set this parameter properly based on actual conditions.

In different applications, 100% of analog input corresponds to different nominal values. For details, refer to the description of different applications.

Function Code	Parameter Name	Setting Range	Default
F3-04	AI curve 2 minimum input	0.00 V~F3-06	0.01 V
F3-05	Corresponding setting of AI curve 2 minimum input	-100.0%~100.0%	0.0%
F3-06	AI curve 2 maximum input	F3-04~10.00V	10.00V
F3-07	Corresponding setting of AI curve 2 maximum input	-100.0%~100.0%	100.0%

Figure 6-11 Corresponding relation between analog giving and setting value



Function Code	Parameter Name	Setting Range	Default
F3-08	AI curve 3 minimum input	0.00 V~F3-10	0.01 V
F3-09	Corresponding setting of AI curve 3 minimum input	-100.0%~100.0%	0.0%
F3-10	AI curve 3 maximum input	F3-08~10.00V	10.00V
F3-11	Corresponding setting of AI curve 3 maximum input	-100.0%~100.0%	100.0%


For the setting method of AI curve 2 and AI curve 3, please refer to AI curve 1.

Function Code	Parameter Name	Setting Range	Default
F3-12	AI curve 4 minimum input	0.00 V~F3-14	0.01 V
F3-13	Corresponding setting of AI curve 4 minimum input	-100.0%~100.0%	0.0%
F3-14	AI curve 4 first point input	F3-12~F3-16	3.33V
F3-15	Corresponding setting of AI4first point input	-100.0%~100.0%	33.3%
F3-16	AI curve 4 second point input	F3-14~F3-18	6.67V
F3-17	Corresponding setting of AI4second point input	-100.0%~100.0%	6.67%

Function Code	Parameter Name	Setting Range	Default
F3-18	AI4 maximum input	F3-16~10.00V	10.00V
F3-19	Corresponding setting of AI4 maximum input	-100.0%~100.0%	100.0%
F3-20	AI curve 5 minimum input	0.00 V~F3-22	0.01 V
F3-21	Corresponding setting of AI curve 5 minimum input	-100.0%~100.0%	0.0%
F3-22	AI curve 5first point input	F3-20~F3-24	3.33V
F3-23	Corresponding setting of AI5first point input	-100.0%~100.0%	33.3%
F3-24	AI curve 5second point input	F3-22~F3-26	6.67V
F3-25	Corresponding setting of AI5second point input	-100.0%~100.0%	6.67%
F3-26	AI5 maximum input	F3-24~10.00V	10.00V
F3-27	Corresponding setting of AI5 maximum input	-100.0%~100.0%	100.0%

The function of AI curve 4 and 5 is similar with AI curve 1 to AI curve 3. Curve 1 to curve 3 is a straight line, but curve 4 and 5 are two curves with 4 points, can implement more flexible corresponding relationship. Please refer the diagram for curve 4 and 5.

Figure 6-12 diagram of AI curve 4 and curve 5



Note that when setting curve 4 and 5, the minimum voltage, inflexion 1 voltage, inflexion 2 voltage and maximum voltage need to increase in sequence.

F3-32 is used to select the pulse input AI1to AI3 among the five curves.

Function Code	Parameter Name	Setting Range	Default
F3-28	Pulse minimum input	0.00 kHz~F3-30	0.00 kHz
F3-29	Corresponding setting of pulse minimum input	-100.00%~100.0%	0.0%
F3-30	Pulse maximum input	F3-28~100.00 kHz	50.00 kHz
F3-31	Corresponding setting of pulse maximum input	-100.00%~100.0%	100.0%

These parameters are used to set the relationship between HDI pulse input and corresponding settings.

The pulses can only be input by HDI. The method of setting this function is similar to that of setting AI1 or AI2 function. Refer the description of diagram 6-11.

Function Code	Parameter Name	Setting Range	Default
F3-32	AI curve setting	Unit's digit(AI curve 1 selection)	321
		1: curve 1; 2: curve 2; 3: curve 3; 4: curve 4; 5: curve 5	
		Ten's digit(AI curve 2 selection)	
		1-5(same as AI curve 1)	
		Hundred's digit(AI curve 2 selection)	
		1-5(same as AI curve 1)	

The unit's digit, ten's digit and hundred's digit of this parameter is used to select the corresponding curve of AI1, AI2 and AI3. These three analog input signals can separately select one of 5 curves.

There are only two points curve of curve 1, curve 2 and curve 3, while curve 4 and 5 have 4 points.

The inverter supports 2 ways of standard analog input signal, so using AI3 needs to add extension card.

Function Code	Parameter Name	Setting Range	Default
F3-33	AI curve lower than minimum input	Unit's digit(AI curve 1 lower limit selection)	000
		0: minimum input; 1: 0.0%	
		Ten's digit(AI curve 2 lower limit selection)	
		0, 1(same as AI1)	
		Hundred's digit(AI curve 3 lower limit selection)	
		0, 1(same as AI1)	

This parameter is used to confirm the corresponding setting of analog input when the analog input voltage is lower than minimum input.

The unit's digit, ten's digit and hundred's digit of this parameter is corresponding to analog input of AI1, AI2 and AI3.

If it is set to 0, then the corresponding setting of analog input is the corresponding setting of minimum input to AI curve.

If this parameter is set to 1, then when AI input is lower than minimum input, the corresponding setting of analog is 0.0%.

Function Code	Parameter Name	Setting Range	Default
F3-34	AI1 filter time	0.00s ~ 10.00s	0.10s
F3-35	AI2 filter time	0.00s ~ 10.00s	0.10s
F3-36	AI3 filter time	0.00s ~ 10.00s	0.10s
F3-37	Pulse filter time	0.00s ~ 10.00s	0.10s
F3-38	AI1 input voltage lower limit	0.00 V ~ F3-39	0.00 V

Function Code	Parameter Name	Setting Range	Default
F3-39	AI1 input voltage upper limit	F3-38 ~ 10.00 V	10.00 V

When the AI1 input is larger than the value of F3-39 or smaller than the value of F3-38, the corresponding DO becomes ON, indicating that AI1 input exceeds the limit.

Function Code	Parameter Name	Setting Range	Default
F3-40	Jump point of AI1 input corresponding setting	-100.0%~100.0%	0.0%
F3-41	Jump amplitude of AI1 input corresponding setting	0.0%~100.0%	0.0%
F3-42	Jump point of AI2 input corresponding setting	-100.0%~100.0%	0.0%
F3-43	Jump amplitude of AI2 input corresponding setting	0.0%~100.0%	0.0%
F3-44	Jump point of AI3 input corresponding setting	-100.0%~100.0%	0.0%
F3-45	Jump amplitude of AI3 input corresponding setting	0.0%~100.0%	0.0%
F3-46	Minimum input value of AI-KB	0.00V ~ 10.00V	0.50V
F3-47	Maximum input value of AI-KB	0.50V ~10.00V	9.50V
F3-48	AI-KB filter time	0.00s~10.00s	1.00s

AI1/AI2/AI3 filter time is used to set the software filter time of AI1/AI2/AI3. If the analog input is liable to interference, increase the value of this parameter to stabilize the detected analog input. However, increase of the AI filter time will slow down the response of analog detection. Set this parameter properly based on actual conditions.

The AI terminals (AI1 to AI3) of FC155 all support the corresponding setting jump function, which fixes the AI input corresponding setting at the jump point when AI input corresponding setting jumps around the jump range.

For example:

AI1 input voltage fluctuation around 6.00V and the amplitude range is 5.90V~6.10V. AI1 minimum input 0.00V corresponds to 0.00% and maximum input 10.00V corresponds to 100.0%. The detected AI1 input corresponding setting varies between 59.0% and 61.0%.

If you set jump point F3-36 to 60.0% and jump amplitude F3-37 to 1.0%, then frequency inverter obtained AI1 input corresponding setting is fixed to 60.0%, eliminating the fluctuation effect.

6.5 Group F4: Output Terminals

FC155 provides 2 analog output (AO) terminals, a digital output (DO) terminal, a relay terminal and a FM terminal (used for high-speed pulse output or open-collector switch signal output) as standard. If these output terminals cannot satisfy site requirements, use an optional I/O extension card.

Function Code	Parameter Name	Setting Range	Default
F4-00	FM terminal output mode	0: Pulse signal output (FMP) 1: Switch signal output (FMR)	1

The FM terminal is programmable multiplexing terminal. It can be used for high-speed pulse output (FMP), with maximum frequency of 100.00 kHz. Refer to F5-00 for relevant functions of FMP. It can also be used as open collector switch signal output (FMR).

Function Code	Parameter Name	Default
F4-01	FMR functionselection (open-collector output terminal)	0
F4-02	Relay 1 functionselection (TA-TB-TC)	3
F4-03	Relay 2 functionselection (Extension card)	0
F4-04	DO1 function selection (open-collector output terminal)	1
F4-05	DO2 function(Extension card)	0

These five parameters are used to select the functions of the five digital output terminals. TA-TB-TC and P/A-P/B-P/C are respectively the relays on the control board and the extension card.

The functions of the output terminals are described in the following table.

Value	Function	Description
0	No output	The terminal has no function.
1	Ready for RUN	If the frequency inverter main circuit and control circuit become stable, and the frequency inverter detects no fault and is ready for RUN, the terminal becomes ON.
2	Frequency inverter running	When the frequency inverter is running and has output frequency (can be zero), the terminal becomes ON.
3	Fault output (stop)	When the frequency inverter stops due to a fault, the terminal becomes ON.
4	Fault output(free stop fault, no output at under-voltage)	
5	Frequency limited	If the set frequency exceeds the frequency upper limit or lower limit and the output frequency of the frequency inverter reaches the upper limit or lower limit, the terminal becomes ON.
6	Torque limited	In speed control mode, if the output torque reaches the torque limit, the frequency inverter enters the stall protection state and meanwhile the terminal becomes ON.
7	Frequency upper limit reached	If the running frequency reaches the upper limit, the terminal becomes ON.
8	Frequency lower limit reached 1(no output at stop)	If the running frequency reaches the lower limit, the terminal becomes ON. In the stop state, the terminal becomes OFF.
9	Frequency lower limit reached 2(having output at stop)	If the running frequency reaches the lower limit, the terminal becomes ON. In the stop state, the signal is still ON.
10	Reverse running	If the frequency inverter is in the reverse running state, the terminal becomes ON.
11	Zero-speed running (no output at stop)	If the frequency inverter runs with the output frequency of 0, the terminal becomes ON. If the frequency inverter is in the stop state, the terminal becomes OFF.
12	Zero-speed running 2 (having output at stop)	If the output frequency of the frequency inverter is 0, the terminal becomes ON. In the state of stop, the signal is still ON.
13	Set count value reached	The terminal becomes ON when the count value reaches the value set in Fd-08.
14	Designated count value reached	The terminal becomes ON when the count value reaches the value set in Fd-09.

Value	Function	Description
15	Length reached	The terminal becomes ON when the detected actual length exceeds the value set in Fd-05.
16	PLC cycle complete	When simple PLC completes one cycle, the terminal outputs a pulse signal with width of 250ms.
17	Frequency-level detection FDT1 output	Refer to the descriptions of F4-17 and F4-18.
18	Frequency level detection FDT2 output	Refer to the descriptions of F4-19 and F4-20.
19	Frequency reached	Refer to the descriptions of F4-21.
20	Frequency 1 reached	Refer to the descriptions of F4-22 and F4-23.
21	Frequency 2 reached	Refer to the descriptions of F4-24 and F4-25.
22	Current 1 reached	Refer to the descriptions of F4-30 and F4-31.
23	Current 2 reached	Refer to the descriptions of F4-32 and F4-33.
24	Module temperature reached	If the heatsink temperature of the inverter module (F7-14) reaches the set module temperature threshold (F4-34), the terminal becomes ON.
25	Timing reached	If the timing function (F6-10=1) is valid, the terminal becomes ON after the present running time of the frequency inverter reaches the set time.
26	Zero current state	Refer to the descriptions of F4-26 and F4-27.
27	Output current limit exceeded	Refer to the descriptions of F4-28 and F4-29.
28	Lower voltage state output	If the frequency inverter is in lower voltage state, the terminal becomes ON.
29	Frequency inverter overload pre-warning	10 seconds before this protection action performs, the terminal becomes ON.
30	Motor overheat warning	If the motor temperature reaches the temperature set in F8-30 (Motor overheat warning threshold), the terminal becomes ON. You can view the motor temperature by using F9-34.
31	Motor overload pre-warning	The frequency inverter judges motor overload according to preset motor overload threshold, and terminal becomes ON. The overload threshold setting refer to F8-01~F8-03.
32	Off load	If the load becomes 0, the terminal becomes ON.
33	AI1 larger than AI2	When the input of AI1 is larger than the input of AI2, the terminal becomes ON.
34	AI1 input limit exceeded	If AI1 input is larger than the value of F3-34 (AI1 input voltage upper limit) or lower than the value of F3-33 (AI1 input voltage lower limit), the terminal becomes ON.
35	Alarm output	If a fault occurs on the frequency inverter and the frequency inverter continues to run, the terminal outputs the alarm signal.
36	This time running time reached	If the current running time of frequency inverter exceeds the value of F6-13, the terminal becomes ON.
37	Accumulative power- on time reached	If the frequency inverter accumulative power-on time (F7-15) exceeds the value set in F6-03, the terminal becomes ON.

Value	Function	Description
38	Accumulative running time reached	If the accumulative running time F7-16 of the frequency inverter exceeds the time set in F6-04, the terminal becomes ON.

Function Code	Parameter Name	Setting Range	Default
F4-06	FMR ON delay time	0.0s~3000.0s	0.0s
F4-07	FMR OFF delay time	0.0s~3000.0s	0.0s
F4-08	Relay 1 ON delay time	0.0s~3000.0s	0.0s
F4-09	Relay 1 OFF delay time	0.0s~3000.0s	0.0s
F4-10	Relay 2 ON delay time	0.0s~3000.0s	0.0s
F4-11	Relay 2 OFF delay time	0.0s~3000.0s	0.0s
F4-12	DO1 ON delay time	0.0s~3000.0s	0.0s
F4-13	DO1 OFF delay time	0.0s~3000.0s	0.0s
F4-14	DO2 ON delay time	0.0s~3000.0s	0.0s
F4-15	DO2 OFF delay time	0.0s~3000.0s	0.0s

Function Code	Parameter Name	Setting Range	Default
F4-16	DO valid mode selection	Unit's digit (FMR valid mode)	00000
		0: Positive logic 1: Negative logic	
		Ten's digit (Relay 1 valid mode)	
		0, 1 (same as FMR)	
		Hundred's digit (Relay 2 valid mode)	
		0, 1 (same as FMR)	
		Thousand's digit (DO1 valid mode)	
		0, 1 (same as FMR)	
		Ten thousand's digit (DO2 valid mode)	
		0, 1 (same as FMR)	

These parameters are used to set the delay time of output terminals FMR, relay1, relay2,DO1 and DO2 from status change to actual output.

- 0: Positive logic

The output terminal is valid when being connected with COM, and invalid when being disconnected from COM.

- 1: Positive logic

The output terminal is invalid when being connected with COM, and valid when being disconnected from COM.


Function Code	Parameter Name	Setting Range	Default
F4-17	Frequency detection value 1(FDT1 level)	0.00 Hz ~ maximum frequency	50.00 Hz
F4-18	Frequency detection hysteresis(FDT 1)	0.0%~100.0% (FDT1 level)	5.0%

If the running frequency is higher than the value of F4-17, the corresponding DO terminal becomes ON.

If the running frequency is lower than value of F4-17, the DO terminal goes OFF.

These two parameters are respectively used to set the detection value of output frequency and hysteresis value of cancellation of the output. The value of F4-18 is a percentage of the hysteresis frequency to the frequency detection value (F4-17). The FDT function is shown in the following figure.

Figure 6-13 FDT level



Function Code	Parameter Name	Setting Range	Default
F4-19	Frequency detection value 2 (FDT2 level)	0.00 ~ maximum frequency	50.00 Hz
F4-20	Frequency detection hysteresis 2 (FDT 2 level)	0.0%~100.0% (FDT2 level)	5.0%


The frequency detection function is the same as FDT1 function. For details, refer to the descriptions of F4-17 and F4-18.

Function Code	Parameter Name	Setting Range	Default
F4-21	Detection range of frequency reached	0.00~100% (maximum frequency)	3.0%

If the frequency inverter running frequency is within the certain range of the set frequency, the corresponding DO terminal becomes ON.

This parameter is used to set the range within which the output frequency is detected to reach the set frequency. The value of this parameter is a percentage relative to the maximum frequency. The detection range of frequency reached is shown in the following figure.

Figure 6-14 Detection range of frequency reached




Function Code	Parameter Name	Setting Range	Default
F4-22	Any frequency reaching detection value 1	0.00 Hz ~ maximum frequency	50.00 Hz
F4-23	Any frequency reaching detection amplitude 1	0.0%~100.0% (maximum frequency)	3.0%

F4-24	Any frequency reaching detection value 2	0.00 Hz ~ maximum frequency	50.00 Hz
F4-25	Any frequency reaching detection amplitude 2	0.0%~100.0% (maximum frequency)	3.0%

If the output frequency of the frequency inverter is within the positive and negative amplitudes of the any frequency reaching detection value, the corresponding DO becomes ON.

FC155 provides two groups of any frequency reaching detection parameters, including frequency detection value and detection amplitude, as shown in the following figure.


Figure 6-15 Any frequency reaching detection



Function Code	Parameter Name	Setting Range	Default
F4-26	Zero current detection level	0.0%~100.0% (rated motor current)	5.0%
F4-27	Zero current detection delay time	0.00s~600.00s	0.10s

If the output current of the frequency inverter is equal to or less than the zero current detection level and the duration exceeds the zero current detection delay time, the corresponding DO becomes ON. The zero current detection is shown in the following figure.


Figure 6-16 Zero current detection



Function Code	Parameter Name	Setting Range	Default
F4-28	Output over current threshold	0.0% (no detection) 0.1%~300.0% (rated motor current)	200.0%
F4-29	Overcurrent detection delay time	0.00s~600.00s	0.10s

If the output current of the frequency inverter is equal to or higher than the over current threshold and the duration exceeds the detection delay time, the corresponding DO becomes ON. The output over current detection function is shown in the following figure.

Figure 6-17 Output over current detection




Function Code	Parameter Name	Setting Range	Default
F4-30	Any current reaching 1	0.0%~100.0% (rated motor current)	100.0%
F4-31	Amplitude of any current reaching 1	0.0%~100.0% (rated motor current)	3.0%
F4-32	Any current reaching 2	0.0%~100.0% (rated motor current)	100.0%
F4-33	Amplitude of any current reaching 2	0.0%~100.0% (rated motor current)	3.0%

If the output current of the frequency inverter is within the positive and negative amplitudes of any current reaching detection value, the corresponding DO becomes ON.

FC155 provides two groups of any current reaching detection parameters, including current detection value and detection amplitudes, as shown in the following figure.

Figure 6-18 Any current reaching detection



Function Code	Parameter Name	Setting Range	Default
F4-34	IGBT Module temperature threshold	25°C ~100°C	75°C

When the heatsink temperature of the frequency inverter reaches the value of this parameter, the corresponding DO becomes ON, indicating that the IGBT module temperature reaches the threshold.

6.6 Group F5: Pulse/analog output terminals

Function Code	Parameter Name	Default
F5-00	FMP function selection(Pulse output terminal)	0
F5-01	AO1 function selection	0
F5-02	AO2 function selection	1

The output pulse frequency of the FMP terminal ranges from 0.01 kHz to "Maximum FMP output frequency" (F5-03). The value of F5-03 is between 0.01 kHz and 100.00 kHz.

The output range of AO1 and AO2 is 0V~10V or 0mA~20mA. The relationship between pulse and analog output ranges and corresponding functions is listed in the following table.

Value	Function	Range (Corresponding to Pulse or Analog Output Range 0.0%~100.0%)
0	Running frequency	0Hz~ maximum frequency
1	Set frequency	0Hz~ maximum frequency
2	Output current	0 ~2 times of rated motor current
3	Output torque (absolute value)	0~ 2 times of rated motor torque (absolute value of torque)
4	Output power	0 ~2 times of rated power
5	Output voltage	0 ~1.2 times of rated frequency inverter DC bus voltage
6	Motor rotational speed	0~rotational speed corresponding to maximum frequency
7	Output current	0.0A~1000.0 A
8	Output voltage	0.0V~000.0 V
9	Output torque (actual value)	-200% of rated motor torque~ 200% of rated motor torque
10	Pulse input	0.01 kHz ~100.00 kHz
11	AI1	0V~10 V
12	AI2	0V~10 V
13	AI3	0V~10 V
14	Length	0~ maximum set length
15	Count value	0 ~ maximum count value
16	Communication setting	0~32767

Function Code	Parameter Name	Setting Range	Default
F5-03	Maximum FMP output frequency	0.01 kHz ~100.00 kHz	50.00 kHz

If the FM terminal is used for pulse output, this parameter is used to set the maximum frequency of pulse output.

Function Code	Parameter Name	Setting Range	Default
F5-04	AO1 zero offset coefficient	-100.0%~100.0%	0.0%
F5-05	AO1 gain	-10.00~10.00	1.00
F5-06	AO2 zero offset coefficient	-100.0%~100.0%	0.00%
F5-07	AO2 gain	-10.00~10.00	1.00

These parameters are used to correct the zero drift of analog output and the output amplitude deviation. They can also be used to define the required AO curve. If "b" represents zero offset, "k" represents gain,

"Y" represents actual output, and "X" represents standard output, the actual output is: $Y = kX + b$. The zero offset coefficient 100% of AO1 and AO2 corresponds to 10 V (or 20 mA). The standard output refers to the value corresponding to the analog output of 0 to 10 V (or 0 to 20 mA) with no zero offset or gain adjustment.

For example, if the analog output is used as the running frequency, and it is expected that the output is 8 V when the frequency is 0 and 3 V at the maximum frequency, the gain shall be set to -0.50, and the zero offset shall be set to 80%.

6.7 Group F6: Auxiliary Functions

Function Code	Parameter Name	Setting Range	Default
F6-00	JOG running frequency	0.00 Hz ~ maximum frequency	6.00 Hz
F6-01	JOG acceleration time	0.01s~65000s	10.0s
F6-02	JOG deceleration time	0.01s~65000s	10.0s

These parameters are used to define the set frequency and acceleration/deceleration time of the frequency inverter when jogging. The startup mode is fixed as "Direct start" (F1-00 = 0) and the stop mode is fixed as "Decelerate to stop" (F1-07 = 0) during jogging.

Function Code	Parameter Name	Setting Range	Default
F6-03	Accumulative power-on time reach	0h~65000 h	0 h

If the accumulative power-on time (F7-15) reaches the value set in this parameter, the corresponding DO terminal output ON signal.

Function Code	Parameter Name	Setting Range	Default
F6-04	Accumulative running time reach threshold	0h~65000 h	0 h

It is used to set the accumulative running time threshold of the Frequency inverter. If the accumulative running time (F7-16) reaches the value set in this parameter, the corresponding DO terminal becomes ON.

Function Code	Parameter Name	Setting Range	Default
F6-05	Action after running time reached	0: Continue to run 1: Stop	0 h

This function is used to define the action after F6-04 preset time reached. Setting 0 inverter will continue work after present running time reached; and set 1, the inverter will stop.

Function Code	Parameter Name	Setting Range	Default
F6-06	Dormant frequency	0.0Hz~Wakeup frequency (F6-08)	0.00 Hz
F6-07	Dormant delay time	0.0s~6000.0s	0.0s
F6-08	Wakeup frequency	Dormant frequency (F6-06) ~ Maximum frequency(F0-03)	0.00 Hz
F6-09	Wakeup delay time	0.0s~6000.0s	0.0s

These parameters are used to implement the dormant and wakeup functions in the water supply application.

When the frequency inverter is in running state, the frequency inverter enters the dormant state and stops automatically after the dormant delay time (F6-07) if the set frequency is lower than or equal to the dormant frequency (F6-06).

When the frequency inverter is in dormant state and the present running command is effective, the frequency inverter starts up after the wakeup delay time (F6-09) if the set frequency is higher than or equal to the wakeup frequency (F6-08).

Generally, set the wakeup frequency should be equal to or higher than the dormant frequency. If the wakeup frequency and dormant frequency are set to 0, the dormant and wakeup functions are disabled. When the dormant function is enabled, if the frequency source is PID, whether PID operation is performed in the dormant state is determined by Fb-27. In this case, select PID operation enabled in the stop state (Fb-27 = 1).

Function Code	Parameter Name	Setting Range	Default
F6-10	Timing function	0: Disabled 1: Enabled	0
F6-11	Timing duration source	0: F6-12 1: AI1 2: AI2 3: AI3 (100% of analog input corresponds to the value of F6-12)	0
F6-12	Timing duration	0.0min~6500.0 min	0.0min

These parameters are used to implement the frequency inverter timing function.

If F6-10 is set to 1, the frequency inverter starts to time at startup. When the set timing duration reached, the frequency inverter stops automatically, and meanwhile the corresponding DO outputs ON signal. The frequency inverter starts timing from 0.0min each time it starts up and the remaining timing duration can be checked by F9-29.

The timing duration is set in F6-11 and F6-12, in unit of minute.

Function Code	Parameter Name	Setting Range	Default
F6-13	This-time running time reachthreshold	0.0min~6500.0 min	0.0 min

If the present running time reaches the value set in this parameter, the corresponding DO outputs ON signal, indicating that present running time is reached.

Function Code	Parameter Name	Setting Range	Default
F6-14	Cooling fan control	0: Fan working during running 1: Fan working during power on	0

It is used to set the working mode of the cooling fan. If this parameter is set to 0, the fan works when the frequency inverter is in running state. When the frequency inverter stops, the cooling fan works if the heatsink temperature is higher than 40°C, and stops working if the heatsink temperature is lower than 40°C.

If this parameter is set to 1, the cooling fan keeps working after power-on.

Function Code	Parameter Name	Setting Range	Default
F6-15	Startup protection	0: No 1: Yes	0

This parameter is used to enable the frequency inverter safety protection. If it is set to 1, the frequency inverter does not respond to the run command after power-on (for example, an input terminal is ON before power-on). The frequency inverter responds only after the run command is cancelled and becomes valid again.

In addition, the frequency inverter does not respond to the run command valid from fault reset of the frequency inverter. The run protection can be disabled only after the run command is cancelled one time.


In this way, the motor will not automatically startup to avoid unexpected dangerous conditions for these startup commands from power-on and fault reset.

Function Code	Parameter Name	Setting Range	Default
F6-16	Jump frequency 1	0.00 Hz ~ maximum frequency	0.00 Hz
F6-17	Jump frequency 2	0.00 Hz ~ maximum frequency	0.00 Hz
F6-18	Frequency jump amplitude	0.00 Hz ~ maximum frequency	0.00 Hz

If the setting frequency is within the jump frequency range, the actual running frequency is the jump frequency close to the set frequency. Setting the jump frequency helps to avoid the mechanical resonance point of the load.

FC155 supports two jump frequencies. If both are set to 0, the frequency jump function is disabled. The principle of the jump frequencies and jump amplitude is shown in the following figure 6-19.

Figure 6-19 Principle of the jump frequencies and jump amplitude




Function Code	Parameter Name	Setting Range	Default
F6-19	Jump frequency during acceleration /deceleration	0: Disabled 1: Enabled	0

It is used to set whether the jump frequencies are valid during acceleration/deceleration.

When the jump frequencies are valid during acceleration/deceleration, and the running frequency is within the frequency jump range, the actual running frequency will jump over the set frequency jump amplitude (rise directly from the lowest jump frequency to the highest jump frequency). The following figure shows the diagram when the jump frequencies are valid during acceleration/deceleration.

Figure 6-20 Diagrams when the jump frequencies are valid during acceleration/deceleration



Function Code	Parameter Name	Setting Range	Default
F6-20	Droop control	0.01~10.00 Hz	0.00 Hz

This function is used for balancing the workload allocation when multiple motors are used to drive the same load. The output frequency of the frequency inverters decreases as the load increases. You can reduce the workload of the motor under load by decreasing the output frequency for this motor, implementing workload balancing among multiple motors.

6.8 Group F7: Display Setting

Function Code	Parameter Name	Setting Range	Default
F7-00	LED display running parameters 1	Unit's digit (set frequency, unit: Hz)	11101
		0: Display 1: No display	
		Ten's digit (running frequency, unit :Hz)	
		0, 1 (same as unit's digit)	
		Hundred's digit (bus voltage, unit: V)	
		0, 1 (same as unit's digit)	
		Thousand's digit (output voltage, unit: V)	
		0, 1 (same as unit's digit)	
		Ten thousand's digit (output current, unit A)	
		0, 1 (same as unit's digit)	
F7-01	LED display running parameters 2	Unit's digit (output power, unit: kW)	00000
		0: Display 1: No display	
		Ten's digit (output torque, unit :%)	
		0, 1 (same as unit's digit)	
		Hundred's digit (DI input status)	
		0, 1 (same as unit's digit)	
		Thousand's digit (DO output status)	
		0, 1 (same as unit's digit)	
		Ten thousand's digit (AI1 voltage, unit V)	
		0, 1 (same as unit's digit)	
F7-02	LED display running parameters 3	Unit's digit (AI2, unit: V)	00000
		0: Display 1: No display	
		Ten's digit (AI3, unit :V)	
		0, 1 (same as unit's digit)	

Function Code	Parameter Name	Setting Range	Default
F7-03	LED display running parameters 4	Hundred's digit (count value)	
		0, 1 (same as unit's digit)	
		Thousand's digit (length value)	
		0, 1 (same as unit's digit)	
		Ten thousand's digit (load speed display)	
		0, 1 (same as unit's digit)	
		Unit's digit (PID setting)	
		0: Display 1: No display	
		Ten's digit (PID feedback)	
		0, 1 (same as unit's digit)	
F7-04	LED display running parameters 5	Hundred's digit (PLC stage)	00000
		0, 1 (same as unit's digit)	
		Thousand's digit (pulse setting frequency, unit: kHz)	
		0, 1 (same as unit's digit)	
		Ten thousand's digit (running frequency 2, unit: Hz)	
		0, 1 (same as unit's digit)	
		Unit's digit (remaining running time)	
		0: Display 1: No display	
		Ten's digit (AI1 voltage before correction)	
		0, 1 (same as unit's digit)	
F7-05	LED display running parameters 6	Hundred's digit (AI2 voltage before correction)	00100
		0, 1 (same as unit's digit)	
		Thousand's digit (AI3 voltage before correction)	
		0, 1 (same as unit's digit)	
		Ten thousand's digit (Linear speed)	
		0, 1 (same as unit's digit)	
		Unit's digit (Current power-on time, unit: Hour)	
		0: Display 1: No display	
		Ten's digit (Current running time, unit: Minute)	
		0, 1 (same as unit's digit)	

Function Code	Parameter Name	Setting Range	Default
		Hundred's digit (Heatsink temperature display, unit: °C)	
		0, 1 (same as unit's digit)	
		Thousand's digit (Communication setting value)	
		0, 1 (same as unit's digit)	
		Ten thousand's digit (Encoder feedback speed, unit: Hz)	
		0, 1 (same as unit's digit)	
F7-06	LED display running parameters 7	Unit's digit (Main frequency X display, unit: Hz)	00
		0: Display 1: No display	
		Ten's digit (Auxiliary frequency Y display, unit: Hz)	
		0, 1 (same as unit's digit)	
		Hundred's digit, reserved	
		Thousand's digit, reserved	
		Ten thousand's digit, reserved	

These parameters are used to set the monitoring parameters that can be viewed when the frequency inverter is in the running state.

Function	Parameter Name	Setting Range	Default
F7-07	LED display stop parameters 1	Unit's digit (set frequency, unit: Hz)	00011
		0: Display 1: No display	
		Ten's digit (bus voltage, unit :V)	
		0, 1 (same as unit's digit)	
		Hundred's digit (DI input status)	
		0, 1 (same as unit's digit)	
		Thousand's digit (DO output status)	
		0, 1 (same as unit's digit)	
		Ten thousand's digit (AI1 voltage, unit V)	
		0, 1 (same as unit's digit)	
F7-08	LED display stop parameters 2	Unit's digit (AI2 voltage, unit V)	00000
		0: Display 1: No display	
		Ten's digit (AI3 voltage, unit V)	
		0, 1 (same as unit's digit)	
		Hundred's digit (count value)	

Function	Parameter Name	Setting Range	Default
		0, 1 (same as unit's digit)	
		Thousand's digit (length value)	
		0, 1 (same as unit's digit)	
		Ten thousand's digit (PLC stage)	
		0, 1 (same as unit's digit)	
F7-09	LED display stop parameters 3	Unit's digit (load speed)	00000
		0: Display 1: No display	
		Ten's digit (PID setting)	
		0, 1 (same as unit's digit)	
		Hundred's digit (pulse setting frequency, unit: kHz)	
		0, 1 (same as unit's digit)	
		Thousand's digit (heatsink temperature display, unit: °C)	
		0, 1 (same as unit's digit)	
		Ten thousand's digit, reserved	

Function Code	Parameter Name	Setting Range	Default
F7-10	Load speed display coefficient	0.0001~6.5000	1.0000

This parameter is used to adjust the relationship between the output frequency of frequency inverter and the load speed. For details, see the description of F7-11.

Function Code	Parameter Name	Setting Range	Default
F7-11	Number of decimal places for load speed display	0: 0 decimal place 1: 1 decimal place 2: 2 decimal places 3: 3 decimal places	1

F7-11 is used to set the number of decimal places for load speed display. The following gives an example to explain how to calculate the load speed:

Assume that F7-10 (Load speed display coefficient) is 2.000 and F7-11 is 2 (2 decimal places). When the running frequency of the frequency inverter is 40.00 Hz, the load speed is $40.00 \times 2.000 = 80.00$ (display of 2 decimal places).

If the frequency inverter is in the stop state, the load speed is the speed corresponding to the set frequency, namely, "setting load speed". If the set frequency is 50.00 Hz, the load speed in the stop state is $50.00 \times 2.000 = 100.00$ (display of 2 decimal places).

Function Code	Parameter Name	Setting Range	Default
F7-14	Heatsink temperature	0.0°C ~100.0°C	--

It is used to display the temperature of heatsink.

Different inverter model has different temperature value for over-temperature protection.

Function Code	Parameter Name	Setting Range	Default
F7-15	Accumulative power-on time	0 h ~65535 h	--

It is used to display the accumulative power-on time of the frequency inverter since the delivery. If the time reaches the set power-on time (F6-03), the terminal with the digital output function 37 becomes ON.

Function Code	Parameter Name	Setting Range	Default
F7-16	Accumulative running time	0~65535 h	--

It is used to display the accumulative running time of the frequency inverter. After the accumulative running time reaches the value set in F6-04, the terminal with the digital output function 25 becomes ON.

Function Code	Parameter Name	Setting Range	Default
F7-17	Accumulative power consumption	0 kWh~65535 kWh	--

It is used to display the accumulative power consumption of the frequency inverter until now.

Function Code	Parameter Name	Setting Range	Default
F7-18	STOP/RESET key function	0: STOP/RESET key enabled only in operation panel control 1: STOP/RESET key enabled in any operation mode	0

Function Code	Parameter Name	Setting Range	Default
F7-19	Restore parameter default settings	0: No operation 1: Restore default settings except motor parameters and accumulation record. 2: Restore default settings for all parameters 3: Reserved 4: Clear records	0

- 0: No operation
- 1: Restore default settings except motor parameters

If F7-19 is set to 1, most function codes are restored to the default settings except motor parameters, frequency command resolution (F0-02), fault records, accumulative running time (F7-16), accumulative power-on time (F7-15) and accumulative power consumption (F7-17).

- 2: Restore default settings for all parameters, including motor parameters
- 4: Clear records

If F7-19 is set to 4, the fault records, accumulative power-on time (F7-15), accumulative running time (F7-16), and accumulative power consumption (F7-17) are cleared.

Function Code	Parameter Name	Setting Range	Default
F7-22	Parameter group display selection 1	Unit's digit (Group F1)	11111
		0: Display	
		1: No display	
		Ten's digit (Group F2)	
		0, 1 (same as unit's digit)	
		Hundred's digit (Group F3)	
		0, 1 (same as unit's digit)	
		Thousand's digit (Group F4)	
		0, 1 (same as unit's digit)	
		Ten thousand's digit (Group F5)	
		0, 1 (same as unit's digit)	
F7-23	Parameter group display	Unit's digit (Group F6)	11111

Function Code	Parameter Name	Setting Range	Default
	selection2	0: Display 1: No display Ten's digit (Group F8) 0, 1 (same as unit's digit) Hundred's digit (Group F9) 0, 1 (same as unit's digit) Thousand's digit (Group FA) 0, 1 (same as unit's digit) Ten thousand's digit (Group Fb) 0, 1 (same as unit's digit)	
		Unit's digit (Group FC) 0: Display 1: No display Ten's digit (Group Fd) 0, 1 (same as unit's digit) Hundred's digit (Group d0) 0, 1 (same as unit's digit) Thousand's digit (Group d1) 0, 1 (same as unit's digit) Ten thousand's digit (Group d2) 0, 1 (same as unit's digit)	
F7-24	Parameter group display selection3	Unit's digit (Group d3) 0: Display 1: No display Ten's digit (Group d4) 0, 1 (same as unit's digit) Hundred's digit, reserved Thousand's digit, reserved Ten thousand's digit, reserved	11111
F7-25	Parameter group display selection4	Unit's digit (Group d3) 0: Display 1: No display Ten's digit (Group d4) 0, 1 (same as unit's digit) Hundred's digit, reserved Thousand's digit, reserved Ten thousand's digit, reserved	11

Function Code	Parameter Name	Setting Range	Default
F7-29	User password	0~65535	00000

If it is set to any non-zero number, the password protection function is enabled. After a password has been set and taken effect, you must enter the correct password in order to enter the menu. If the entered password is incorrect you cannot view or modify parameters.

If F7-29 is set to 00000, the previously set user password is cleared, and the password protection function is disabled.

Function Code	Parameter Name	Setting Range	Default
F7-30	Parameter modification property	0: Modifiable 1~65535: Not modifiable	00000

It is used to set whether the parameters are modifiable to avoid mal-function. If it is set to 0, all parameters are modifiable. If it is set to 1, all parameters can only be viewed.

Function Code	Parameter Name	Setting Range	Default
F7-31	MF.K Key function selection	0: MF.K key disabled 1: Switchover between operation panel control and remote command control (terminal or communication) 2: Switchover between forward rotation and reverse rotation 3: Forward JOG 4: Reverse JOG	3

MF.K key refers to multifunctional key. You can set the function of the MF.K key by using this parameter. You can perform switchover by using this key both in stop or running state.

- 0: MF.K key disabled

This key is disabled.

- 1: Switchover between operation panel control and remote command control (terminal or communication)

You can perform switchover from the present command source to the operation panel control (local operation). If the present command source is operation panel control, this key is invalid.

- 2: Switchover between forward rotation and reverse rotation

You can change the direction of the frequency inverter running by using the MF.K key. It is valid only when the present command source is operation panel control.

- 3: Forward JOG

You can perform forward JOG (FJOG) by using the MF.K key.

- 4: Reverse JOG

You can perform reverse JOG (FJOG) by using the MF.K key.

Function Code	Parameter Name	Setting Range	Default
F7-33	Product number	product number of frequency inverter	Model dependent
F7-34	Function software version	Function software version of frequency inverter	Model dependent
F7-35	Performance software version	Performance software version of frequency inverter	Model dependent
F7-36	Temporary function software version	Temporary function software version of frequency inverter	Model dependent
F7-37	Temporary performance software	Temporary performance software version of frequency inverter	Model dependent

These parameters are used for displaying the software version of frequency inverter, only for the manufacturer's checking.

6.9 Group F8: Fault and Protection

Function Code	Parameter Name	Setting Range	Default
F8-00	G/P type display	0: P type(variable torque load e.g. fan and pump) 1: G type(constant torque load)	1

This parameter is used to display the delivered model and cannot be modified.

- 0: Applicable to variable torque load (fan and pump) with rated parameters specified.
- 1: Applicable to constant torque general load with rated parameters specified.

Function Code	Parameter Name	Setting Range	Default
F8-01	Motor overload protection selection	0: Disabled 1: Enabled	0
F8-02	Motor overload protection gain	0.20~10.00	1.00

- F8-01=0

The motor overload protective function is disabled. The motor is exposed to potential damage due to overheating. A thermal relay is suggested to be installed between the frequency inverter and the motor.

- F8-01 = 1

The frequency inverter judges whether the motor is overloaded according to the inverse time-lag curve of the motor overload protection.

The inverse time-lag curve of the motor overload protection is:

$220\% \times (F8-02) \times \text{rated motor current}$

(If the load remains at this value for one minute, the frequency inverter reports motor overload fault), or
 $150\% \times (F8-02) \times \text{rated motor current}$

(If the load remains at this value for 60 minutes, the frequency inverter reports motor overload fault).

Set F8-02 properly based on the actual overload capacity. If the value of F8-02 is set too large, may result in damaging to the motor because the motor overheats but the frequency inverter does not report the alarm.

Function Code	Parameter Name	Setting Range	Default
F8-03	Motor overload warning coefficient	50%~100%	80%

This function is used to give a warning signal to the control system via DO before motor overload protection. This parameter is used to determine the percentage, at which pre-warning is performed before motor overload. The larger the value is, the less advance the pre-warning will be.

When the output current of the frequency inverter is greater than the value of the overload inverse time-lag curve multiplied by F8-03, the DO terminal of the frequency inverter set with motor overload pre-warning becomes ON.

Function Code	Parameter Name	Setting Range	Default
F8-04	Overvoltage stall gain	0% (no stall overvoltage)~100%	0%
F8-05	Overvoltage stall protective voltage	120%~150%	130%

When the DC bus voltage exceeds the value of F8-05 (Overvoltage stall protective voltage) during deceleration of the frequency inverter, the frequency inverter stops deceleration and keeps the present running frequency. After the bus voltage declines, the frequency inverter continues to decelerate.

F8-04 (Overvoltage stall gain) is used to adjust the overvoltage suppression capacity of the frequency inverter. The larger the value is, the greater the overvoltage suppression capacity will be. In the prerequisite of no overvoltage occurrence, set F8-04 to a small value.

For small-inertia load, the value should be small. Otherwise, the system dynamic response will be slow. For large-inertia load, the value should be large. Otherwise, the suppression result will be poor and an overvoltage fault may occur.

If the overvoltage stall gain is set to 0, the overvoltage stall function is disabled. The overvoltage stall protective voltage setting 100% corresponds to the base values in the following table:

Voltage Class	Corresponding Base
Single-phase 220V	290V
Three-phase 220 V	290 V
Three-phase 380 V	530 V
Three-phase 480 V	620 V
Three-phase 690 V	880 V

Function Code	Parameter Name	Setting Range	Default
F8-06	Over current stall gain	0~100	20
F8-07	Over current stall protective current	100%~200%	150%


Over current stall: When the output current exceeds the over current stall protective current (F8-07) during acceleration/deceleration of the frequency inverter, the frequency inverter stops acceleration/deceleration and keeps the present running frequency. After the output current declines to below F8-07, the frequency inverter continues to accelerate/decelerate.

F8-07 (over current stall protective current) is used to select the current protection value of over current stall function. This function will be carried out by frequency inverter, when the current exceeds F8-07. This value is the percentage of motor rated current.

F8-06 (over current stall gain) is used to adjust the over current suppression capacity of the frequency inverter. The larger the value is, the greater the over current suppression capacity will be. In condition of no over current occurrence, should set F8-06 to a small value.

For small-inertia load, the value should be small. Otherwise, the system dynamic response will be slow. For large-inertia load, the value should be large. Otherwise, the suppression result will be poor and over current fault may occur. If the over current stall gain is set to 0, the over current stall function is disabled.

Figure 6-21 Diagram of the overcurrent stall protection function



Function Code	Parameter Name	Setting Range	Default
F8-08	Overvoltage threshold	200.0V~2500.0 V	810.0V

It is used to set the overvoltage threshold of the frequency inverter. The default values of different voltage classes are listed in the following table.

Voltage Class	Default Overvoltage Threshold
Single-phase 220V	400.0V
Three-phase 220 V	400.0 V
Three-phase 380 V	830.0 V
Three-phase 480 V	890.0 V
Three-phase 690 V	1300.0 V

Note: The default value is also the upper limit of the frequency inverter's internal overvoltage protection voltage. The parameter becomes effective only when the setting of F8-08 is lower than the default value. If the setting is higher than the default value, use the default value.

Function Code	Parameter Name	Setting Range	Default
F8-09	Undervoltage threshold	50.0%~150.0%	100.0%

It is used to set the undervoltage threshold of Err09. The under voltage threshold 100% of the frequency inverter of different voltage classes corresponds to different nominal values, as listed in the following table.

Voltage Class	Nominal Value of undervoltage
Single-phase 220V	200V
Three-phase 220 V	200 V
Three-phase 380 V	350 V
Three-phase 480 V	450 V
Three-phase 690 V	650 V

Function Code	Parameter Name	Setting Range	Default
F8-10	Braking use ratio	0%~100%	100%

It is valid only for the frequency inverter with internal braking unit and used to adjust the duty ratio of the braking unit. The larger the value of this parameter is, the better the braking result will be. However, too larger value causes great fluctuation of DC bus voltage during the braking process.

Function Code	Parameter Name	Setting Range	Default
F8-11	Short-circuit to ground after power- on	0: Disabled 1: Enabled	1

It is used to determine whether to check the motor is short-circuited to ground after power-on of the frequency inverter. If this function is enabled, the frequency inverter's UVW will have voltage output a while after power-on.

Function Code	Parameter Name	Setting Range	Default
F8-12	Input phase loss protectionselection	Unit's digit: Input phase loss protection 0: Disabled 1: Enabled	1

It is used to determine whether to perform input phase loss protection.

The FC155 models that provide this function are listed in the following table.

Voltage Class	Models
Single-phase 220V	None
Three-phase 220 V	From 5.5 kW G
Three-phase 380 V	From 11 kW G model
Three-phase 690 V	From 18.5 kW G

For every voltage class, the FC155 frequency inverters provide function of input phase loss protection for above model. The FC155 Frequency inverters do not have this function below the power listed in the table no matter whether F8-12 is set to 0 or 1.

Function Code	Parameter Name	Setting Range	Default
F8-13	Output phase loss protection selection	0: Disabled 1: Enabled	0

It is used to determine whether to perform output phase loss protection.

Function Code	Parameter Name	Setting Range	Default
F8-14	Off load protection	0: Disabled 1: Enabled	0
F8-15	Off load detection level	0.0%~100.0% (ratedmotor current)	1.0%
F8-16	Off load detection time	0.0s~60.0s	1.0s

If off load protection is enabled, when the output current of the frequency inverter is lower than the detection level (F8-15) and the duration time exceeds the detection time (F8-16), the output frequency of frequency inverter automatically declines to 7% of the rated frequency. During the protection, the frequency inverter automatically accelerates to the set frequency if the load restore to normal.

Function Code	Parameter Name	Setting Range	Default
F8-17	Rapid current limit	0: Disabled 1: Enabled	1

The rapid current limit function can reduce the frequency inverter overcurrent faults at maximum, guaranteeing uninterrupted running of the frequency inverter.

However, long-time rapid current limit may cause the frequency inverter to overheat, which is not allowed. In this case, the frequency inverter will report Err40, indicating the frequency inverter is overloaded and needs to stop.

Function Code	Parameter Name	Setting Range	Default
F8-18	Over-speed detection value	0.0%~50.0% (maximum frequency)	20.0%
F8-19	Over-speed detection time	0.0s~60.0s	1.0s

This function is valid only when the frequency inverter runs in the VC+PG mode.

If the actual motor rotational speed detected by the frequency inverter exceeded the maximum frequency and the excessive value is greater than the value of F8-18 and the lasting time exceeded the value of F8-19, the frequency inverter reports Err43 and acts according to the selected fault protection action.

If the F8-19(over-speed detection time) is 0.0s, the over-speed detection function is disabled.

Function Code	Parameter Name	Setting Range	Default
F8-20	Detection value of too large speed deviation	0.0%~50.0% (maximum frequency)	20.0%
F8-21	Detection time of too large speed deviation	0.0s~60.0s	5.0s

This function is valid only when the frequency inverter runs in the VC+PG mode.

If the frequency inverter detects the deviation over than F8-20 between the actual motor rotational and the settingmotor frequency, and the duration time exceeds the value of F8-21, the frequency inverter reports Err42 and act according to the selected fault protection action.

If F8-21 (Detection time of too large speed deviation) is 0.0s, this function is disabled.


Function Code	Parameter Name	Setting Range	Default
F8-22	Action selection at instantaneous power failure	0: Invalid 1: Decelerate 2: Decelerate to stop	0

Function Code	Parameter Name	Setting Range	Default
F8-23	Voltage rally judging time at instantaneous power failure	0.00s~100.00s	0.00s
F8-24	Judging voltage of instantaneous power failure	60.0%~100.0% (standard bus voltage)	80.0%
F8-25	Judging voltage of instantaneous power failure restoring	60.0%~100.0% (standard bus voltage)	90.0%

Of instantaneous power failure or sudden voltage dip, the DC bus voltage of the frequency inverter reduces. This function enables the frequency inverter to compensate the DC bus voltage reduction with the load feedback energy by reducing the output frequency so as to keep the frequency inverter running continuously.

- If F8-22 = 1, when instantaneous power failure or sudden voltage dip, the frequency inverter decelerates until DC bus voltage restore to normal, the frequency inverter accelerates to the set frequency. If the DC bus voltage remains normal for the time exceeding the value set in F8-23, it is considered that the DC bus voltage restores to normal.
- If F8-22 = 2, when instantaneous power failure or sudden voltage dip, the frequency inverter decelerates to stop.

Figure 6-22 Frequency inverter action diagram of instantaneous power failure



Function Code	Parameter Name	Setting Range	Default
F8-26	Fault auto reset times	0~99	00

It is used to set the times of fault auto resets if this function is used. After the value is exceeded, the frequency inverter will remain in the fault state.

Function Code	Parameter Name	Setting Range	Default
F8-27	Relay action selection during fault auto reset	0: Not act 1: Act	0

It is used to decide whether DO acts during the fault auto reset if the fault auto reset function is used.

Function Code	Parameter Name	Setting Range	Default
F8-28	Interval time of fault auto reset	0.1s~100.0s	1.0s

It is used to set the waiting time from the frequency inverter alarm to fault auto reset.

Function Code	Parameter Name	Setting Range	Default
F8-29	Type of motor temperature sensor	0: No temperature sensor 1: PT100 2: PT1000	0
F8-30	Motor overheat protection threshold	0°C~200°C	120°C
F8-31	Motor overheat warning threshold	0°C~200°C	100°C

The signal of the motor temperature sensor needs to be connected to the optional I/O extension card. This card is an optional component. PG card also can be used for the temperature signal input with motor over-temperature protection function. Please contact with manufacturer or distributors.

The PG card interface of the FC155 supports both PT100 and PT1000. Set the sensor type correctly during the use. You can view the motor temperature via parameter F9-34.

If the motor temperature exceeds the value set in F8-30, the frequency inverter reports an alarm and acts according to the selected fault protection action.

If the motor temperature exceeds the value set in F8-31, the DO terminal of frequency inverter set with motor overheat warning becomes ON.

Function Code	Parameter Name	Setting Range	Default
F8-32	Fault protection action selection 1	Unit's digit (Motor overload, Err11)	00000
		0: Free stop 1: Stop according to the stop mode 2: Continue to run	
		Ten's digit (Power input phase loss, Err12)	
		Same as unit's digit	
		Hundred's digit (Power output phase loss, Err13)	
		Same as unit's digit	
		Thousand's digit (External equipment fault, Err15)	
		Same as unit's digit	
		Ten thousand's digit (Communication fault, Err16)	

Function Code	Parameter Name	Setting Range	Default
		Same as unit's digit	
F8-33	Fault protection action selection 2	Unit's digit (Encoder /PG card fault, Err20)	00000
		0: Free stop	
		1: Switch to V/F mode, stop according to stopping mode	
		2: Switch to V/F control, continue to run	
		Ten's digit (EEPROM read-write fault, Err21)	
		0: Free stop	
		1: Stop according to the stop mode	
		Hundred's digit: reserved	
		Thousand's digit (Motor overheat, Err25)	
		Same as unit's digit in F8-32	
F8-34	Fault protection action selection 3	Ten thousand's digit (Accumulative running time reached)	00000
		Same as unit's digit in F8-32	
		Unit's digit (User-defined fault 1, Err27)	
		Same as unit's digit in F8-32	
		Ten's digit (User-defined fault 2, Err28)	
		Same as unit's digit in F8-32	
		Hundred's digit (Accumulative power-on time reached, Err29)	
		Same as unit's digit in F8-32	
		Thousand's digit (Off load, Err30)	
		0: Free stop	
F8-35	Fault protection action selection 4	1: Stop according to the stop mode	000
		2: Continue to run at 7% of rated motor frequency and restore to the set frequency if the load recovers	
		Ten thousand's digit (PID feedback lost during running, Err31)	
		Same as unit's digit in F8-32	
		Unit's digit (Too large speed deviation, Err42)	
		Same as unit's digit in F8-32	
		Ten's digit (Motor over-speed, Err43)	

- If "free stop" is selected, the frequency inverter displays Err** and directly stops.
- If "Stop according to the stop mode" is selected, the frequency inverter displays A** and stops according to the stop mode. After stop, the frequency inverter displays Err**.
- If "Continue to run" is selected, the frequency inverter continues to run and displays A**. The running frequency is set in F8-36.

Function Code	Parameter Name	Setting Range	Default
F8-36	Frequency selection for continuing to run of fault	0: At present running frequency 1: At setting frequency 2: Frequency upper limit 3: Frequency lower limit 4: Backup frequency of abnormality(F8-37)	0
F8-37	Backup frequency of abnormality	0.0%~100.0% (maximum frequency)	1.0%

If a fault occurs during the running of the frequency inverter and the handling of fault is set to "continueto run", the frequency inverter displays A** and continues to run at the frequency set in F8-36.

The setting of F8-37 is a percentage relative to the maximum frequency.

Function Code	Name	Setting Range
F8-38	1st fault type	0~99
F8-39	2nd fault type	
F8-40	3rd (latest) fault type	

It is used to record the types of the most recent three faults of the frequency inverter. 0 indicates no fault. For possible causes and solution of each fault, refer to Chapter 8.

Function Code	Parameter Name	Description																				
F8-41	Frequency of latest fault	It displays the frequency when the latest fault occurs.																				
F8-42	Current of latest fault	It displays the current when the latest fault occurs.																				
F8-43	DC Bus voltage of latest fault	It displays the DC bus voltage when the latest fault occurs.																				
F8-44	DI terminals status of latest fault	<p>It displays the status of all DI terminals when the latest fault occurs. The sequence is as follows:</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>BIT9</td> <td>BIT8</td> <td>BIT7</td> <td>BIT6</td> <td>BIT5</td> <td>BIT4</td> <td>BIT3</td> <td>BIT2</td> <td>BIT1</td> <td>BIT0</td> </tr> <tr> <td>DI0</td> <td>DI9</td> <td>DI8</td> <td>DI7</td> <td>DI6</td> <td>DI5</td> <td>DI4</td> <td>DI3</td> <td>DI2</td> <td>DI1</td> </tr> </table> <p>If a DI is ON, the setting is 1. If the DI is OFF, the setting is 0. The value is the equivalent decimal number converted from the DI status.</p>	BIT9	BIT8	BIT7	BIT6	BIT5	BIT4	BIT3	BIT2	BIT1	BIT0	DI0	DI9	DI8	DI7	DI6	DI5	DI4	DI3	DI2	DI1
BIT9	BIT8	BIT7	BIT6	BIT5	BIT4	BIT3	BIT2	BIT1	BIT0													
DI0	DI9	DI8	DI7	DI6	DI5	DI4	DI3	DI2	DI1													
F8-45	DO terminals status of latest fault	<p>It displays the status of all output terminals when the latest fault occurs. The sequence is as follows:</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>BIT4</td> <td>BIT3</td> <td>BIT2</td> <td>BIT1</td> <td>BIT0</td> </tr> <tr> <td>DO2</td> <td>DO1</td> <td>REL2</td> <td>REL1</td> <td>FMP</td> </tr> </table> <p>If an output terminal is ON, the setting is 1. If the output terminal is OFF, the setting is 0. The value is the equivalent decimal number converted from the DI statuses.</p>	BIT4	BIT3	BIT2	BIT1	BIT0	DO2	DO1	REL2	REL1	FMP										
BIT4	BIT3	BIT2	BIT1	BIT0																		
DO2	DO1	REL2	REL1	FMP																		
F8-46	Frequency inverter status of latest fault	Reserved																				
F8-47	Power-on time of latest fault	It displays the present power-on time when the latest fault occurs.																				
F8-48	Running time of latest fault	It displays the present running time when the latest fault occurs.																				
F8-49	Frequency of 2nd fault	Same as F8-41~F8-48.																				

Function Code	Parameter Name	Description
F8-50	Current of 2nd fault	
F8-51	DC Bus voltage of 2nd fault	
F8-52	DI terminals status of 2nd fault	
F8-53	DO terminals status of 2nd fault	
F8-54	Frequency inverter status of 2nd fault	
F8-55	Power-on time of 2nd fault	
F8-56	Running time of 2nd fault	
F8-57	Frequency of 1st fault	
F8-58	Current of 1st fault	
F8-59	DC Bus voltage of 1st fault	
F8-60	DI terminals status of 1st fault	Same as F8-41~F8-48.
F8-61	DO terminals status of 1st fault	
F8-62	Frequency inverter status of 1st fault	
F8-63	Power-on time of 1st fault	
F8-64	Running time of 1st fault	

6.10 Group F9: Monitoring Parameters

Function Code	Parameter Name	Display Range
F9-00	Running frequency	
F9-01	Set frequency	
F9-02	DC Bus voltage	
F9-03	Output voltage	
F9-04	Output current	
F9-05	Output power	
F9-06	Output torque	
F9-07	Fault information	
F9-08	Present setting frequency	
F9-09	Present running frequency	
F9-10	Frequency inverter running state	
F9-11	AI1 voltage	
F9-12	AI2 voltage	
F9-13	AI3 voltage	
F9-14	AI1 voltage before correction	
F9-15	AI2 voltage before correction	
F9-16	AI3 voltage before correction	
F9-17	Counter value	
F9-18	Length value	

Function Code	Parameter Name	Display Range
F9-19	Load speed	
F9-20	PID setting	
F9-21	PID feedback	
F9-22	PLC stage	
F9-23	Current remaining time of PLC	
F9-24	Input pulse frequency	
F9-25	feedback speed	
F9-26	Remaining running time	
F9-27	Linear speed	
F9-28	Present power-on time	
F9-29	Present running time	
F9-30	Communication setting value	
F9-31	Actual feedback speed	
F9-32	Main frequency X	
F9-33	Auxiliary frequency Y	
F9-34	Motor temperature	
F9-35	Target torque	
F9-36	Resolver position	
F9-37	Heatsink temperature	
F9-38	ABZ position	
F9-39	Target voltage of V/F separation	
F9-40	Output voltage of V/F separation	
F9-41	DI state	
F9-42	DO state	

Group F9 is used to monitor the frequency inverter's running state.

6.11 Group FA: Communication parameters

Function Code	Parameter Name	Setting Range	Default
FA-00	Communication type selection	0: Modbus protocol	0

The FC155now supports Modbus. For details, see the description of "FC155 communication protocol".

Function Code	Parameter Name	Setting Range	Default
FA-01	Baud ratio	Unit's digit(Modbus band rate) 0:300BPS 1:600BPS 2:1200BPS 3:2400BPS 4:4800BPS 5:9600BPS 6:19200BPS 7:38400BPS	5

This parameter is used to set the data transfer baud rate from host computer to frequency inverter. Please note that baud rate of the host computer and the inverter should be consistent. Otherwise, the

communication is impossible. The higher the baud rate is, the faster the communication is.

Function Code	Parameter Name	Setting Range	Default
FA-02	Modbus data format	0: No check, data format <8,N,2> 1: Even parity check, dataformat<8,E,1> 2: Odd Parity check, data format<8,O,1> 3: No check, data format<8,N,1> Valid for Modbus	0

The host computer and inverter setup data format must be consistent, otherwise, communication is impossible.

Function Code	Parameter Name	Setting Range	Default
FA-03	Broadcast address	0~249, 0 is broadcast address	1

When the local address is set to 0, that is, broadcast address, it can realize the broadcast function of host computer.

The address is unique; it is base of point to point communication between host computer and frequency inverter.

Function Code	Parameter Name	Setting Range	Default
FA-04	Modbus response delay	0ms~20ms(only valid for Modbus)	2ms

Response delay: it refers to the interval time from the inverter finishes receiving data to response data back to the host machine. If the response delay is less than the system processing time, then the response time is based on the time of the system processing. If the response delaying time is more than the system processing time, after the system processes the data, it should be delayed to wait until the response delay time is reached, and then sending back data to host machine.

Function Code	Parameter Name	Setting Range	Default
FA-05	Communication interface timeout	0.0s(inactive), 0.1s~60.0s	0.0s

When this parameter is set to 0.0s, the communication interface timeout function is invalid.

When the function code is set to a value, if the interval time between this communication and the next communication is beyond the communication timeout, the system will report communication failure error (Err16). At normal application, it will be set as invalid. If in the continuous communication system, setting this parameter, you can monitor the communication status.

Function Code	Parameter Name	Setting Range	Default
FA-06	Communication protocol selection	Unit's digit(Modbus) 0: Non-standard Modbus protocol	1

FA-06=1: Select standard Modbus protocol.

FA-06=0: When reading the command, the slave machine return is one byte more than the standard Modbus protocol's, for details, refer to communication data structure of appendix .

Function Code	Parameter Name	Setting Range	Default


FA-07	Communication reading current resolution	0: 0.01A 1: 0.1A	0
-------	--	---------------------	---

It is used to confirm the unit of current value when the communication reads the output current.

6.12 Group Fb: Process Control PID Function

PID control is a general process control method. By performing proportional, integral and differential operations on the difference between the feedback signal and the target signal, it adjusts the output frequency and constitutes a feedback system to stabilize the controlled counter around the target value. It is applied to process control such as flow control, pressure control and temperature control. The following figure shows the principle block diagram of PID control.

Figure 6-23 Principle block diagram of PID control.



Function Code	Parameter Name	Setting Range	Default
Fb-00	PID setting source	0: Fb-01 1: AI1 2: AI2 3: AI3 4: Pulse setting (HDI) 5: Communication setting 6: Multi-function	0
Fb--01	PID digital setting	0.0%~100.0%	0.0%

Fb-00 is used to select the channel of target process PID setting. The PID setting is a relative value and ranges from 0.0% to 100.0%. The PID feedback is also a relative value. The purpose of PID control is to make the PID setting and PID feedback equal.

Function Code	Parameter Name	Setting Range	Default
Fb-02	PID setting change time	0.00s~650.00s	1.00s

The PID setting change time indicates the time required for PID setting changing from 0.0% to 100.0%. The PID setting changes linearly according to the change time, reducing the impact caused by sudden setting change on the system.

Function Code	Parameter Name	Setting Range	Default

Fb-03	PID feedback source	0: AI1 1: AI2 2: AI3 3: Pulse setting (HDI) 4: AI1 – AI2 5: AI1 + AI2 6: MAX (AI1 , AI2) 7: MIN (AI1 , AI2) 8: Communication setting	0
-------	---------------------	--	---

This parameter is used to select the feedback signal channel of process PID. The PID feedback is a relative value and ranges from 0.0% to 100.0%. Similarly, the feedback of PID is also a relative value. The function of PID is to make the two values the equal.

Function Code	Parameter Name	Setting Range	Default
Fb-04	PID action direction	0: Forward action 1: Reverse action	0

- 0: Forward action

When the feedback value is smaller than the PID setting, the frequency inverter's output frequency rises. For example, the winding tension control requires forward PID action.

- 1: Reverse action

When the feedback value is larger than the PID setting, the frequency inverter's output frequency reduces. For example, the unwinding tension control requires reverse PID action.

Note this function is influenced by the DI function 24 "Reverse PID action direction".

Function Code	Parameter Name	Setting Range	Default
Fb-05	PID setting feedback range	0~65535	1000

This parameter is a non-dimensional unit. It is used for PID setting display (F9-20) and PID feedback display (F9-21).

Relative value 100% of PID setting feedback corresponds to the value of Fb-05. If Fb-05 is set to 2000 and PID setting is 100.0%, the PID setting display (F9-20) is 2000.

Function Code	Parameter Name	Setting Range	Default
Fb-06	Proportional gain Kp1	0.00~10.00	2.00
Fb-07	Integral time Ti1	0.01s~10.00s	0.50s
Fb-08	Differential time Td1	0.000s~10.000s	0.000s

- Fb-06 (Proportional gain Kp1)

It decides the regulating intensity of the PID regulator. The higher the Kp1 is, the larger the regulating intensity is. The value 10.00 indicates when the deviation between PID feedback and PID setting is 100.0%, the adjustment amplitude of the PID regulator on the output frequency reference is the maximum frequency.

- Fb-07 (Integral time Ti1)

It decides the integral regulating intensity. The shorter the integral time is, the larger the regulating intensity is. When the deviation between PID feedback and PID setting is 100.0%, the integral regulator performs continuous adjustment for the time. Then the adjustment amplitude reaches the maximum frequency.

- Fb-08 (Differential time Td1)

It decides the regulating intensity of the PID regulator on the deviation change. The longer the differential time is, the larger the regulating intensity is. Differential time is the time within which the feedback value change reaches 100.0%, and then the adjustment amplitude reaches the maximum frequency.

Function Code	Parameter Name	Setting Range	Default

Fb -09	Proportional gain Kp2	0.01~10.00	2.00
Fb -10	Integral time Ti2	0.01s~10.00s	0.50s
Fb-11	Differential time Td2	0.00~10.00s	0.00s
Fb -12	PID parameter switchover condition	0: No switchover 1: Switchover via DI 2: Automatic switchover based on deviation	0
Fb -13	PID parameter switchover deviation 1	0.0% ~Fb-14	20.0%
Fb -14	PID parameter switchover deviation 2	Fb -13 ~ 100.0%	80.0%


In some applications, PID parameters switchover is required when one group of PID parameters cannot satisfy the requirement of the whole running process.

These parameters are used for switchover between two groups of PID parameters. Regulator parameters Fb-09 ~Fb-11 are set in the same way as Fb-06 ~Fb-08.

The switchover can be implemented either via a DI terminal or automatically implemented based on the deviation.

- If you select switchover via a DI terminal, the DI must be set with function 25 "PID parameter switchover". If the DI is OFF, group 1 (Fb-06 ~ Fb-08) is selected. If the DI is ON, group 2 (Fb-09 to Fb-11) is selected.
- If you select automatic switchover, when the absolute value of the deviation between PID feedback and PID setting is smaller than the value of Fb-13, group 1 is selected. When the absolute value of the deviation between PID feedback and PID setting is higher than the value of Fb-14, group 2 is selected. When the deviation is between Fb-13 and Fb-14, the PID parameters are the linear interpolated value of the two groups of parameter values.

Figure 6-24PID parameters switchover



Function Code	Parameter Name	Setting Range	Default
Fb-15	PID integral property	Unit's digit (Integral separation) 0: Invalid 1: Valid Ten's digit (Whether to stop integral operation when the output reaches the limit) 0: Continue integral operation 1: Stop integral operation	00

- Integral separation

If integral separation is set to valid, and the DI is defined as function 23 "PID integral pause". In this case, only proportional and differential operations take effect.

If integral separation is set to invalid, no matter whether the DI set with function 23 "PID integral pause"

is ON or not, integral separation remains invalid.


- Stop integral

After the output has reached to maximum or minimum limit in PID operation, we can select to stop the integral operation or not. If we select to stop, it may help to reduce the PID overshoot.

Function Code	Parameter Name	Setting Range	Default
Fb-16	PID initial value	0.0%~100.0%	0.0%
Fb-17	PID initial value holding time	0.00s~650.00s	0.00s

When the frequency inverter starts up, the PID output initial value (Fb-16), and sustain the holding time (Fb-17), the PID start close-loop calculation.

Figure 6-25 PID initial value function



Function Code	Parameter Name	Setting Range	Default
Fb-18	Frequency upper limit of PID reverse rotation	0.00 ~ maximum frequency	0.00 Hz

In some situations, only when the PID output frequency is a negative value (frequency inverter reverse rotation), PID setting and PID feedback can be equal. However, too high reverse rotation frequency is prohibited in some applications, and Fb-18 is used to determine the reverse rotation frequency upper limit.

Function Code	Parameter Name	Setting Range	Default
Fb-19	PID deviation limit	0.0%~100.0%	0.0%

If the deviation between PID feedback and PID setting is smaller than the value of Fb-19, PID control stops. The small deviation between PID feedback and PID setting will make the output frequency stabilize, which is effective for some closed-loop control applications.

Function Code	Parameter Name	Setting Range	Default
Fb-20	PID differential amplitude limit	0.00%~100.00%	0.10%

It is used to set the PID differential output range. In PID control, the differential operation may easily cause system oscillation. Thus, the PID differential regulation is restricted to a small range.

Function Code	Parameter Name	Setting Range	Default
Fb-21	Maximum positive deviation between two PID outputs	0.00%~100.00%	1.00%
Fb-22	Maximum negative deviation between two PID outputs	0.00%~100.00%	1.00%

This function is used to limit the deviation between two PID outputs (2 ms per PID output) to suppress

the rapid change of PID output and stabilize the running of the frequency inverter.

Fb-21 and Fb-22 respectively are corresponding to the maximum absolute value of the output deviation in forward direction and in reverse direction.

Function Code	Parameter Name	Setting Range	Default
Fb-23	PID feedback filter time	0.00s~60.00s	0.00s
Fb-24	PID output filter time	0.00s~60.00s	0.00s

Fb-23 is used to filter the PID feedback, helping to reduce interference on the feedback but slowing the response of the process closed-loop system.

Fb-24 is used to filter the PID output frequency, helping to weaken sudden change of the frequency inverter output frequency but slowing the response of the process closed-loop system.

Function Code	Parameter Name	Setting Range	Default
Fb-25	Detection value of PID feedback loss	0.0%: Not judging feedback loss 0.1%~100.0%	0.0%
Fb-26	Detection time of PID feedback loss	0.0s~20.0s	0.0s

These parameters are used to judge whether PID feedback is lost.

If the PID feedback is smaller than the value of Fb-25 and the lasting time exceeds the value of Fb-26, the frequency inverter reports Err31 and acts according to the selected fault protection action.

Function Code	Parameter Name	Setting Range	Default
Fb-27	PID operation at stop	0: No PID operation at stop 1: PID operation at stop	1

It is used to select whether to continue PID operation in the state of stopping. Generally, to set the PID operation stops when the frequency inverter stops.

6.13 Group FC: Multi-reference and simple PLC

The FC155 multi-reference has many functions. Besides multi-speed, it can be used as the setting source of the V/F separated voltage source and setting source of process PID. In addition, the multi-reference is relative value.

The simple PLC function is different from the FC155 user programmable function. Simple PLC can only complete simple combination of multi-reference.

Function Code	Parameter Name	Setting Range	Default
FC-00	Reference 0	-100.0% ~ 100.0%	0.0%
FC-01	Reference 1	-100.0% ~ 100.0%	0.0%
FC-02	Reference 2	-100.0% ~ 100.0%	0.0%
FC-03	Reference 3	-100.0% ~ 100.0%	0.0%
FC-04	Reference 4	-100.0% ~ 100.0%	0.0%
FC-05	Reference 5	-100.0% ~ 100.0%	0.0%
FC-06	Reference 6	-100.0% ~ 100.0%	0.0%
FC-07	Reference 7	-100.0% ~ 100.0%	0.0%
FC-08	Reference 8	-100.0% ~ 100.0%	0.0%
FC-09	Reference 9	-100.0% ~ 100.0%	0.0%
FC-10	Reference 10	-100.0% ~ 100.0%	0.0%
FC-11	Reference 11	-100.0% ~ 100.0%	0.0%
FC-12	Reference 12	-100.0% ~ 100.0%	0.0%
FC-13	Reference 13	-100.0% ~ 100.0%	0.0%

FC -14	Reference 14	-100.0% ~ 100.0%	0.0%
FC -15	Reference 15	-100.0% ~ 100.0%	0.0%

Multi-reference can be the setting source of frequency, V/F separated voltage and processPID. The multi-reference is relative value and ranges from -100.0% to 100.0%.

As frequency source, it is a percentage relative to the maximum frequency. As V/F separated voltage source, it is a percentage relative to the rated motor voltage. As process PID setting source, it does not require conversion.

Multi-reference can be switched over based on different states of DI terminals. For details, see the descriptions of group b3.

Function Code	Parameter Name	Setting Range	Default
FC-16	Multi-reference 0 source	0: Set by FC-00 1: AI1 2: AI2 3: AI3 4: Pulse setting(HDI) 5: PID 6: Set by preset frequency (F0-08), modified via terminal UP/DOWN	0

It determines the setting channel of multi-function 0. You can perform convenient switchover between the setting channels. When multi-function or simple PLC is used as frequency source, the switchover between two frequency sources can be realized easily.

Function Code	Parameter Name	Setting Range	Default
FC-17	Simple PLC running mode	0: Stop after the frequency inverter runs one cycle 1: Keep final values after the frequency inverter runs one cycle 2: Repeat after the frequency inverter runs one cycle	0
FC-18	Simple PLC retentive selection	Unit's digit (Retentive upon power failure) 0: No 1: Yes Ten's digit (Retentive upon stop) 0: No 1: Yes	00
FC-19	Running time of simple PLC segment 0	0.0s(h)~6553.5s(h)	0.0s (h)
FC-20	Running time of simple PLC segment 1	0.0s(h)~6553.5s(h)	0.0s (h)
FC-21	Running time of simple PLC segment 2	0.0s(h)~6553.5s(h)	0.0s (h)
FC-22	Running time of simple PLC segment 3	0.0s(h)~6553.5s(h)	0.0s (h)
FC-23	Running time of simple PLC segment 4	0.0s(h)~6553.5s(h)	0.0s (h)
FC-24	Running time of simple PLC segment 5	0.0s(h)~6553.5s(h)	0.0s (h)


FC-25	Running time of simple PLC segment 6	0.0s(h)~6553.5s(h)	0.0s (h)
FC-26	Running time of simple PLC segment 7	0.0s(h)~6553.5s(h)	0.0s (h)
FC-27	Running time of simple PLC segment 8	0.0s(h)~6553.5s(h)	0.0s (h)
FC-28	Running time of simple PLC segment 9	0.0s(h)~6553.5s(h)	0.0s (h)
FC-29	Running time of simple PLC segment 10	0.0s(h)~6553.5s(h)	0.0s (h)
FC-30	Running time of simple PLC segment 11	0.0s(h)~6553.5s(h)	0.0s (h)
FC-31	Running time of simple PLC segment 12	0.0s(h)~6553.5s(h)	0.0s (h)
FC-32	Running time of simple PLC segment 13	0.0s(h)~6553.5s(h)	0.0s (h)
FC-33	Running time of simple PLC segment 14	0.0s(h)~6553.5s(h)	0.0s (h)
FC-34	Running time of simple PLC segment 15	0.0s(h)~6553.5s(h)	0.0s (h)
FC-35	Time unit of simple PLC running	0: s (second) 1: h (hour)	0
FC-36	Acceleration time of simple PLC segment 0	0.01s~65000s	Model dependent
FC-37	Deceleration time of simple PLC segment 0	0.01s~65000s	Model dependent
FC-38	Acceleration time of simple PLC segment 1	0.01s~65000s	Model dependent
FC-39	Deceleration time of simple PLC segment 1	0.01s~65000s	Model dependent
FC-40	Acceleration time of simple PLC segment 2	0.01s~65000s	Model dependent
FC-41	Deceleration time of simple PLC segment 2	0.01s~65000s	Model dependent
FC-42	Acceleration time of simple PLC segment 3	0.01s~65000s	Model dependent
FC-43	Deceleration time of simple PLC segment 3	0.01s~65000s	Model dependent
FC-44	Acceleration time of simple PLC segment 4	0.01s~65000s	Model dependent
FC-45	Deceleration time of simple PLC segment 4	0.01s~65000s	Model dependent
FC-46	Acceleration time of simple PLC segment 5	0.01s~65000s	Model dependent
FC-47	Deceleration time of simple PLC segment 5	0.01s~65000s	Model dependent
FC-48	Acceleration time of simple PLC segment 6	0.01s~65000s	Model dependent

FC-49	Deceleration time of simple PLC segment 6	0.01s~65000s	Model dependent
FC-50	Acceleration time of simple PLC segment 7	0.01s~65000s	Model dependent
FC-51	Deceleration time of simple PLC segment 7	0.01s~65000s	Model dependent
FC-52	Acceleration time of simple PLC segment 8	0.01s~65000s	Model dependent
FC-53	Deceleration time of simple PLC segment 8	0.01s~65000s	Model dependent
FC-54	Acceleration time of simple PLC segment 9	0.01s~65000s	Model dependent
FC-55	Deceleration time of simple PLC segment 9	0.01s~65000s	Model dependent
FC-56	Acceleration time of simple PLC segment 10	0.01s~65000s	Model dependent
FC-57	Deceleration time of simple PLC segment 10	0.01s~65000s	Model dependent
FC-58	Acceleration time of simple PLC segment 11	0.01s~65000s	Model dependent
FC-59	Deceleration time of simple PLC segment 11	0.01s~65000s	Model dependent
FC-60	Acceleration time of simple PLC segment 12	0.01s~65000s	Model dependent
FC-61	Deceleration time of simple PLC segment 12	0.01s~65000s	Model dependent
FC-62	Acceleration time of simple PLC segment 13	0.01s~65000s	Model dependent
FC-63	Deceleration time of simple PLC segment 13	0.01s~65000s	Model dependent
FC-64	Acceleration time of simple PLC segment 14	0.01s~65000s	Model dependent
FC-65	Deceleration time of simple PLC segment 14	0.01s~65000s	Model dependent
FC-66	Acceleration time of simple PLC segment 15	0.01s~65000s	Model dependent
FC-67	Deceleration time of simple PLC segment 15	0.01s~65000s	Model dependent

Simple PLC can be either the frequency source or V/F separated voltage source.

Figure 6-26 is the figure when simple PLC is used as frequency source. When simple PLC is used as the frequency source, whether parameter values of FC-00 ~FC-15 are positive or negative determines the frequency inverter running direction. If the parameter values are negative, it indicates that the frequency inverter runs in reverse direction.

Figure 6-26Simple PLC when used as frequency source



When used as frequency source, there are three modes of simple PLC (FC-17). When as V/F separated voltage source, the simple PLC do not have these three modes.

- 0: Stop after the frequency inverter runs one cycle

The frequency inverter stops after running one cycle, and will not start up until receiving another command.

- 1: Keep final values after the frequency inverter runs one cycle

The frequency inverter keeps the final running frequency and direction after running one cycle.

- 2: Repeat after the frequency inverter runs one cycle

The frequency inverter automatically starts another cycle after running one cycle, and will not stop until receiving the stop command.

PLC retentive upon power failure (FC-18) indicates that the AC drive memorizes the PLC running moment and running frequency before power failure and will continue to run from the memorized moment after it is powered on again. If the unit's digit is set to 0, the AC drive restarts the PLC process after it is powered on again.

PLC retentive upon stop indicates that the AC drive records the PLC running moment and running frequency upon stop and will continue to run from the recorded moment after it starts up again. If the ten's digit is set to 0, the AC drive restarts the PLC process after it starts up again.


6.14 Group Fd: Swing Frequency, Fixed Length and Count

The swing frequency function is applied to the textile and chemical fiber fields where traversing and winding functions are required.

The swing frequency function indicates that the output frequency of the frequency inverter swings up and down with the setting frequency as the center. The trace of running frequency at the time axis is shown in the following figure.

The swing amplitude is set in Fd-00 and Fd-01. When Fd-01 is set to 0, the swing amplitude is 0 and the swing frequency does not work.

Figure 6-27 Swing frequency control



Function Code	Parameter Name	Setting Range	Default
Fd-00	Swing frequency setting mode	0: Relative to the central frequency 1: Relative to the maximum frequency	0

This parameter is used to select the basic value of the swing amplitude.

- 0: Relative to the central frequency (F0-10 frequency source selection)

It is variable swing amplitude system. The swing amplitude varies with the central frequency (setting frequency).

- 1: Relative to the maximum frequency (F0-03 maximum output frequency)

It is fixed swing amplitude system. The swing amplitude is fixed.

Function Code	Parameter Name	Setting Range	Default
Fd-01	Swing frequency amplitude	0.0%~100.0%	0.0%
Fd-02	jump frequency amplitude of Swing running	0.0%~50.0%	0.0%

This parameter is used to confirm the swing frequency amplitude and jump frequency amplitude of swing running.

- If swing frequency is relative to the central frequency (Fd-00 = 0), the actual swing amplitude **AW**= b0-10 (Frequency source) \times Fd-01(Swing frequency amplitude).
- If swing frequency is relative to the maximum frequency (Fd-00 = 1), the actual swing amplitude **AW**=F0-03 (Maximum frequency) \times Fd-01(Swing frequency amplitude).

The jump frequency is relative to the percentage of swing frequency amplitude. That is to say, jump frequency = Swing frequency running amplitude **AW** \times Fd-02 (Jump frequency amplitude).

- If Swing frequency amplitude is relative to the central frequency (Fd-00 = 0), the jump frequency is a variable value.
- If Swing frequency amplitude is relative to the maximum frequency (Fd-00 = 1), the jump frequency is a fixed value.

The swing frequency is limited by the frequency upper limit and frequency lower limit.

Function Code	Parameter Name	Setting Range	Default
Fd-03	Swing frequency cycle	0.1s~3000.0s	10.0s
Fd-04	Triangular wave rising time coefficient	0.1%~100.0%	50.0%

Fd-03 specifies the time of a complete swing frequency cycle.

Fd-04 specifies the time percentage of triangular wave rising time to Fd-03 (Swing frequency cycle).

- Triangular wave rising time = Fd-03 (Swing frequency cycle) \times Fd-04 (Triangular wave rising time coefficient, unit: s)
- Triangular wave falling time = Fd-03 (Swing frequency cycle) \times (1 – Fd-04 Triangular wave rising time coefficient ,unit: s)

Function Code	Parameter Name	Setting Range	Default
Fd-05	Set length	0m~65535 m	1000 m
Fd-06	Actual length	0m~65535 m	0 m
Fd-07	Number of pulses per meter	0.1~6553.5	100.0

The above parameters are used for fixed length control.

The length information is collected by DI terminals. Fd-06 (Actual length) is equal to the number of pulses collected by the DI terminal divides Fd-07 (Number of pulses each meter).

When the actual length Fd-06 exceeds the set length in Fd-05, the DO terminal set with function "Length reached" becomes ON.

During the fixed length control, the length reset operation can be performed via the DI terminal. For details, see the descriptions of F2-00 to F2-09.

Please set corresponding DI terminal with function 30 (Length count input) in applications. If the pulse frequency is high, HDI terminal must be used.

Function Code	Parameter Name	Setting Range	Default
Fd-08	Set count value	1~65535	1000
Fd-09	Designated count value	1~65535	1000

The count value needs to be collected by DI terminal. Set the corresponding DI terminal with function 28(Counter input) in applications. If the pulse frequency is high, HDI terminal must be used.

When the counting value reaches the set count value (Fd-08), the DO terminal set with function (Set count value reached) becomes ON. Then the counter stops counting.

When the counting value reaches the designated counting value (Fd-09), the DO terminal set with function (Designated count value reached) becomes ON. Then the counter continues to count until the set count value is reached.

6.15 Group d0: Motor Parameters

Function Code	Parameter Name	Setting Range	Default
d0-00	Rated motor power	0.1kw~1000.0 kW	Model dependent
d0-01	Rated motor voltage	1V~2000 V	Model dependent
d0-02	Rated motor current	0.01A~655.35 A (Frequency inverter power ≤ 55 kW) 0.1A~6553.5 A (Frequency inverter power ≥ 75 kW)	Model dependent
d0-03	Rated motor frequency	0.01 Hz~maximum frequency	Model dependent
d0-04	Rated motor rotational speed	1rpm~65535rpm	Model dependent

Set the parameters according to the motor nameplate no matter whether V/F control or vector control is adopted.

To achieve better V/F or vector control performance, motor auto-tuning is required. The motor auto-tuning accuracy depends on the correct setting of motor nameplate parameters.

Function Code	Parameter Name	Setting Range	Default

d0-05	Motor auto-tuning selection	0: No auto-tuning 1: Asynchronous motor static auto-tuning 2: Asynchronous motor complete auto-tuning 3: Asynchronous motor static complete auto-tuning	0
-------	-----------------------------	--	---

- 0: No auto-tuning

Auto-tuning is prohibited.

- 1: Asynchronous motor static auto-tuning

It is applicable to the asynchronous motor cannot be performed complete auto-tuning when the asynchronous motor cannot be taken apart from the load.

Before performing static auto-tuning, properly set the motor type and motor nameplate parameters of d0-00 ~ d0-04 firstly. The frequency inverter will obtain parameters of d0-06 ~ d0-08 by static auto-tuning.

Action guide: Set this parameter to 1, and press **RUN** key. Then, the frequency inverter implements static auto-tuning.

- 2: Asynchronous motor complete auto-tuning

Please select complete auto-tuning to ensure the dynamic control performance of inverter, at this time, the motor is disconnected from the load to keep no-load state. During the process of complete auto-tuning, the frequency inverter performs static auto-tuning first and then accelerates to 80% of the rated motor frequency within the acceleration time set in F0-20. The frequency inverter keeps running for a certain period and then decelerates to stop with deceleration time set in F0-21.

Before performing complete auto-tuning under FVC control mode, properly motor nameplate parameters of d0-00 to d0-04, encoder pulses per revolution (d0-11) and encoder type (d0-12).

The frequency inverter will obtain motor parameters of d0-06 ~ d0-10, A/B phase sequence of ABZ incremental encoder (d0-13) and vector control current loop PI parameters of d1-09 ~ d1-12 by complete auto-tuning.

Action guide: Set this parameter to 2, and press **RUN** key. Then, the frequency inverter starts complete auto-tuning.

- 3: Asynchronous motor static complete auto-tuning

This auto-tuning method is used when the motor cannot separate from the load, but still needs accurate motor parameters (such as lifting applications). The obtained parameters are same as complete auto-tuning.

Action guide: Set this parameter to 3, and press **RUN** key. Then the frequency inverter performs static complete auto-tuning. Please notice that slight vibration of motor occurs probably during this process.

Note: Motor auto-tuning can be performed only in operation panel mode and is invalid under terminal control and communication control modes.

Function Code	Parameter Name	Setting Range	Default
d0-06	Stator resistance (asynchronous motor)	0.001Ω~65.535 Ω (Frequency inverter power ≤ 55 kW) 0.0001Ω~6.5535 Ω (Frequency inverter power ≥ 75 kW)	Tuning parameter
d0-07	Rotor resistance (asynchronous motor)	0.001Ω~65.535 Ω (Frequency inverter power ≤ 55 kW) 0.0001Ω~6.5535 Ω (Frequency inverter power ≥ 75 kW)	Tuning parameter
d0-08	Leakage inductive reactance(asynchronous motor)	0.01mH~655.35 mH (Frequency inverter power ≤ 55 kW) 0.001mH~65.535 mH (Frequency inverter power ≥ 75 kW)	Tuning parameter

Function Code	Parameter Name	Setting Range	Default
d0-09	Mutual inductive reactance(asynchronous motor)	0.1mH~6553.5 mH (Frequency inverter power ≤ 55 kW) 0.01~655.35 mH (Frequency inverter power ≥75 kW)	Tuning parameter
d0-10	No-load current (asynchronous motor)	0.01A to d0-02 (Frequency inverter power ≤ 55 kW) 0.1A to d0-02 (Frequency inverter power ≥75 kW)	Tuning parameter

The parameters in d0-06 ~ d0-10 are asynchronous motor parameters. These parameters are usually unavailable on the motor nameplate and are obtained by means of motor auto-tuning. Only d0-06 ~ d0-08 can be obtained through static motor auto-tuning. Through complete motor auto-tuning, encoder phase sequence and current loop PI can be obtained besides the parameters in d0-06 ~ d0-10. Through static complete motor auto-tuning, current loop PI can be obtained besides the parameters in d0-06 ~ d0-10.

When the "Rated motor power" (d0-00) or "Rated motor voltage" (d0-01) is changed, the frequency inverter automatically restores values of d0-06 ~ d0-10, to restore setting of these 5 parameters according to common standard Y series asynchronous motor.

If it is impossible to perform motor auto-tuning onsite, manually set the values of these parameters according to data provided by the motor manufacturer.

Function Code	Parameter Name	Setting Range	Default
d0-11	Encoder pulses per revolution	1~32767	1024

This parameter is used to set the pulses per revolution (PPR) of ABZ or UVW incremental encoder. In VC mode, the motor cannot run properly if this parameter is set incorrectly.

Function Code	Parameter Name	Setting Range	Default
d0-12	Encoder type	0: ABZ incremental encoder 1: Resolver	0

FC155 supports two types of encoder. After installation of the PG card is complete, set this parameter properly based on the actual condition. Otherwise, the frequency inverter cannot run properly.

Function Code	Parameter Name	Setting Range	Default
d0-13	A/B phase sequence of ABZ incremental encoder	0: Forward 1: Reserve	0

This parameter is used to set the A/B phase sequence of the ABZ incremental encoder or the direction of resolver. The input direction of encoder can be obtained through asynchronous motor complete auto-tuning.

Function Code	Parameter Name	Setting Range	Default
d0-14	Number of pole pairs of resolver	1~99	1

If a resolver is applied, set the number of pole pairs properly.

Function Code	Parameter Name	Setting Range	Default
d0-15	Encoder wire-break fault detection time	0: No action 0.1s~10.0s	0.0s

This parameter is used to set the detecting time that a wire-break faults. If it is set to 0.0s, the frequency inverter does not detect the encoder wire-break fault. If the duration time of the encoder wire-break fault detected by the frequency inverter exceeds the time set in this parameter, the frequency inverter

reports Err20.

6.16 Group d1: Motor Vector Control Parameters


The Group d1 function codes are only valid for motor vector control. It is invalid for motor V/F control.

Function Code	Parameter Name	Setting Range	Default
d1-00	Speed loop proportional gain 1 (Kp1)	0.01~10.00	0.30
d1-01	Speed loop integral time 1 (Ti1)	0.01s~10.00s	0.50s
d1-02	Switchover frequency 1	0.00 to d1-05	5.00 Hz
d1-03	Speed loop proportional gain 2 (Kp2)	0.01~10.00	0.20
d1-04	Speed loop integral time 2 (Ti2)	0.01s~10.00s	1.00s
d1-05	Switchover frequency 2	d1-02 to maximum output frequency	10.00 Hz

Speed loop PI parameters vary with running frequencies of the frequency inverter.

- If the running frequency is less than or equal to "Switchover frequency 1" (d1-02), the speed loop PI parameters are d1-00 and d1-01.
- If the running frequency is equal to or greater than "Switchover frequency 2" (d1-05), the speed loop PI parameters are d1-03 and d1-04.
- If the running frequency is between d1-02 and d1-05, the speed loop PI parameters are obtained from the linear switchover between the two groups of PI parameters, as shown in Figure 6-28.

Figure 6-28 Relationship between running frequencies and PI parameters



The speed dynamic response characteristics in vector control can be adjusted by setting the proportional gain and integral time of the speed regulator.

To achieve a faster system response, increase the proportional gain and reduce the integral time. Be aware that this may lead to system oscillation. The recommended adjustment method is as follows:

If the factory setting cannot meet the requirements, make proper adjustment. Increase the proportional gain first to ensure that the system does not oscillate, and then reduce the integral time to ensure that the system has quick response and small overshoot.

Note: Improper PI parameter setting may cause too large speed overshoot, and overvoltage fault may even occur when the overshoot drops.

Function Code	Parameter Name	Setting Range	Default
d1-06	Speed loop integral property	0: Integral separation disable 1: Integral separation enable	0

Function Code	Parameter Name	Setting Range	Default
d1-07	ASR input filtering time	0~100	0

Function Code	Parameter Name	Setting Range	Default
d1-09	Excitation adjustment proportional gain	0~30000	1300
d1-10	Excitation adjustment integral gain	0~30000	1300
d1-11	Torque adjustment proportional gain	0~30000	1300
d1-12	Torque adjustment integral gain	0~30000	1300

These are current loop PI parameters for vector control. These parameters are automatically obtained through asynchronous motor completes auto-tuning, and need not be modified.

The dimension of the current loop integral regulator is integral gain rather than integral time. Note that too large current loop PI gain may lead to oscillation of the entire control loop. Therefore, when current oscillation or torque fluctuation is great, manually decrease the proportional gain or integral gain here.

Function Code	Parameter Name	Setting Range	Default
d1-13	torque upper limit source in speed control mode	0: d1-14 1: AI1 2: AI2 3: AI3 4: Pulse setting (HDI) 5: Communication setting	0
d1-14	Digital setting of torque limit	0.0%~200.0%	150.0%

In the speed control mode, the maximum output torque of the frequency inverter is restricted by d1-13. If the torque upper limit is analog, pulse or communication setting, 100% of the setting corresponds to the value of d1-14, and 100% of the value of d1-14 corresponds to the frequency inverter rated torque. For details on the AI1, AI2 and AI3 setting, see the description of the AI curves. For details on the pulse setting, see the description of F3-28 ~ F3-31.

Function Code	Parameter Name	Setting Range	Default
d1-15	Motor running slip gain	50%~200%	100%

For SFVC, it is used to adjust speed stability accuracy of the motor. When the motor with load runs at a very low speed, increase the value of this parameter; when the motor with load runs at a very fast speed, decrease the value of this parameter.

For CLVC, it is used to adjust the output current of the frequency inverter with same load.

6.17 Group d2: Torque Control Function

Function Code	Parameter Name	Setting Range	Default
d2-00	Speed/Torque control selection	0: Speed control 1: Torque control	0

It is used to select the frequency inverter's control mode: speed control or torque control.

FC155provides DI terminals with two torque related functions, function 21 (Torque control prohibited) and function 20 (Speed control/Torque control switchover). The two DI terminals need to be used together with d2-00 to implement speed control/torque control switchover.

If the DI terminal set with function 20 (Speed control/Torque control switchover) is OFF, the control mode is determined by d2-00. If the DI terminal set with function 20 is ON, the control mode is reverse to the value of d2-00.

However, if the DI terminal with function 21 (Torque control prohibited) is ON, the frequency inverter is fixed to run in the speed control mode.

Function Code	Parameter Name	Setting Range	Default
d2-01	Torque setting source in torque control	0: Digital setting (d2-02) 1: AI1 2: AI2 3: AI3 4: Pulse setting (HDI) 5: Communication setting 6: MIN (AI1, AI2) 7: MAX (AI1, AI2)	0
d2-02	Torque digital setting in torque control	-200.0% ~ 200.0%	100.0%

d2-01 is used to set the torque setting source. There are a total of eight torque setting sources.

The torque setting is a relative value. 100.0% corresponds to the frequency inverter's rated torque. The setting range is -200.0% ~ 200.0%, indicating the frequency inverter's maximum torque is twice of the frequency inverter's rated torque.

If the torque setting is positive, the frequency inverter rotates in forward direction. If the torque setting is negative, the frequency inverter rotates in reverse direction.

- 0: Digital setting (d2-02)

The target torque directly uses the value set in d2-02.

- 1: AI1
- 2: AI2
- 3: AI3

The target torque is decided by analog input. FC155 control board provides two AI terminals (AI1, AI2). Another AI terminal (AI3) is provided by the I/O extension card.

AI1 is 0V~10 V voltage input or 4mA~20mA current input decided by jumper J2 on the control board.

AI2 is 0V~10 V voltage input or 4mA~20mA current input decided by jumper J3 on the control board.

AI3 is -10 V ~ +10 V voltage input.

For the details of AI Curve setting, please refer to the description of Group F3 analog input parameters.

When AI is used as frequency setting source, the corresponding value 100% of voltage/ current input corresponds to the value of d2-02.

- 4: Pulse setting (HDI)

The target torque is set by HDI (high-speed pulse).

The pulse setting signal specification is 9V~30 V (voltage range) and 0 kHz~100 kHz (frequency range).

The pulse can only be input via HDI.

The relationship (which is a two-point line) between HDI input pulse frequency and the corresponding value is set in F3-28~F3-31. The corresponding value 100.0% of pulse input corresponds to the percentage of d2-02.

- 5: Communication setting

The target torque is set by means of communication.

Function Code	Parameter Name	Setting Range	Default
d2-05	Forward maximum frequency in torque control	0.00 Hz ~ maximum frequency (F0-03)	50.00 Hz
d2-06	Reverse maximum frequency in torque control	0.00 Hz ~ maximum frequency (F0-03)	50.00 Hz

The two parameters are used to set the maximum frequency in forward or reverse rotation in torque

control mode.

In torque control, if the load torque is smaller than the motor output torque, the motor's rotational speed will rise continuously. To avoid runaway of the mechanical system, the motor maximum rotating speed must be limited in torque control.

You can implement continuous change of the maximum frequency in torque control dynamically by controlling the frequency upper limit.

Function Code	Parameter Name	Setting Range	Default
d2-07	Acceleration time in torque control	0.00s~120.00s	0.10s
d2-08	Deceleration time in torque control	0.00s~120.00s	0.10s

In torque control, the difference between the motor output torque and the load torque determines the speed change rate of the motor and load. The motor rotational speed may change quickly and this will result in noise or too large mechanical stress. The setting of acceleration/deceleration time in torque control makes the motor rotational speed change softly.

However, in applications requiring rapid torque response, set the acceleration/deceleration time in torque control to 0.00s. For example, two frequency inverters are connected to drive the same load. To balance the load allocation, set one frequency inverter as master in speed control and the other as slave in torque control. The slave receives the master's output torque as the torque command and must follow the master rapidly. In this case, the acceleration/deceleration time of the slave in torque control is set to 0.0s.

6.18 Group d3: V/F Control Parameters

Group d3 is valid only for V/F control, invalid for vector control.

The V/F control mode is applicable to general used load applications (fan or pump) or applications where one frequency inverter operates multiple motors or there is a large difference between the frequency inverter power and the motor power.

Function Code	Parameter Name	Setting Range	Default
d3-00	V/F curve setting	0: Linear V/F 1: Multi-point V/F 2: Square V/F 3: 1.2-power V/F 4: 1.4-power V/F 6: 1.6-power V/F 8: 1.8-power V/F 10: V/F complete separation 11: V/F half separation	0

- 0: Linear V/F

It is applicable to common constant torque load.

- 1: Multi-point V/F

It is applicable to special loads such as dehydrator and centrifuge. Any relationship V/F curve can be obtained by setting parameters of d3-03 ~ d3-08.

- 2: Square V/F

It is applicable to centrifugal loads such as fan and pump.

- 3 ~ 8: V/F curve between linear V/F and square V/F

- 10: V/F complete separation

In this mode, the output frequency and output voltage of the frequency inverter are independent. The output frequency is determined by the frequency source, and the output voltage is determined by "Voltage source for V/F separation" (d3-11).

It is applicable to induction heating, inverse power supply and torque motor control.

- 11: V/F half separation

In this mode, V and F are proportional and the proportional relationship can be set in d3-11. The relationship between V and F are also related to the "rated motor voltage" and "rated motor frequency".

Assume that the voltage source input is X (0% ~100%), the relationship between V and F is:
 $V/F = 2 \times X \times (\text{Rated motor voltage}) / (\text{Rated motor frequency})$

Function Code	Parameter Name	Setting Range	Default
d3-01	Torque boost	0.0% (fixed torque boost) 0.1%~30.0%	Model dependent
d3-02	Cut-off frequency of torque boost	0.0%~80.0% Actual cut-off frequency=Motor rated frequency×d3-02	50.0%


To compensate the low frequency torque characteristics of V/F control, you can boost the output voltage of the frequency inverter at low frequency by modifying d3-01.

If the torque boost is set to too large, the motor is easily overheated, and the frequency inverter easily suffers over current.

If the load is large and the motor startup torque is insufficient, increase the value of d3-01. If the load is small, decrease the value of d3-01. If it is set to 0.0, the frequency inverter performs automatic torque boost. In this case, the frequency inverter automatically calculates the torque boost value based on motor parameters including the stator resistance.

d3-02 specifies torque boost is valid when the running frequency is lower than this setting frequency. Torque boost becomes invalid when this frequency is exceeded, as shown in the following figure.

Figure 6-29 Manual torque boost




Function Code	Parameter Name	Setting Range	Default
d3-03	Multi-point V/F frequency 1 (F1)	0.00 Hz ~ d3-05	0.00 Hz
d3-04	Multi-point V/F voltage 1 (V1)	0.0%~100.0%	0.0%
d3-05	Multi-point V/F frequency 2 (F2)	d3-03 to d3-07	0.00 Hz
d3-06	Multi-point V/F voltage 2 (V2)	0.0%~100.0%	0.0%
d3-07	Multi-point V/F frequency 3 (F3)	d3-05 ~ maximum frequency (F0-03)	0.00 Hz
d3-08	Multi-point V/F voltage 3 (V3)	0.0%~100.0%	0.0%

When d3-00 set to 1, these six parameters are used to define the multi-point V/F curve.

The multi-point V/F curve is set based on the motor's load characteristic. The relationship between voltages and frequencies is: V1 < V2 < V3, F1 < F2 < F3. Figure 6-30 shows the setting of multi-point V/F curve.

At low frequency too higher voltage setting may cause motor overheat or even burnt and cause frequency inverter over current stall or over current protection.

Figure 6-30 Setting of multi-point V/F curve



V1-V3: 1st, 2nd and 3rd voltage percentages of multi-point V/F

Vb: Rated motor voltage

f1-f3: 1st, 2nd and 3rd frequency percentages of multi-point V/F

fb: Rated motor running frequency

Function Code	Parameter Name	Setting Range	Default
d3-09	V/F slip compensation gain	0.0%~200.0%	0.0%

This parameter is valid only for the asynchronous motor.

It can compensate the rotational speed slip of the asynchronous motor when the load of the motor increases, stabilizing the motor speed in case of load change.

If this parameter is set to 100%, it indicates that the slip compensation when the motor drives rated load is the rated motor slip. The rated motor slip is automatically obtained by the frequency inverter through calculation based on the rated motor frequency and rated motor speed in group d0.

Generally, if the motor rotational speed is different from the target speed, slightly adjust this parameter.

Function Code	Parameter Name	Setting Range	Default
d3-10	Oscillation suppression gain	0~100	0

The setting method for this parameter is to set as small as possible on the premise of effective oscillation suppression, to avoid the bad effect for V/F running. When there is no oscillation of the motor, please set the gain to 0. Only when there is obvious oscillation of the motor, you can increase the gain properly. The larger the gain is, more obviously the effect of oscillation suppression is.

When the oscillation suppression function is used, the parameters of motor rated current and no-load current must be set correctly, or the effect of oscillation suppression is poor.

Function Code	Parameter Name	Setting Range	Default
d3-11	Voltage source for V/F separation	0: Digital setting(d3-13) 1: AI1 2: AI2 3: AI3 4: Pulse setting(HDI) 5: Multi-function 6: Simple PLC 7: PID 8: Communication setting Note:100.0% corresponds to the rated motor voltage	0
d3-12	Voltage digital setting for V/F separation	0 V ~ rated motor voltage	0 V

V/F separation is generally applicable to these sites, such as induction heating, dc-ac power supply and

motor torque control.

If V/F separation control is enabled, the output voltage can be set in d3-12 or by analog, Multi-function, simple PLC, PID or communication. If you set the output voltage by means of non-digital setting, 100% of the setting corresponds to the rated motor voltage. If a negative percentage is set, its absolute value is used as the effective value.

- 0: Digital setting (d3-12)

The output voltage is set directly in d3-12.

- 1: AI1;
- 2: AI2;
- 3: AI3

The output voltage is set by analog input terminals.

- 4: Pulse setting (HDI)

The output voltage is set by pulses of the terminal HDI.

Pulse setting specification: voltage range 9V~30 V, frequency range 0kHz~100 kHz

- 5: Multi-function
- 6: Simple PLC

If the voltage source is simple PLC mode, parameters in group FC must be set to determine the setting output voltage.

- 7: PID

The output voltage is generated based on PID closed loop. For details, see the description of PID in group Fb.

- 8: Communication setting


The output voltage is set by the host computer by means of communication.

The voltage source for V/F separation is selected in the similar way to the frequency source selection. For details, see F0-10 (main frequency source X specification). 100.0% of the setting in each mode corresponds to the rated motor voltage. If the corresponding value is negative, its absolute value is used.

Function Code	Parameter Name	Setting Range	Default
d3-13	Voltage rise time of V/F separation	0.0s~1000.0s	0.0s

d3-13 indicates the time required for the output voltage to rise from 0 V to the rated motor voltage shown as t1 in the figure 6-31.

Figure 6-31 Voltage of V/F separation



6.19 Group d4: Control Optimization Parameters

Function Code	Parameter Name	Setting Range	Default
d4-00	Carrier frequency	0.5kHz~16.0 kHz	Model dependent

It is used to adjust the carrier frequency of the frequency inverter, helping to reduce the motor noise, avoiding the resonance of the mechanical system, and reducing the leakage current to earth and interference generated by the frequency inverter.

If the carrier frequency is low, output current has high harmonic wave, and then the motor will increase power loss and temperature rising.

If the carrier frequency is higher, the power loss and temperature rising of the motor will decline. However, the frequency inverter will have an increasing in power loss, temperature rising and interference.

Adjusting the carrier frequency will exert influences on the aspects listed in the following table.

The factory setting of carrier frequency varies with the frequency inverter power. If you need to modify the carrier frequency, note that if the set carrier frequency is higher than factory setting, it will lead to an increase in temperature rise of the frequency inverter's heatsink. In this case, you need to de-rate the frequency inverter. Otherwise, the frequency inverter may overheat and alarm.

Carrier frequency	Low→High
Motor noise	Large→Small
Output current	Bad→Good
Motor temperature rising	High→Low
Frequency inverter	Low→High
Leakage current	Small→Large
External radiation interference	Small→Large

Function Code	Parameter Name	Setting Range	Default
d4-01	DPWM switchover frequency upper limit	0.00Hz~15.00 Hz	12.00 Hz

This parameter is valid only for V/F control.

It is used to determine the wave modulation mode in V/F control of asynchronous motor. If the frequency is lower than the value of this parameter, the waveform is 7-segment continuous modulation. If the frequency is higher than the value of this parameter, the waveform is 5-segment intermittent modulation.

The 7-segment continuous modulation causes more wastage of IGBT switches of the frequency inverter but smaller current ripple. The 5-segment intermittent modulation causes less wastage of IGBT switches of the frequency inverter but larger current ripple. This parameter may lead to motor running instability at high frequency. Do not modify this parameter generally.

For instability of V/F control, refer to parameter d3-10. For wastage of frequency inverter and temperature rising, please refer to parameter d4-00.

Function Code	Parameter Name	Setting Range	Default
d4-02	PWM modulation mode	0: Asynchronous modulation 1: Synchronous modulation	0

This parameter is valid only for V/F control.

Synchronous modulation indicates that the carrier frequency varies linearly with the change of the output frequency, ensuring that the ratio of carrier frequency to output frequency remains unchanged. Synchronous modulation is generally used at high output frequency, which helps improve the output voltage quality.

At low output frequency (100 Hz or lower), synchronous modulation is not required. This is because ratio of carrier frequency to output frequency is still high, and asynchronous modulation is more superior at such low running frequency.

Synchronous modulation takes effect only when the running frequency is higher than 85 Hz. If the frequency is lower than 85 Hz, asynchronous modulation is always valid.

Function Code	Parameter Name	Setting Range	Default
d4-03	Carrier frequency adjustment with temperature	0: No 1: Yes	0

It is used to set whether the carrier frequency is adjusted based on the temperature. The frequency inverter automatically reduces the carrier frequency to decrease its temperature when detecting that the heatsink temperature is high. The frequency inverter restores the carrier frequency to the set value when the heatsink temperature becomes normal. This function is used to reduce the overheat alarms.

Function Code	Parameter Name	Setting Range	Default
d4-04	Random PWM depth	0: Random PWM invalid 1~10: Random PWM carrier frequency depth	0

The setting of random PWM depth can make the motor shrill noise to soft and reduce the electromagnetic interference to other equipment. If this parameter is set to 0, random PWM is invalid. Regulating the value of this parameter will get different result.

Function Code	Parameter Name	Setting Range	Default
d4-05	Dead zone compensation mode selection	0: No compensation 1: Compensation mode 1 2: Compensation mode 2	1

Generally, you need not modify this parameter. Try to use a different compensation mode only when there is special requirement on the output voltage waveform quality or oscillation occurs on the motor.

Function Code	Parameter Name	Setting Range	Default
d4-06	SFVC mode selection	0: SFVC mode 1 1: SFVC mode 2	2

SFVC mode 1: Used in the application that high speed stability required.

SFVC mode 2: Used in the application that high torque control linearity required.

Chapter 7 EMC (Electromagnetic compatibility)

7.1 Definition

Electromagnetic compatibility is the ability of the electric equipment to run in the electromagnetic interference environment and implement its function stably without interferences on the electromagnetic environment.

7.2 EMC Standard Description

In accordance with the requirements of the national standard GB/T12668.3, the inverter needs to comply with electromagnetic interference and anti-electromagnetic interference requirements.

The existing products of our company apply the latest international standard—IEC/EN61800-3: 2004 (Adjustable speed electrical power drive systems part 3: EMC requirements and specific test methods), which is equivalent to the national standard GB/T12668.3.

IEC/EN61800-3 assesses the inverter in terms of electromagnetic interference and anti-electronic interference. Electromagnetic interference mainly tests the radiation interference, conduction interference and harmonics interference on the inverter (required for the inverter for civil use)Anti-electromagnetic interference mainly tests the conduction interference rejection, radiation interference rejection, surge interference rejection, fast and mutable pulse group interference rejection, ESD interference rejection and power low frequency end interference rejection (specific test items including: 1. Interference rejection tests of input voltage sag, interrupt and change; 2. Phase conversion interference rejection test; 3. Harmonic input interference rejection test; 4. Input frequency change test; 5. Input voltage unbalance test; 6. input voltage fluctuation test).

The tests shall be conducted strictly in accordance with the above requirements of IEC/ EN61800-3, and the products of our company are installed and used according to Section 7.3 and have good electromagnetic compatibility in general industry environment.

7.3 EMC Guide

7.3.1 Harmonic Effect

Higher harmonics of power supply may damage the inverter. Thus, at some places where mains quality is rather poor, it is recommended to install AC input reactor.

7.3.2 Electromagnetic Interference and Installation Precautions

There are two kinds of electromagnetic interferences, one is interference of electromagnetic noise in the surrounding environment on the inverter, and the other is interference of inverter on the surrounding equipment.

Installation precautions:

- 1) The earth wires of the frequency inverter and other electric products shall be well grounded;
- 2) The power input and output power cables of the inverter and weak current signal cables (e.g. control line) shall not be arranged in parallel and vertical arrangement is preferable.
- 3) It is recommended that the output power cables of the inverter employ shield cables or steel pipe shielded cables and that the shielding layer be earthed reliably. The lead cables of the equipment suffering interferences are recommended to employ twisted-pair shielded control cables, and the

shielding layer shall be earthed reliably.

- 4) When the length of motor cable is longer than 100 meters, it needs to install output filter or reactor.

7.3.3 Handling method for the interferences of the surrounding equipment on the inverter:

The electromagnetic interference on the inverter is generated because plenty of relays, contactors and electromagnetic brakes are installed near the inverter. When the inverter has error action due to the interferences, the following measures can be taken:

- 1) Install surge suppressor on the devices generating interference;
- 2) Install filter at the input end of the inverter. Refer to Section 7.3.6 for the specific operations.
- 3) The lead cables of the control signal cable of the inverter and the detection line employ shielded cable and the shielding layer shall be earthed reliably.

7.3.4 Handling method for the interferences of frequency inverter on the surrounding equipment:

These interferences include two types: one is radiation interference of the inverter, and the other is conduction interference of the inverter. These two types of interferences cause the surrounding electric equipment to suffer electromagnetic or electrostatic induction. The surrounding equipment hereby produces error action. For different interferences, it can be handled by referring to the following methods:

- 1) For the measuring meters, receivers and sensors, their signals are generally weak. If they are placed nearby the inverter or together with the inverter in the same control cabinet, they are easy to suffer interference and thus generate error actions. It is recommended to handle with the following methods: Put in places far away from the interference source; do not arrange the signal cables with the power cables in parallel and never bind them together; both the signal cables and power cables employ shielded cables and are well earthed; install ferrite magnetic ring (with suppressing frequency of 30 to 1,000MHz) at the output side of the inverter and wind it 2 to 3 cycles; install EMC output filter in more severe conditions.
- 2) When the equipment suffering interferences and the inverter use the same power supply, it may cause conduction interference. If the above methods cannot remove the interference, it shall install EMC filter between the inverter and the power supply (refer to Section 7.3.6 for the prototyping operation); the surrounding equipment is separately earthed, which can avoid the interference caused by the leakage current of the inverter's earth wire when common earth mode is adopted.
- 3) The surrounding equipment is separately earthed, which can avoid the interference caused by the leakage current of the inverter's earth wire when common earth mode is adopted.

7.3.5 Leakage current and handling

There are two forms of leakage current when using the inverter. One is leakage current to the earth, and the other is leakage current between the cables.

- 1) Factors influencing the leakage current to the earth and the solutions:

There are distributed capacitance between the lead cables and the earth. The larger the distributed capacitance is, the larger the leakage current will be. The distributed capacitance can be reduced by effectively reducing the distance between the inverter and the motor. The higher the carrier frequency is, the larger the leakage current will be. The leakage current can be reduced by reducing the carrier frequency. However, reducing the carrier frequency may result in addition of motor noise. Note that

additional installation of reactor is also an effective method to remove the leakage current.

The leakage current may increase following the addition of circuit current. Therefore, when the motor power is high, the corresponding leakage current will be high too.

2) Factors of producing leakage current between the cables and solutions:

There is distributed capacitance between the output cables of the inverter. If the current passing the lines has higher harmonic, it may cause resonance and thus result in leakage current. If thermal relay is used, it may generate error action.

The solution is to reduce the carrier frequency or install output reactor. It is recommended that thermal relay not be installed before the motor when using the inverter, and that electronic over current protection function of the inverter be used instead.

7.3.6 Precautions for Installing EMC input filter at the input end of power supply

- 1) When using the inverter, please follow its rated values strictly. Since the filter belongs to Classification I electric appliances, the metal enclosure of the filter shall be large and the metal ground of the installing cabinet shall be well earthed and have good conduction continuity. Otherwise there may be danger of electric shock and the EMC effect may be greatly affected.
- 2) Through the EMC test, it is found that the filter ground must be connected with the PE end of the inverter at the same public earth. Otherwise the EMC effect may be greatly affected.
- 3) The filter shall be installed at a place close to the input end of the power supply as much as possible.

Chapter 8 Fault Diagnosis and Solution

8.1 Fault Alarm and Countermeasures

FC155 inverter has 24 types of warning information and protection function. In case of abnormal fault, the protection function will be invoked, the inverter will stop output, and the faulty relay contact of the inverter will start, and the fault code will be displayed on the display panel of the inverter. Before consulting the service department, the user can perform self-check according to the prompts of this chapter, analyze the fault cause and find out the solution. If the fault is caused by the reasons as described in the dotted frame, please consult the agents of inverter or our company directly. Among the 21 types of warning information, Err22 is hardware over current or over voltage signal. In most cases, the hardware over voltage fault will cause Err22 alarm.

Table 8-1 Common faults and solution of the frequency inverter

Fault Name	Display	Possible Causes	Solutions
Inverter unit protection	Err01	1: The output circuit is grounded or short circuited. 2: The connecting cable of the motor is too long. 3: The IGBT overheat. 4: The internal connections become loose. 5: The main control board is faulty. 6: The drive board is faulty. 7: The inverter IGBT is faulty.	1: Eliminate external faults. 2: Install a reactor or an output filter. 3: Check the air filter and the cooling fan. 4: Connect all cables properly. 5: Ask for technical support 6: Ask for technical support 7: Ask for technical support
Over current during acceleration	Err02	1: The output circuit is grounded or short circuited. 2: Motor auto-tuning is not performed. 3: The acceleration time is too short. 4: Manual torque boost or V/F curve is not appropriate. 5: The voltage is too low. 6: The startup operation is performed on the rotating motor. 7: A sudden load is added during acceleration. 8: The frequency inverter model is of too small power class.	1: Eliminate external faults. 2: Perform the motor auto-tuning. 3: Increase the acceleration time. 4: Adjust the manual torque boost or V/F curve. 5: Adjust the voltage to normal range. 6: Select rotational speed tracking restart or start the motor after it stops. 7: Remove the added load. 8: Select a frequency inverter of higher power class.

Fault Name	Display	Possible Causes	Solutions
Over current during deceleration	Err03	1: The output circuit is grounded or short circuited. 2: Motor auto-tuning is not performed. 3: The deceleration time is too short. 4: The voltage is too low. 5: A sudden load is added during deceleration. 6: The braking unit and braking resistor are not installed.	1: Eliminate external faults. 2: Perform the motor auto-tuning. 3: Increase the deceleration time. 4: Adjust the voltage to normal range. 5: Remove the added load. 6: Install the braking unit and braking resistor.
Over current at constant speed	Err04	1: The output circuit is grounded or short circuited. 2: Motor auto-tuning is not performed. 3: The voltage is too low. 4: A sudden load is added during operation. 5: The frequency inverter model is of too small power class.	1: Eliminate external faults. 2: Perform the motor auto-tuning. 3: Adjust the voltage to normal range. 4: Remove the added load. 5: Select a frequency inverter of higher power class.
Overvoltage during acceleration	Err05	1: The input voltage is too high. 2: An external force drives the motor during acceleration. 3: The acceleration time is too short. 4: The braking unit and braking resistor are not installed.	1: Adjust the voltage to normal range. 2: Cancel the external force or install a braking resistor. 3: Increase the acceleration time. 4: Install the braking unit and braking resistor.
Overvoltage during deceleration	Err06	1: The input voltage is too high. 2: An external force drives the motor during deceleration. 3: The deceleration time is too short. 4: The braking unit and braking resistor are not installed.	1: Adjust the voltage to normal range. 2: Cancel the external force or install the braking resistor. 3: Increase the deceleration time. 4: Install the braking unit and braking resistor.
Overvoltage at constant speed	Err07	1: The input voltage is too high. 2: An external force drives the motor during deceleration.	1: Adjust the voltage to normal range. 2: Cancel the external force or install the braking resistor.
Control power supply fault	Err08	The input voltage is not within the allowable range.	Adjust the input voltage to the allowable range.

Fault Name	Display	Possible Causes	Solutions
Low voltage	Err09	1: Instantaneous power failure occurs on the input power supply. 2: The frequency inverter's input voltage is not within the allowable range. 3: The DC bus voltage is abnormal. 4: The rectifier bridge and buffer resistor are faulty. 5: The drive board is faulty. 6: The main control board is faulty.	1: Reset the fault. 2: Adjust the voltage to a normal range. 3: Ask for technical support. 4: Ask for technical support. 5: Ask for technical support. 6: Ask for technical support.
Frequency inverter overload	Err10	1: The load is too heavy or locked-rotor occurs on the motor. 2: The frequency inverter model is of too small power class.	1: Reduce the load and check the motor and mechanical condition. 2: Select a frequency inverter of higher power class.
Motor overload	Err11	1: F8-02 is set improperly. 2: The load is too heavy or locked-rotor occurs on the motor. 3: The frequency inverter model is of too small power class.	1: Set F8-02 correctly. 2: Reduce the load and check the motor and mechanical condition. 3: Select a frequency inverter of higher power class.
Power input phase loss	Err12	1: The three-phase power input is abnormal. 2: The drive board is faulty. 3: The lightning proof board is faulty. 4: The main control board is faulty.	1: Eliminate external faults. 2: Ask for technical support. 3: Ask for technical support. 4: Ask for technical support.
Power output phase loss	Err13	1: The cable connecting the frequency inverter and the motor is faulty. 2: The frequency inverter's three-phase outputs are unbalanced when the motor is running. 3: The drive board is faulty. 4: The IGBT module is faulty.	1: Eliminate external faults. 2: Check whether the motor three-phase winding is normal. 3: Ask for technical support. 4: Ask for technical support.
IGBT Module overheating	Err14	1: The ambient temperature is too high. 2: The air filter is blocked. 3: The fan is damaged. 4: The thermally sensitive resistor of the IGBT module is damaged. 5: The inverter IGBT module is damaged.	1: Lower the ambient temperature. 2: Clean the air filter. 3: Replace the damaged fan. 4: Replace the damaged thermally sensitive resistor. 5: Replace the inverter module.
External equipment fault	Err15	1: External fault signal is input via DI. 2: External fault signal is input via virtual I/O.	1: Reset the operation. 2: Reset the operation.

Fault Name	Display	Possible Causes	Solutions
Communication fault	Err16	1: The host computer is in abnormal state. 2: The communication cable is faulty. 3: The communication extension card is set improperly. 4: The communication parameters in group FA are set improperly.	1: Check the cabling of host computer. 2: Check the communication cabling. 3: Set the communication extension card correctly. 4: Set
Contactor fault	Err17	1: The drive board and power supply are faulty. 2: The contactor is faulty.	1: Replace the faulty drive board or power supply board. 2: Replace the contactor.
Current detection fault	Err18	1: The HALL device is faulty. 2: The drive board is faulty.	1: Replace the faulty HALL device. 2: Replace the faulty drive board.
Motor auto-tuning fault	Err19	1: The motor parameters are not set according to the nameplate. 2: The motor auto-tuning times out.	1: Set the motor parameters according to the nameplate properly. 2: Check the cable connecting the Frequency inverter and the motor.
Encoder fault	Err20	1: The encoder type is incorrect. 2: The cable connection of the encoder is incorrect. 3: The encoder is damaged. 4: The PG card is faulty.	1: Set the encoder type correctly based on the actual situation. 2: Eliminate external faults. 3: Replace the damaged encoder. 4: Replace the faulty PG card.
EEPROM read- write fault	Err21	The EEPROM chip is damaged.	Replace the main control board.
Frequency inverter hardware fault	Err22	1: Overvoltage exists. 2: Over current exists.	1: Handle based on overvoltage. 2: Handle based on over current.
Short circuit to ground	Err23	The motor is short circuited to the ground.	Replace the cable or motor.
Accumulative running time reached	Err26	The accumulative running time reaches the setting value.	Clear the record through parameter F7-19.
User-defined fault 1	Err27	1: The signal of user-defined fault 1 is input via DI. 2: The signal of user-defined fault 1 is input via virtual I/O.	1: Reset the operation. 2: Reset the operation.
User-defined fault 2	Err28	1: The signal of user-defined fault 2 is input via DI. 2: The signal of user-defined fault 2 is input via virtual I/O.	1: Reset the operation. 2: Reset the operation.

Fault Name	Display	Possible Causes	Solutions
Accumulative power-on time reached	Err29	The accumulative power-on time reaches the setting value.	Clear the record through parameter F7-19.
Off load	Err30	The frequency inverter running current is lower than the setting value.	Check that the load is disconnected or the parameter setting is correct.
PID feedback lost during running	Err31	The PID feedback is lower than the setting of Fb-26.	Check the PID feedback signal or set Fb-26 to a proper value.
By wave current limiting fault	Err40	1: The load is too heavy or locked-rotor occurs on the motor. 2: The frequency inverter model is of too small power class.	1: Reduce the load and check the motor and mechanical condition. 2: Select a frequency inverter of higher power class.
Motor switchover fault during running	Err41	Change the selection of the motor via terminal during running of the frequency inverter.	Perform motor switchover after the frequency inverter stops.
Too large speed deviation	Err42	1: The encoder parameters are set incorrectly. 2: The motor auto-tuning is not performed. 3: The detection parameters of too large speed deviation are set incorrectly.	1: Set the encoder parameters properly. 2: Perform the motor auto-tuning. 3: Set the detection parameters correctly based on the actual situation.
Motor over-speed	Err43	1: The encoder parameters are set incorrectly. 2: The motor auto-tuning is not performed. 3: The over-speed detection parameters are set incorrectly.	1: Set the encoder parameters properly. 2: Perform the motor auto-tuning. 3: Set the over-speed detection parameters correctly based on the actual situation.
Motor overheating	Err45	1: The cabling of the temperature sensor becomes loose. 2: The motor temperature is too high.	1: Check the temperature sensor cabling and eliminate the cabling fault. 2: Lower the carrier frequency or adopt other heat radiation

8.2 Common Faults and Solutions

You may come across the following faults during the use of the frequency inverter. Refer to the following table for simple fault analysis.

Table 8-2 Troubleshooting to common faults of the frequency inverter

S/N	Fault	Possible Causes	Solutions
1	There is no display at power-on.	1: There is no power supply to the frequency inverter or the power input to the frequency inverter is too low. 2: The power supply of the switch on the drive board of the frequency inverter is faulty. 3: The rectifier bridge is damaged. 4: The control board or the operation panel is faulty. 5: The cable connecting the control board and the drive board and the operation panel loose or breaks.	1: Check the power supply. 2: Check the DC bus voltage. 3: Check the internal wiring plug 4: Change a keypad 5: Ask for technical support.
2	"300" is displayed at power-on.	1: The cable between the drive board and the control board is in poor contact. 2: Related components on the control board are damaged. 3: The motor or the motor cable is short circuited to the ground. 4: The HALL device is faulty. 5: The power input to the frequency inverter is too low.	1: Check the wiring 2: Ask for technical support.
3	"Err23" is displayed at power-on.	1: The motor or the motor output cable is short-circuited to the ground. 2: The frequency inverter is damaged.	1: Measure the insulation of the motor and the output cable with a megger. 2: Ask for technical support.
4	The frequency inverter display is normal after power-on. But "-300-" is displayed after running and stops immediately.	1: The cooling fan is damaged or locked-rotor occurs. 2: The external control terminal cable is short circuited.	1: Replace the damaged fan. 2: Eliminate external fault.
5	Err14 (IGBT module overheat) fault is reported frequently.	1: The setting of carrier frequency is too high. 2: The cooling fan is damaged, or the air filter is blocked. 3: Components inside the frequency inverter are damaged (thermal coupler or others).	1: Reduce the carrier frequency (d4-00). 2: Replace the fan and clean the air filter. 3: Ask for technical support.
6	The motor does not rotate after the frequency inverter runs.	1: Check the motor and the motor cables. 2: The frequency inverter parameters are set improperly (motor parameters). 3: The cable between the drive board and the control board is in poor contact. 4: The drive board is faulty.	1: Ensure the cable between the Frequency inverter and the motor is normal. 2: Replace the motor or clear mechanical faults. 3: Check and re-set motor parameters.

S/N	Fault	Possible Causes	Solutions
7	The DI terminals are disabled.	1: The parameters are set incorrectly. 2: The external signal is incorrect. 3: The jumper bar across OP and +24 V becomes loose. 4: The control board is faulty.	1: Check and reset the parameters in group F2. 2: Re-connect the external signal cables. 3: Re-confirm the jumper bar across OP and +24 V. 4: Ask for technical support.
8	The motor speed is always low in VC mode.	1: The encoder is faulty. 2: The encoder cable is connected incorrectly or in poor contact. 3: The PG card is faulty. 4: The drive board is faulty.	1: Replace the encoder and ensure the cabling is proper. 2: Replace the PG card. 3: Ask for technical support.
9	The frequency inverter reports overcurrent and overvoltage frequently.	1: The motor parameters are set improperly. 2: The acceleration/deceleration time is improper. 3: The load fluctuates.	1: Re-set motor parameters or re-perform the motor auto-tuning. 2: Set proper acceleration/deceleration time. 3: Ask for technical support.
10	Err17 is reported of power-on or running.	The soft startup contactor is not sucked up.	1: Check whether the contactor cable is loose. 2: Check whether the contactor is faulty. 3: Check whether 24 V power supply of the contactor is faulty. 4: Ask for technical support.
11	0.0.0.0 is displayed of power-on.	Related component on the control board is damaged.	Replace the control board.

Appendix A Modbus communication protocol

FC155 series of inverter provides RS485 communication interface, and adopts MODBUS communication protocol. User can carry out centralized monitoring through PC/PLC to get operating requirements. And user can set the running command, modify or read the function codes, the working state or fault information of frequency inverter by Modbus communication protocol.

A.1 About Protocol

This serial communication protocol defines the transmission information and use format in the series communication and it includes master-polling (or broadcasting) format, master coding method and the content includes function code of action, transferring data and error checking. The response of slave is the same structure, and it includes action confirmation, returning the data and error checking etc. If slave takes place the error while it is receiving the information or cannot finish the action demanded by master, it will send one fault signal to master as a response.

A.2 Application Methods

The frequency inverter will be connected into a “Single-master Multi-slave” PC/PLC control net with RS485 bus as the communication slave.

A.3 Bus structure

(1) Hardware interface.


The “485+” and “485-“terminals on frequency inverter are the communication interfaces of Modbus

(2) Topological mode

It is a “Single-master Multi-slave” system. In this network, every communication machine has a unique slave address. One of them is as “master” (usually PC host machine, PLC and HMI, etc.), actively sends out the communication, to read or write the parameters of slave. Other machines will be used as slave and response to the inquiry/command from master. At one time only one machine can send the data and other machines are in the receiving status. The setup range of slave address is 0 to 247. Zero refers to broadcast communication address. The address of slave must is exclusive in the network.

(3) Transmission mode

There provide asynchronous series and half-duplex transmission mode. In the series asynchronous communication, the data is sent out frame by frame in the form of message. According to the Modbus-RTU protocol, when the free time of no transmission in communication data lines is more than the transmission time of 3.5byte, it indicates that a new start of communication frame.




FC155 series inverter has built-in the Modbus-RTU communication protocol, and is applicable to

response the slave “Inquiry/command” or doing the action according to the master’s “Inquiry / Command” and response to the data.


Here, master is personnel computer (PC), industrial machine or programmable logical controller (PLC), and the slave is inverter. Master not only visits some slave, but also sends the broadcast information to all the slaves. For the single master “Inquiry/Command”, all of slaves will return a signal that is a response; for the broadcast information provided by master, slave needs not feedback a response to master machine.


Communication data structure

Modbus protocol communication data format of FC155 series inverter is shown as following. The inverter only support the reading and writing of Word type parameters, the corresponding reading operation command is “0x03”, the writing operation command is “0x06”. The writing and reading operation of byte or bit is not supported.




In theory, the host computer can continuously read several function codes once (that is, the maximum value of “n” is 12), but note that not to jump across the last function code in this function group to avoid the wrong reply.





If the wrong communication frame was detected by the slave or other reasons caused the failure of reading and writing, the wrong frame will be replied.



RTU frame format

Frame start (START)	More than the 3.5- character time
Slave address(ADR)	Communication address:1 to 247(0: broadcast address)
Command code(CMD)	03: Read slave parameters 06: Write slave parameters
Function code address(H)	It indicates the external parameter address of frequency inverter in hexadecimal format; There are functional code or non-functional code (such as running state parameter/ running command parameters) type parameters, for details see the address definition.
Function code address(L)	During the transmission, high bit is put in the front, and low bit is at the back.
Number of function code(H)	It indicates the number of function code ready by the frame. If it is "1", then it indicates that it reads one function code. During the transmission, high bit is put in the front, and low bit is at the back.
Number of function code(L)	Only one function code can be modified at one time without the field.
Data(H)	It indicates the replying data or the data waiting to write-in. During the transmission, high bit is put in the front, and low bit is at the back.
Data(L)	
END	3.5- character time

CRC Checking

In RTU mode, messages include an error-checking field that is based on a CRC method. The CRC field checks the contents of the entire message. The CRC field is two bytes, containing a 16-bit binary value. The CRC value is calculated by the transmitting device, which appends the CRC to the message. The receiving device recalculates a CRC during receipt of the message, and compares the calculated value to the actual value it received in the CRC field.

If the two values are not equal, that means transmission is error

The CRC is started by 0xFFFF. Then a process begins of applying successive eight-bit bytes of the message to the current contents of the register. Only the eight bits of data in each character are used for generating the CRC. Start and stop bits, and the parity bit, do not apply to the CRC. During generation of the CRC, each eight-bit character is exclusive ORed with the register contents. Then the result is shifted in the direction of the least significant bit (LSB), with a zero filled into the most significant bit (MSB) position. The LSB is extracted and examined. If the LSB was a 1, the register is then exclusive ORed with a preset, fixed value. If the LSB was a 0, no exclusive OR takes place. This process is repeated until eight shifts have been performed. After the last (eighth) shift, the next eight-bit byte is exclusive ORed with the register's current value, and the process repeats for eight more shifts as described above. The final contents of the register, after all the bytes of the message have been applied, is the CRC value.

When the CRC is appended to the message, the low-order byte is appended first, followed by the high-order byte.

```
unsigned int crc_chk_value(unsigned char *data_value,unsigned char length
{
    unsigned int crc_value=0xFFFF;
    int i;
    while(length--)
    {
        crc_value^= *data_value++;
        for(i=0;i<8;i++)
        {
            if (crc_value&0x0001)
            {
                crc_value=(crc_value>>1)^0xa001;
            }
            else
            {
                crc_value=crc_value>>1;
            }
        }
    }
    return (crc_value);
}
```

Definition of communication parameter address

Read and write function-code parameters (Some functional code is not changed, only for the manufacturer use.)

The group number and mark of function code is the parameter address for indicating the rules.

High level bytes: F0~FF(Group F0-FF), d0-dF(Group d0-d6F)

Low level bytes: 00 to FF

For example: F0-20, address indicates to 0xF014.

Note:

Some parameters cannot be changed during operation, some parameters regardless of what kind of state the inverter in, the parameters cannot be changed. Change the function code parameters, pay attention to the scope of the parameters, units, and relative instructions.

Function code group	Communication inquiry address	Inquiry address When Communication modifies RAM
F0~FF	0xF000~0xFFFF	0x0000~0x0FFF
d0~dF	0xD000~0xDFFF	0x4000~0x4FFF

Besides, due to EEPROM be frequently stored, it will reduce the lifetime of EEPROM. In the communication mode, and some function codes don't have to be stored as long as change the RAM value.

Stop/start parameter

Parameter address	Parameter description	Parameter address	Parameter description
1000	Communication set value(-10000 ~ 10000)(Decimal)	1011	PID feedback
1001	Running frequency	1012	PLC process
1002	DC Bus voltage	1013	Pulse input frequency, unit: 0.01KHz
1003	Output voltage	1014	Feedback speed
1004	Output current	1015	Remaining running time
1005	Output power	1016	Voltage before AI1 correction
1006	Output torque	1017	Voltage before AI2 correction
1007	Running speed	1018	Voltage before AI3 correction
1008	DI input terminal	1019	Linear speed
1009	DO output terminal	101A	Present power-on time
100A	AI1 voltage	101B	Present running time
100B	AI2 voltage	101C	Pulse input frequency, unit:1Hz
100C	AI3 voltage	101D	Communication setting value
100D	Counting value input	101E	Actual feedback speed
100E	Length value input	101F	Main frequency X display
100F	Load speed	1020	Auxiliary frequency Y display
1010	PID setting		

Note:

Communication setting value is the percentage of relative value, 10000 corresponds to 100%, -10000 correspond to -100.00%.

Control command input frequency inverter: (write in only)

Command word address	Command function
2000	0001: Forward running
	0002: Reverse running
	0003: Forward jog
	0004: Reverse jog
	0005: Free stop
	0006: Decelerating stop
	0007: Fault reset

Read inverter status: (read only)

Command word address	Command function
3000	0001: Forward running
	0002: Reverse running
	0003: Stop

Parameter locking password collation: (If the feedback is the 8888H, it indicates the password collation passed)

Password address	Contents of input password
1F00	*****

Digital output terminal control: (write in only)

Address Of locking password command	Contents of locking password command
2001	BIT0: DO1 output control BIT1: DO2 output control BIT2: Relay 1 output control BIT3: Relay 2 output control BIT4: FMR output control

Analog output AO1 control: (write in only)

Command word address	Command function
2002	0~7FFF indicates 0%~100%

Analog output AO2 control: (write in only)

Command word address	Command function
2003	0~7FFF indicates 0%~100%

Pulse output control: (write in only)

Command word address	Command function
2004	0~7FFF indicates 0%~100%

Inverter fault description:

Inverter fault description	Inverter fault information	
8000	0000: No fault 0001: Reserved 0002: Acceleration over current 0003: Deceleration over current 0004: Constant speed over current 0005: Acceleration over voltage 0006: Deceleration over voltage 0007: Constant speed over voltage 0008: Buffer resistor fault 0009: Under-voltage fault 000A: Frequency inverter overload 000B: Motor overload 000C: Input phase failure 000D: Output phase failure 000E: IGBT overheat 000F: External equipment fault 0010: Communication fault 0011: Contactor fault 0012: Current detection fault 0013: Motor auto-tuning fault 0014: Encoder/PG fault	0015: EEPROM read-write in fault 0016: Frequency inverter hardware fault 0017: Short circuit to ground fault 0018: Reversed 0019: Reversed 001A: Accumulative running time reached 001B: User-defined fault 1 001C: User-defined fault 2 001D: Accumulative power-on time reached 001E: Off load 001F: PID lost during running 0028: Fast current limit fault 0029: Motor switchover fault during running 002A: Too large speed deviation 002B: Motor over-speed 002D: Motor overheat 005A: Encode lines setting fault 005B: Not connect to the encoder 005C: Initial location fault 005E: Speed feedback fault

Group FA Communication parameters

Function Code	Parameter Name	Setting Range	Default
FA-00	Communication type selection	0: Modbus protocol	0

FC155 currently supports Modbus protocol.

Function Code	Parameter Name	Setting Range	Default
FA-01	Baud ratio	Unit's digit(Modbus baud ratio) 0:300BPS 1:600BPS 2:1200BPS 3:2400BPS 4:4800BPS 5:9600BPS 6:19200BPS 7:38400BPS	5

This parameter is used to set the data transfer rate from host computer and the frequency inverter. Please note that baud ratio of the host computer and the inverter should be consistent. Otherwise, the communication is impossible. The higher the baud ratio is, the faster the communication is.

Function Code	Parameter Name	Setting Range	Default
FA-02	Modbus data format	0: No check, data format <8,N,2> 1: Even parity check, dataformat<8,E,1> 2: Odd Parity check, dataformat<8,O,1> 3: No check, data format <8,N,1> Valid for Modbus	0

The host computer and frequency inverter setup data format must be consistent, otherwise, communication is impossible.

Function Code	Parameter Name	Setting Range	Default
FA-03	Broadcast address	0~247, 0 is broadcast address	1

When the local address is set to 0, that is, broadcast address, it can realize the broadcast function of host computer.

Function Code	Parameter Name	Setting Range	Default
FA-04	Modbus response delaytime	0~20ms(only valid for Modbus)	2ms

Response delay time: it refers to the interval time from the inverter finishes receiving data to sending data to the host machine. If the response time is less than the system processing time, then the response delay time is based on the time delay of the system processing time. If the response delay time is more than the system processing time, after the system processes the data, it should be delayed to wait until the response delay time is reached, then sending data back to host machine.

Function Code	Parameter Name	Setting Range	Default
FA-05	Communication interface timeout	0.0s(invalid) 0.1s~60.0s	0.0s

When the function is set to 0.0s, the communication interface timeout parameter is invalid.

When the function code is set to time value, if the interval time between the communication and the next communication is beyond the communication timeout, the system will report communication failure error (Err16). At normal circumstances, it will be set as invalid. If in the continuous communication system, set this parameter, you can monitor the communication status.

Function Code	Parameter Name	Setting Range	Default
FA-06	Communication protocol selection	Unit's digit(Modbus)	1
		0: Non-standard Modbus protocol 1: Standard Modbus protocol	

FA-06=1: Select standard Modbus protocol.

FA-06=0: When reading the command, the slave machine return is one byte more than the standard Modbus protocol's, for details, refer to communication data structure of this protocol.

Function Code	Parameter Name	Setting Range	Default
FA-07	Communication reading current resolution	0: 0.01A 1: 0.1A	0

It is used to confirm the unit of current value when the communication reads the output current.